

TheWizCorner.hyper

COLLABORATORS

	<i>TITLE :</i> TheWizCorner.hyper		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		December 6, 2024	

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME

Contents

1	TheWizCorner.hyper	1
1.1	The Wizard Corner (Tue Nov 3 15:03:32 1992)	1
1.2	The Wizard Corner : Introduction	1
1.3	The Wizard Corner : The 'pvcall' command	2
1.4	The Wizard Corner : Description of internal memory formats	10
1.5	The Wizard Corner : The bases	11
1.6	The Wizard Corner : main base (pvcall 36)	11
1.7	The Wizard Corner : eval base (pvcall 30)	15
1.8	The Wizard Corner : arexx base (pvcall 31)	16
1.9	The Wizard Corner : debug base (pvcall 32)	16
1.10	The Wizard Corner : file base (pvcall 33)	20
1.11	The Wizard Corner : general base (pvcall 34)	20
1.12	The Wizard Corner : list base (pvcall 35)	22
1.13	The Wizard Corner : screen base (pvcall 40)	26
1.14	The Wizard Corner : memory base (pvcall 41)	32

Chapter 1

TheWizCorner.hyper

1.1 The Wizard Corner (Tue Nov 3 15:03:32 1992)

Contents:

- Introduction
- The 'pvcall' command
- Description of internal memory formats
- The bases

All bases:

- main base (pvcall 36)
- eval base (pvcall 30)
- arexx base (pvcall 31)
- debug base (pvcall 32)
- file base (pvcall 33)
- general base (pvcall 34)
- list base (pvcall 35)
- screen base (pvcall 40)
- memory base (pvcall 41)

Various:

- Back to main contents

1.2 The Wizard Corner : Introduction

WARNING !!! ONLY READ IF YOU THINK YOU ARE VERY EXPERIENCED WITH
POWERVERISOR!

READ THE ABOVE STATEMENT AGAIN! (BUT DON'T GO IN AN INFINITE LOOP)

This file contains all information for the experienced script writer.
It explains the powerful pvcall command and lists the contents of
some internal PowerVisor data structures. With the information contained
in this chapter in combination with the Scripts chapter you can make very
powerful scripts. Some examples are given in the 'Source' subdirectory.

Note that there are include files (both .h and .i) for all

structures given in this file. These include files can be found in the PVDevelop/include/PV subdirectory.

For SAS/C users there is also 'PVCallStub.lib'. Using this library you can more easily call the pvcall routines from C. You can find this library in PVDevelop/lib.

If you want some examples you can look in the 'Source' subdirectory. This directory contains sources in C and machinelanguage using the PVCallTable and other internal variables.

1.3 The Wizard Corner : The 'pvcall' command

The pvcall command can be used to access internal variables and to install some extra features. The first argument of 'pvcall' is the number of the function you want to use (see below for a list of all functions). After this number follow the extra arguments (if any). Note that not all 'pvcall' functions are callable from within PowerVisor. Some are only intended to be called from within a machinelanguage script. To call a 'pvcall' function from within a machinelanguage script you can use the PVCallTable (offset 34 in the PowerVisor-port). This is a pointer to the table containing all pointers to the 'pvcall' functions. The pointer to the PVCallTable is also automatically available if your machinelanguage routine is executed from within PowerVisor (in register a2) (see the Scripts chapter for more information about machinelanguage scripts). The return value from these functions is always in d0. If a certain pvcall function is only available from machinelanguage an asterix ('*') is put after the number. All functions callable from both machinelanguage and PowerVisor expect their arguments on a commandline. If you want to use any of these functions in machinelanguage you have to build a commandline and provide the pointer to it in a0. Except for the 'Install<xxx>Cmd' functions ('Pre' command, 'Post' command, 'Quit' command and 'Snap' command) all functions preserve registers d2-d7 and a2-a6. The 'Instal<xxx>Cmd' functions preserve d2-d7 and a3-a6.

Number	Function
0	Create a new PowerVisor function <name> <address of routine> this is a pointer to a machinelanguage routine. When this routine is called, a0 points to the arguments and a2 points to the 'PVCallTable'.
1	Generate an error <error number>
2	Advance history buffer one line. Nothing happens if this line is the last. This function updates 252:4 in MainBase.
3	Lower history buffer one line. Nothing happens if this line is the first. This function updates 252:4 in MainBase.

- 4 Get current history line and copy to stringgadget buffer.
The current history line is the line pointed to by 252:4 in MainBase. If 252:4 is 0 the stringgadget buffer is cleared.
 - 5 Refresh the stringgadget. Use this function after you have changed something in the stringgadget buffer.
 - 6 Install a 'Pre' command. This is a command that is executed before the commandline is parsed that is just typed in by the user. The command can find the pointer to the commandline in 'ScreenBase' (the stringgadget buffer) and can make changes. See the Technical information chapter for the exact moment of the execution of this command. When you generate an error in the 'Pre' command, you will prevent further execution (The user can override both the 'Pre' and 'Post' commands with the '\ ' prefix commandline operator).
 <commandstring>
 - 7* Evaluate an expression.
All expression features that PowerVisor supports are supported by this function (even groups).
 <a0 = pointer to expression>
 -> <a0 = pointer after expression or 0 if error (flags)>
 -> <d0 = resulting value>
 - 8 Remove a variable, special variable, constant or function. Be careful with this command since you can remove internal variables like 'rc', 'mode' and 'error' with this function. Removing these variables will certainly do no good.
 <name>
 - 9* Parse a string from the commandline.
The '\ ' and '..' (strong quote) operators are supported. Note that you are NOT responsible for freeing the string. The string is automatically added to the autoclear list. This also means that you must copy the string if you want to remember it permanently.
 <a0 = commandline>
 -> <a0 = pointer after string or 0 if error (flags)>
 -> <d0 = pointer to string>
 - 10 Copy string to the stringgadget buffer
 <string>
 - 11 Add string to the history buffer. Note that the PowerVisor history buffer never contains two equal history lines after each other. This function checks if the previous history line is equal to the one you are going to add. If they are equal nothing happens
 <string>
 - 12 Get address of the stringgadget buffer
 -> <address>
 - 13 Append string to the stringgadget buffer
 <string>
-

- 14 Skip spaces. This command skips all spaces in a string (',' chars are also considered spaces).
 <string>
 -> <pointer to first non space character>
- 15 Set cursor position in stringgadget. Use this command to set the cursor position where it must be the next time a 'Scan' is executed. The internal 'Scan' routine is called to get the commandline and for the scan command.
 <position>
- 16 Install a 'Post' command. This is a command that is executed after the commandline is parsed and executed that was typed in by the user.
 <commandstring>
- 17 Set debug mode for PowerVisor.
 When debug mode is on, PowerVisor prints each command before it is executed (after alias expansion) and also prints the return code of each command. This is useful for debugging recursive aliases, scripts, macros and other special things.
 <debug number> = 0 for no debug, 1 for debugging info
- 18 Get execution level
 -> <execlevel>
- | | | |
|----|---|--|
| 0 | = | commandline |
| 1 | = | script |
| 2 | = | attach (IDC) |
| 3 | = | for command |
| 4 | = | to command |
| 5 | = | with command |
| 6 | = | tg command |
| 7 | = | on command |
| 8 | = | refresh |
| 9 | = | group command |
| 10 | = | snap command |
| 11 | = | intuition handler command |
| 12 | = | quit handler command |
| 13 | = | signal handler command |
| 14 | = | OBSOLETE |
| 15 | = | called from 'ExecCommand' portprint function |
| 16 | = | Pre command |
| 17 | = | Post command |
- 19 OBSOLETE
- 20 Get mStringInfo. Note that when you change something in this structure, you will probably have to call 'pvcall 52' or 'pv 5' to remake the stringgadget.
 -> <pointer to StringInfo>
 Fields in the StringInfo structure.
- | offs | size | function |
|-------|------|------------|
| ----- | | |
| 0 | 4 | Buffer |
| 4 | 4 | UndoBuffer |
| 8 | 2 | BufferPos |
-

- | | | | |
|--|----|---|-----------|
| | 10 | 2 | MaxChars |
| | 12 | 2 | DispPos |
| | 14 | 2 | UndoPos |
| | 16 | 2 | NumChars |
| | 18 | 2 | DispCount |
| | 20 | 2 | CLeft |
| | 22 | 2 | CTop |
| | 24 | 4 | LayerPtr |
| | 28 | 4 | LongInt |
| | 32 | 4 | AltKeyMap |
- 21 Get Snap Buffer. This buffer is 120 bytes long.
-> <pointer to snap buffer>
- 22 Install command before 'snap'. Using 'pvcall 21' you can change something in the string that is snapped. If you return 0 from this command the 'snap' will not happen.
<commandstring>
- 23 OBSOLETE
- 24 Beep
<period>
<time>
- 25 Get address of variable or function
<variable name>
-> <address or null if it does not exists>
- 26 OBSOLETE (Since V1.10)
- 27 Create constant
<name>
<value>
- 28 Compare two strings
<pointer to string 1>
<pointer to string 2>
<length>
-> -1 if equal
- 29 Call machinelanguage script
<pointer>
Routine is called with a0 the pointer to the rest of the commandline, a1 the pointer to the RC variable, a2 the pointer to the PVCallTable and d6 equal to 0 (d6 is normally the number of arguments but 'pvcall 29' does not allow you to give arguments to the routine).
The result of this 'pvcall' is the result from the routine in d0.
- 30 EvalBase
-> <EvalBase>
- 31 ARexxBase
-> <ARexxBase>
-

```

32     DebugBase
       -> <DebugBase>

33     FileBase
       -> <FileBase>

34     GeneralBase
       -> <GeneralBase>

35     ListBase
       -> <ListBase>

36     MainBase
       -> <MainBase>

37     Routines. You may change this routine table but if you do so
       you must make sure that the list remains sorted (at least
       sorted for the first letter).
       Note that this table actually points into the RexxList
       table containing all Rexx commands (see 'pvcall 39').
       Note that <type> is not used by PowerVisor but is used by
       the ARexx interpreter
       -> <pointer to routine table>
           <pointer to string>.L <type>.L <pointer to routine>.L
           .
           .
           .
           0.L 0.L

38     Mode masks and values. You may change this table. This list
       need not be sorted
       -> <pointer to mode routine table>
           <pointer to string>.L <mask>.L <value>.L
           .
           .
           .
           0.L

39     RexxList. You may change this table. The first part of this
       table consists of all PowerVisor functions. The second part
       of table (also pointed to by 'pvcall 37') consists of all
       PowerVisor commands.
       -> <pointer to rexx command list>
           <pointer to string>.L <type>.L <pointer to routine>.L
           .
           .
           .
           0.L 0.L 0.L
       <type>
           0 = Normal function, returns number
           1 = String function, returns string

40     ScreenBase
       -> <ScreenBase>

41     MemoryBase
       -> <MemoryBase>

```

- 42 OBSOLETE
- 43 Get pointer to stringgadget
 -> <stringgadget>
 Fields in the StringGadget structure.
 offs size function

 0 4 NextGadget
 4 2 LeftEdge
 6 2 TopEdge
 8 2 Width
 10 2 Height
 12 2 Flags
 14 2 Activation
 16 2 GadgetType
 18 4 GadgetRender
 22 4 SelectRender
 26 4 GadgetText
 30 4 MutualExclude
 34 4 SpecialInfo
 38 2 GadgetID (not used by PowerVisor)
 40 4 UserData (not used by PowerVisor)
- 44 OBSOLETE
- 45 OBSOLETE
- 46* Error handler. The error handler executes a routine (pointer
 in a5). If there is any error in the routine, control will
 return back to after the call of this routine (the 'Z' flag
 will be set to indicate that there was an error). All registers
 are preserved for the routine.
 <a5 = pointer to routine>
- 47 Install a command that will be executed before PowerVisor
 quits. Using this function you can cleanup your memory
 before it is too late. If you return 0 from this function
 the quit will not happen.
 <commandstring>
- 48 Search the alias list and return the converted command. If the
 command is not in the alias list the original commandline is
 returned. Note that this function always returns a pointer to
 a new string. You must free this string later with 'pvcall 51'.
 <string>
 -> <new string> (PV block)
- 49* Add a memory region allocated with 'pvcall 50' to the
 autoclear list. The autoclear list contains at most 10
 (by default, you can change this value in 'MemoryBase')
 allocations. If more than 10 allocations are added the
 last allocation (timewise) is removed and freed. This means
 that this method is not absolutely safe, but safe enough
 for most purposes. The autoclear list is mostly used for
 strings.
 Note that it is not possible to remove something from this
-

list. This means that once some pointer is added you may never free the pointer yourselves.

PowerVisor also frees all memory in this list before quitting. Note that PowerVisor uses this list for all strings and string pointers the user uses.

<d0 = pointer>

-> Z flag is set if there was an error

50* Allocate a block of memory. The memoryblock allocated with this function is called a PV block (do not confuse with PV memoryblock since this is something completely different). A PV block is a pointer after the size. This size is contained in a word if the block is smaller than a 65533 bytes. Else it is contained in a longword.

Note that you must explicitly free this block with 'pvcall 51' except if you add this block to the autoclear list with 'pvcall 49' or to the global autoclear list with 'pvcall 55'.

<d0 = size>

-> <d0/Z flag = pointer to PV block or 0 if error>

51* Free a PV block. Do not free a PV block when it is added to the autoclear list using 'pvcall 49' or when it is added to the global autoclear list with 'pvcall 55'. Generally it is not safe to free memory not allocated with 'pvcall 50' (there are exceptions like 'pvcall 48' for example).

<a0 = pointer>

52 Compute the gadget and the intuition signal bits. Use this function when you have changed something to the StringInfo structure or the Gadget structure, or when you have changed the IDCMP values for the PowerVisor window.

53* Print a string. The printing will stop when the 0 character is encountered in the string or when d3 characters are printed. You may also enclose linefeed characters in the string (ascii 10).

<a0 = pointer to string>

<d3 = length>

54* Print a number. Note that this function may be interrupted by the user. If you want to be absolutely sure you should use the errorhandler ('pvcall 46') for this routine. Note that the previous routine ('pvcall 53') is safe and can't be interrupted.

<d0 = number>

55* Add a pointer to a PV block to the global autoclear list. This is the list where all allocations from the 'alloc' function reside. Note that when you have added the pointer to this list you must not forget to remove the pointer from the list when you free the PV block with 'pvcall 51' (Use 'pvcall 56' for this purpose). (Use the showalloc command to see all allocations in this list).

<d0 = pointer to PV block>

-> <Z flag is true if not enough memory to add it>

- 56* Remove a pointer to a PV block from the global autoclear list.
Note that you are still responsible for freeing the PV block.
<a0 = pointer to PV block>
- 57* Close a PV handle.
You must remember that when you close a standard PV handle
(like the PV handle for the help file), you MUST set the handle
value in the corresponding base to 0. Otherwise PowerVisor will
try to close the file again.
<d1 = pointer to PV handle>
- 58* Reallocate a PV memory block.
<a0 = pointer to PV memory block>
<d0 = new size (if 0 block is freed)>
-> <a0 = pointer to the same PV memory block (unchanged)>
-> <d0/Z flag = pointer to memory or 0 if no success>
- 59 OBSOLETE (Since V1.32)
- 60 OBSOLETE
- 61* Refresh a logical window
<a0 = pointer to logical window>
- 62* Snap a word from a position in a logical window
<a0 = pointer to logical window>
<d0 = x position (relative to physical window)>
<d1 = y position>
<a1 = buffer for word>
<d2 = length of buffer>
-> <d0/Z flag = resulting length of buffer or 0>
- 63* Disassemble some memory
<a0 = pointer to string space (make it big enough)>
<d0 = address to disassemble>
<a6 = pointer to library (or NULL), this is in fact the
contents of the 'a6' variable. When a6 <> 0 PowerVisor
will disassemble library calls with the correct
names instead of the offset>
-> <d0 = number of bytes disassembled>
-> <a0 = pointer to end of string>
- 64 Disassemble some memory. Commandline version
<string pointer>
<address>
<library pointer or 0>
-> <number of bytes disassembled>
- 65 OBSOLETE
- 66* Allocate some memory in the internal PowerVisor memory pool.
All memory allocated here is automatically freed when
PowerVisor quits. This function represents the lowest level
of allocation routines in PowerVisor. Normally you do not
need this function. Use the higher level functions instead
(see above)
<d0 = size in bytes>
-

- <d1 = attributes like MEMF_CHIP and MEMF_CLEAR>
-> <d0/Z flag = pointer to allocated memory or 0>
- 67* Free some memory allocated with 'pvcall 66'. This function represents the lowest level of allocation routines in PowerVisor. Normally you do not need this function. Use the higher level functions instead (see above)
<a1 = pointer to memory allocated with 'pvcall 66'>
<d0 = size in bytes>
- 68* Reallocate some memory in the internal PowerVisor memory pool. This is memory allocated with 'pvcall 66'. This function represents the lowest level of allocation routines in PowerVisor. Normally you do not need this function. Use the higher level functions instead (see above)
<a1 = pointer to memory allocated with 'pvcall 66'>
<d0 = old size in bytes>
<d1 = new size in bytes>
<d2 = attributes (MEMF_CHIP) for the new block. These attributes are only used when the block must be moved because there is not enough room to grow a block>
-> <d0/Z flag = pointer to new block> Note that when the allocation failes, the old block is NOT freed


1.4 The Wizard Corner : Description of internal memory formats

Almost all memory in PowerVisor is allocated in the internal memory management system. Normally you don't need to concern yourselves with that system since the higher level routines take care of it. So you should use 'alloc()', 'free()', 'realloc()', 'pvcall 49', 'pvcall 50', 'pvcall 51', 'pvcall 55', 'pvcall 56' and 'pvcall 58' to handle memory instead of 'pvcall 66', 'pvcall 67' and 'pvcall 68'. Except maybe in some rare cases.

Here are all the highlevel memory allocation elements used by PowerVisor :

PV block

A PV block is a pointer to memory. It is used very often. You can use the 'pvcall 50' and 'pvcall 51' functions to allocate or free such blocks. Be careful when you free PV blocks that you have not allocated. If you want to be totally safe you should always clear the variable in the appropriate base when you free a PV block. If it is absolutely unsafe to free a certain PV block, a warning will be given in the description (see below). Otherwise you may assume that you can use the PV block.




```

|          PV block points to this
|
+----- Size is 2 bytes or 4 bytes long
          If size is 2 bytes long the PV block will not be
          long word aligned.

```

PV memory block

A PV memory block is a relocatable piece of memory. You can use 'pvcall 58' to manage this memory. Note that after a reallocmem ('pvcall 58') the memory block can be moved to another place.



PV handle

PV handles are filehandles used by PowerVisor for buffered file IO. The only operation you can do on a PV handle is 'pvcall 57'.

EXEC block

A normal block allocated with AllocMem ('pvcall 66') (NOT with the Exec AllocMem).

DOS file

A normal DOS filehandle (BPTR).

1.5 The Wizard Corner : The bases

The rest of this chapter is dedicated to the internal data structures. You can get the pointers to these structures with the 'pvcall' commands. Read-only fields are indicated with an asterix ('*') in front of the line. A read-only field does not always mean that changing it may harm PowerVisor. It can also indicate that PowerVisor only uses the field once and changing it won't have any effect. All other fields can be modified but you must make sure that you follow the conventions: A PV block must remain a PV block and so on. You can use 'pvcall 51' to free a PV block. When there is some restriction on the use of an internal variable it is mentioned in the list.

Note that all structures described below are also available in include file form (both .h and .i include files). See the 'PVdevelop' subdirectory.

1.6 The Wizard Corner : main base (pvcall 36)

Offset	Size	Function
* 0	2	OS version (1 if 2.0 or higher)
* 2	4	DosBase

```

* 6      4      IntuitionBase
* 10     4      GraphicsBase
* 14     4      UtilityBase (0 in AmigaDOS 1.2/1.3 version)
* 18     4      ExpansionBase
* 22     4      DiskFontBase
* 26     4      PowerVisorBase
* 30     4      CLI commandline for PowerVisor
  34     4      If TRUE PowerVisor is detached
  38     4      Pointer to error file handle (DOS file)
< 42     8      >
  50     2      Speed of refresh
  52     2      Refresh counter
  54     4      Command that is refreshing (PV block)
  58     (2+2)*6 Codes (WORD) /Qualifier (WORD) table

                                   Key      Default code  Default Qualifier
                                   -----
                                   Break   ESC          none
                                   HotKey  /            right-shift+right-alt
                                   Pause   HELP        right-alt
                                   NextWin TAB         none
                                   HistUp  UPKEY       none
                                   HistDo  DOWNKEY     none

Same keys as in 'prefs key' command
  82     1      If equal to 1 we are in PowerVisor debug mode
              (see 'pvcall 17')
< 83     3      >
  86     4      'Pre' command (PV block)
  90     4      'Post' command (PV block)
  94     4      'Quit' command (PV block)
  98     4      Pointer to last history string in history buffer
              (or 0 if the history buffer is empty). This is
              the first history line that is going to be deleted
              when there are too many lines in the history
              buffer. For the format of history lines see below
  102    2      Last error code
  104    2      Execution level (pvcall 18)
* 106    (4+4)*6 Signal bitnumbers (LONG) and signal sets (LONG)

Hold
  Sending this signal to PowerVisor will cause
  PowerVisor to reopen it's screen after a
  'hold'.
PortPrint
  Use this signal bit in conjunction with
  sending a message on the PowerVisor port.
IDC
  (Input Device Command) Using this signal you
  can execute IDC commands.
GadgetRefresh (to PowerVisor.task)
  Say to PowerVisor.task that the stringgadget
  needs refreshing.
PVToFront (to PowerVisor.task)
  Say to PowerVisor.task that PowerVisor should
  come to the front. Sending this signal also
  causes a 'Hold' signal to PowerVisor.

```

InterruptPV
Interrupt PowerVisor.

* 154	4	PowerVisor.task
* 158	4	Input request block
* 162	4	Input device port
166	4	Pointer to first history line

The format of one history line is the following :

<next>.L <prev>.L <Size>.W <string>

One history line is a simple EXEC block. If you want to free one you must make sure that you use <Size>.W for size, and that the double linked list remains correct, 166:4 (this field) must point to the first history line (may be 0 if there are no history lines) and 98:4 must point to the last history line in the history buffer. Note that <prev>.L is 0 for the first history line (the one pointed to by 166:4) and <next>.L is 0 for the last history line (the one pointed to by 98:4).

Also make sure that 252:4 (the pointer to the history line we are scanning) points to 0 (the easy way) or points to an existing history line (the hard way) when you delete a line. If you delete or add a history line you must also make sure to update 170:4 (this is not necessary if you use the standard pvcall functions to add a history line)

170	4	Number of lines in history
174	4	Maximum number of lines in history (default 20)
178	32	Code table
		Each bit in this table represents a code. If the bit is 1 this means that there is a macro with this code defined.
210	4	Pointer to first alias structure (or 0 if there are no aliases)

Each alias structure looks as follows :

offs	size	function

0	4	Next alias string (0 for last)
4	4	Previous alias string (0 for first)
8	4	Pointer to command string (PV block)
12	4	Pointer to alias string (PV block)

It is safe to change this list and to replace strings as long as you respect the double linked list and give valid PV blocks in each structure. You may free the two strings (with pvcall 51) if you replace them with other PV blocks. Note that an alias structure is an EXEC block.

214	4	Pointer to scriptline
		Make sure that you respect the maximum line length (see 218:2) when you change this pointer.

```

218      2      Default line length
220      1      Character used for comments (default ;)
221      1      Character used for feedback suppress (default ~)
222      1      Character used for quick exec (default \)
223      1      Character used to suppress output (default -)
224      1      Last command
                0 normal command
                1 memory command
                2 unasm
                3 view
< 225      1      >
< 226      1      >
* 227      1      If 1 we are in hold mode (screens are closed)
< 228      1      >
229      1      Input device command number

```

nr	name	function
1	NEXTWIN	Make next logwin the scroll window
2	SCROLL1UP	Scroll logwin one line up
3	SCROLLPGUP	Scroll logwin five lines up
4	SCROLLHOME	Scroll to home position
5	SCROLLEND	Scroll to bottom position
6	SCROLL1DO	Scroll one line down
7	SCROLLPGDO	Scroll five lines down
8	SCROLLRIGHT	Scroll to the complete right side
9	SCROLL1RI	Scroll one column right
10	SCROLL1LE	Scroll one column left
11	DSCROLL1UP	Scroll debug window one word up
12	DSCROLLPGUP	Scroll debug window 20 words up
13	DSCROLL1DO	Scroll debug window one word down
14	DSCROLLPGDO	Scroll debug window 20 words down
15	DSCROLLPC	Scroll debug window to PC
16	EXEC	Execute command (ptr in 230:4)
17	SNAP	Snap string (ptr in 230:4)
18	DSCROLL1IUP	Scroll one instruction up
19	DSCROLL1IDO	Scroll one instruction down

```

230      4      Pointer to argument for IDC command EXEC.
234      14     List containing the macros (key attachements).
                One macro node looks like this :

```

offs	size	function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (not used)
10	4	ln_Name (not used)
14	2	Code for key
16	2	Qualifier

	18	4	Commandstring (EXEC block)
	22	2	Length of command string
	24	2	Flags
			INVISIBLE = 1 If set, command is not added to stringgadget before it is executed. It is executed with IDC commands
			SNAP = 2. If set, command is snapped to the current position in the stringgadget. Nothing is executed
			HOLDKEY = 4. If set, the attached key is not removed from the input event list
248	4		Pointer to workbench message (or 0 if started from cli)
252	4		Pointer to history line we are scanning, if 0 we are typing a new line or the stringgadget is empty (See the history variables above for more information). This pointer is used by the general input routine and by the input handler to scan through the history buffer. You can use pvcall 2 and pvcall 3 to change this pointer or you can change it yourselves
256	22		Input event used by the 'AddEvent' command
* 278	4		LayersBase
< 282	4		>
* 286	1		If true this is the master PowerVisor

1.7 The Wizard Corner : eval base (pvcall 30)

Offset	Size	Function
< 0	8	>
8	8	Variables and functions (PV memory block) Format for variables and functions: <Value or pointer>.L <Name len>.B <Type>.B <Name> [<pad>.B] [<spec>.L] <Type> 0 = variable 1 = constant 2 = special 3 = function <spec> is pointer to routine to call when variable changes (only when <Type> == 2) Note that you better not change the variables 'error' and 'rc'. These should remain on the same position. This is because PowerVisor accesses these variables with a fixed offset from the start of the variable list.
16	18	Operator priorities One byte for each operator. Priorities between 1 and 10 are supported (1 is low priority)

Op	Function	Default priority
^	Xor	4
&	And	5
	Or	3
*	Multiply	10
/	Divide	10
%	Modulo	10
+	Add	9
-	Subtract	9
>	Greater than	7
<	Less than	7
>=	Greater or equal	7
<=	Less or equal	7
!=	Not equal	6
==	Equal	6
<<	Left shift	8
>>	Right shift	8
&&	Logical and	2
	Logical or	1

1.8 The Wizard Corner : arexx base (pvcall 31)

Offset	Size	Function
* 0	4	Rexx signal bit
4	2	Sync flag (if 1 we are in Sync)
* 6	2	Hide flag (if 1 we are in Hide)

1.9 The Wizard Corner : debug base (pvcall 32)

Offset	Size	Function
* 0	4	If floatingpoint coprocessor present this variable contains 4, else 0
4	14	List containing all debug tasks. One debug node looks like this :

```
offs  size  function
```

```
-----
0     4     ln_Succ
4     4     ln_Pred
8     1     ln_Type
9     1     ln_Pri (not used)
10    4     ln_Name
14    4     MatchWord = 'DEBUG'
18    1     Mode (mode)
```

```
Nr Name      Function
-----
0  NONE      Doing nothing
```

		1	TRACE	Tracing	
		2	EXEC	Executing	
		3	FLOWT	Flow tracing (68020)	
19	1		SMode	(special mode)	
			Nr	Name	Function

		0	NORMAL	Normal debugging	
		1	TTRACE	Temporary trace	
		2	CRASH	There was a crash	
		3	BREAK	There was a breakpoint	
		4	TBREAK	Break due to trace	
		5	WAIT	Waiting for PowerVisor	
		6	ERROR	There was an error	
20	4		BPTR	to loaded segment (only with 'debug 1')	
24	4			Address of instruction to execute	
28	4			Pointer to temporary routine	
32	4			Pointer to trace exception routine	
36	4			Address to restore breakpoint (only if SMode = TTRACE)	
40	4			Additional information for tracing.	
44	1		TMode	(trace mode) <n> is 40:4	
			Nr	Name	Trace Function

		0	NORMAL	Normal	
		1	AFTER	<n> instructions	
		2	STEP	endlessly	
		3	UNTIL	until pc=<n>	
		4	REG	until register changes (OBSOLETE)	
		5	COND	until condition true	
		6	BRANCH	until branch	
		7	FORCE	force tracing (trace f)	
		8	OSCALL	until OS call used	
		9	SKIP	for trace t	
		10	QCOND	quick condition	
		11	PROF	profile tracing	
<45	1		>		
46	1		TDNestCnt		
47	1		IDNestCnt		
48	1		TaskState	(TS_READY or TS_WAIT)	
49	1		Dirty.	If 1 our debug window needs full refreshing. If 2 our source window needs full refreshing. If 3 both windows need refreshing	
50	4		TC_SIGWAIT		
54	4		Crash number		
58	4			Additional argument for some trace	

		modes
62	4	Pointer to task corresponding with debug node
66	4	Top PC visible in debug window
70	4	Bottom PC visible in debug window
<74	2	>
76	32	Number of bytes for each instruction on screen (32 bytes, one byte for each line)
108	4	Initial programcounter
112	4	Previous trapcode for task
116	8	PV memory block for symbol values. Each element in this block is a value and an offset in the following string quickblock (8 bytes per entry)
124	4	Pointer to the source structure where the program counter is located
128	8	PV memory block containing all strings for the symbols. All strings in this block are null terminated.
136	4	Linenummer in source where the program counter is located
140	14	Breakpoint list.
<154	2	>
<156	4	>
<160	2	>
<162	1	>
<163	1	>
164	4	Pointer to quit code on stack.
168	4	Original quit code. (Code that is called when the task quits).
172	4	SP
176	4	PC
180	2	SR
182	15*4	Registers
<242	16	>
258	4	Pointer to first source structure
262	4	Pointer to current source structure
266	2	If 1, logical window is locked (does not follow the program counter) (like 'source h')

One breakpoint node looks like this :

offs	size	function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (not used)
10	4	ln_Name (not used)
14	2	Number
16	4	Address of breakpoint
20	2	Original contents of memory
22	1	Type

```

T temporary breakpoint
t temporary breakpoint
  (internal)
N normal breakpoint
P profile breakpoint
C conditional breakpoint
A break after <n> passes
s temporary breakpoint
  (internal)
<23  1  >
24  4  Usage count
28  4  Additional argument
      conditional string if type is 'C'
      breaknumber if type is 'A'
32  4  Routine to jump to if a break occurs
<36  4  >

```

One source structure looks like this :

```

offs  size  function
-----
0     4     Next source structure
4     4     Previous source structure
8     4     Pointer to source filename
12    4     Size of following block
16    4     Pointer to the block with linenumber
      information. Each info block is 8
      bytes long. The first long is
      the address and the second long is
      the line number in this source
20    4     Size of the following block
24    4     Pointer to the loaded file or 0
28    4     Current linenumber for program-
      counter
32    4     Top linenumber visible in Source
      logical window
36    4     Bottom linenumber visible in Source
      logical window
40    4     Current hilighted linenumber
      (linenumber in Source logical
      window, not the linenumber in the
      file)

18    4     Current debug task
< 22  16   >
< 38  8    >
46    1     Show register info after each trace (default 1)
47    1     Give disassembly after each trace (default 1)
48    2     Number of lines to disassemble (default 5)
50    2     Show previous instruction after each trace
      (default 1)
52    2     Tab size for source level debugger (default 8)

```

1.10 The Wizard Corner : file base (pvcall 33)

Offset	Size	Function
0	4	Pointer to CLI outputhandle (DOS file)
4	4	Pointer to control file (PV handle)
8	4	Pointer to help file (PV handle)
12	4	Pointer to script file (PV handle)
16	4	Pointer to log file (DOS file)
20	4	Pointer to log logical window

1.11 The Wizard Corner : general base (pvcall 34)

Offset	Size	Function
* 0	4	Pointer to PowerVisor (process)
4	4	Lower bound for stack pointer when PowerVisor should give a 'Possible stack overflow' error. This pointer is 512 bytes away from the TC_SPLOWER value of the PowerVisor task. You can change this value if you think it is not safe enough or it is too safe. This bound is checked whenever a command is executed (a group is not a command but a group of commands) and in the recursive part of the expression evaluator.
* 8	4	Trackdisk request block
* 12	4	Trackdisk port
* 16	4	Old ExecTrapCode
* 20	4	MMUType 0 = no MMU 68851, 68030 or 68040
* 24	2	1 if 68020 or higher, else 0
* 26	4	Block with account tasks
* 30	4	Old Switch function
* 34	4	Old Alert function
* 38	4	Old AddTask function
* 42	4	Old AutoRequest function
46	4	Stack fail level (default 40)
< 50	8	>
58	14	List with freezed tasks
72	14	List with crashed tasks

One crash node looks like this :

offs	size	function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (not used)
10	4	ln_Name
14	4	Crashed task
18	4	TrapNumber
22	4	2ndInfo (from Alert)

```

26    1    0 if trap, 1 if guru, 2 if stack
        fail
<27   1    >
28    4    SP
32    4    PC
36    2    SR
38    15*4 Registers

```

86 14 List with fd-files
One fd-file node looks like this :

```

offs  size  function
-----
0     4     ln_Succ
4     4     ln_Pred
8     1     ln_Type
9     1     ln_Pri (not used)
10    4     ln_Name
14    4     Library
18    2     Bias
20    8     PV memory block containing all
        functions
28    8     PV memory block containing all
        strings
36    2     Number of functions

```

100 14 List with functions we are monitoring (see the
'AddFunc' command)
One function node looks like this :

```

offs  size  function
-----
0     4     ln_Succ
4     4     ln_Pred
8     1     ln_Type
9     1     ln_Pri (not used)
10    4     ln_Name
14    4     Library
18    2     Offset
20    4     Task to monitor (if zero, all tasks)
24    4     Usage count
28    4     Pointer to count code (EXEC block)
32    4     Size of count code
36    4     Old function to restore later
40    2     Type flags

                0 = Normal
                1 = Led
                2 = With register information
                3 = Led and register information
                8 = Exec

42    2     Position in following block where
        the last added task is added
44    8*4   8 pointers to the 8 last tasks using
        this function
76    8*56  All registers for each task (d0-d7/

```

		a0-a5)
	524	4 Ptr to command
114	34+6	The PowerVisor port. This is an Exec message port followed by a longword containing the pointer to the PVCallTable and a private word. You can find the pointer to the PVCallTable at offset 34 in this port.
< 154	1	>
155	1	Old priority (before PowerVisor set it to 4)
* 156	4	Timer device request block (for 'stack' command)
* 160	4	Timer device port
164	4	Maximum stack usage (like 'getstack' function)
168	4	Task we are looking at with 'stack' command
172	4	Number of microseconds to wait
176	4	Task we are tracking (with the 'track' command)
180	4	Pointer to the first element in the double linked track list. There is one element in this list for each 'AllocMem', 'AllocVec' or 'OpenLibrary'. One track structure looks like this :
		offs size function

	0	4 Next track structure
	4	4 Previous track structure
	8	4 Pointer to tracked data (result from 'AllocMem' or 'AllocVec' or pointer to library for 'OpenLibrary')
	12	4 Size of allocation for 'AllocMem' or 'AllocVec' or version of library for 'OpenLibrary'
	16	4 Program counter
	20	1 Type
		0 = AllocMem
		1 = OpenLibrary
		2 = AllocVec
		3 = AllocSignal
		4 = CreateMsgPort
		5 = CreateIORequest
		6 = Lock
		7 = Open
		8 = AllocRaster
	<21	3 >
184	4	Pointer to debug node we are profiling
188	4	Number of micro seconds to wait
192	4	Number of ticks the debug node was in 'WAIT' state
196	4	Number of ticks the debug node was in 'READY' state
200	8	PV memory block to profiler table

1.12 The Wizard Corner : list base (pvcall 35)

Offset	Size	Function
* 0	4	Old WindowPtr from PowerVisor process
4	4	Prompt string
8	2	Current list number
< 10	2	>
12	14	List containing all structure nodes. (Warning ! Structure nodes and structure definitions are not the same)

One structure node looks like this :

offs	size	function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (used to sort the nodes by length of name)
10	4	ln_Name
14	4	MatchWord = 'PVSD'
18	4	Pointer to string block (PV block)
22	4	Pointer to structure definition (PV block), (see below)
26	2	Length of structure

Structure definitions look like this :

```
{ <String>.L <Type>.W <Offset>.W ... } 0.L 0.L
```

<String> is a pointer to the string corresponding with the name of a structure element.

<Type>.W can be somethine like :

```
0 = byte
1 = word
2 = long
3 = string
4 = object in object (like ViewPort in Screen)
```

To do BPTR to APTR conversion you must add 128 to this word.

<Offset>.W is the offset of the element in the structure.

26	30*40	All infoblocks (see above) for all standard lists. In the following order (size is 28*40 for AmigaDOS 1.3) :
----	-------	--

```
Exec
Intb
Task
Libs
```

```

Devs
Reso
Memr
Intr
Port
Wins
Scrs
Font
Dosd
Func
Sema
Resm
Fils
Lock
IHan
FDFi
Attc
Crsh
Graf
Dbug
Stru
PubS (not in AmigaDOS 1.3 version)
Moni (not in AmigaDOS 1.3 version)
Conf
LWin
PWin

```

An infoblock is a description of a list.
One infoblock looks like this :


offs	size	function
0	4	Prompt string
4	1	Item number
5	1	Control byte. This byte controls how you should go to the start of the list.

-1 = routine (like 'DosD')
6:4 is pointer to routine to call to go to the first element of the list
-2 = structure (like 'Exec')
6:4 is pointer to pointer to structure
-3 = (like 'Fils')
6:4 is pointer to routine to call. This routine will do the complete list without any intervention at all

If Control is not equal to -1, -2 or -3 the start of the list is computed as follows :

The byte is split in two

nibbles :



The value in 6:4 is loaded. If 'llll' is equal to 0 nothing happens with this value, if it is equal to 1 you must take the indirection one step further (take the contents of the value), if it is equal to 2 you must first convert the value from BPTR to APTR before you take the contents of this value.

We continue with the value obtained from the previous algorithm and add 10:2 to it. Now we look at 'rrrr'. If it is equal to 0 we do nothing, if it is equal to 1 we take the contents of this value, if it is equal to 2 we convert the value from BPTR to APTR before we take the contents.

Now we have computed the address of the first element in the list.

6	4	Pointer to the routine to go to the base of a list or the pointer to the base of the list (what it really is depends on the value of the control byte 5:1) The routine must return the pointer to the first list element in a2. This routine may initialize d7 for use by the next element routine (see below).
10	2	Offset to add to 6:4 (depending on the control byte 5:1)
12	4	If control byte is -2 this variable contains the pointer to the structure definition (not the node) (structure definitions are described above) If control byte is -3 this variable is not used. Else this variable contains the pointer to the routine to go to the next element in the list. This routine must preserve a0 and a1. d7 is free to be used as an external

		variable (may be setup by startup function). a2 is pointer to list element currently listing. This routine must return the pointer to the next element in the list in a2 and set the Z flag to true if the end of the list is reached.
16	4	Pointer to header string
20	4	Pointer to format string (RawDoFMT format)
24	4	Argument string for 'list' command
28	1	Must contain 0
29	1	If true, 30:4 is a pointer to a structure definition (not the node) containing all the information to be printed when the 'info' command is used. Else 30:4 is a pointer to a routine doing the same thing.
30	4	Routine or structure definition. for the 'info' command. If 0, there is no more info for this list.
34	4	Pointer to routine printing one line for one element of the list. This routine expects the pointer to the list element in a2.
38	2	Offset for the name element in the structure

1.13 The Wizard Corner : screen base (pvcall 40)

Offset	Size	Function
< 0	1	>
< 1	1	>
< 2	1	>
< 3	1	>
< 4	1	>
5	1	If true PowerVisor will not clear line the next time 'Scan' is started.
< 6	1	>
< 7	1	>
< 8	1	>
< 9	1	>
* 10	4	Length of stringgadget buffer line (not used)
14	4	Pointer to stringgadget buffer
18	2	Position of cursor in stringgadget
20	(2*4)*7	Default sizes and parameters for each logical window (like 'prefs logwin' command) <columns>.W <rows>.W <mask>.W <flags>.W . (6 times for each logical window) (Main,Extra,Refresh,Debug,PPrint,Rexx,Source) .

```

76      4      Pointer to 'snap' command (PV block)
< 80    1      >
< 81    3      >
< 84    4      >
88      4      Pointer to 'Main' physical window
A physical window structure looks like this :

```

Offs	Size	Function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (not used)
10	4	ln_Name (EXEC block)
14	48	NewWindow structure
62	4	Window
<66	4	>
70	2	Last code for VANILLAKEY
72	2	Last qualifier
74	1	LeftBorder for masterbox
75	1	TopBorder
76	1	RightBorder
77	1	BottomBorder
78	4	Pointer to masterbox
82	4	Pointer to Global structure
86	14	Logical window list
<100	4	>
104	4	Gadget list (AmigaDOS 2.0 only)

```

92      4      Pointer to 'Main' logical window
A logical window structure looks like this :

```

Offs	Size	Function
0	4	ln_Succ
4	4	ln_Pred
8	1	ln_Type
9	1	ln_Pri (not used)
10	4	ln_Name (EXEC block)
14	4	pointer to box
18	2	x real coordinate (in physical window)
20	2	y real coordinate
22	2	w real width
24	2	h real height
26	2	first visible column in logical window
28	2	first visible row
30	2	current column coordinate
32	2	current row coordinate
34	2	visible width in characters
36	2	visible height in characters
38	4	flags

1	Print on file
2	Print on screen
4	Enable -MORE- check

```

8      private
16     private
32     Total home is equal to
      (0,0)
64     statusline on/off
128    breakcheck on/off
256    auto output snap
512    (if false) add scrollbar
      to logical window if 'mode
      sbar' is set
1024   (if true) always add
      scrollbar (ignore previous
      flag)

42     8      TextAttr
      A TextAttr structure looks like
      this :

      Offs  Size  Function
      -----
      0      4      Name
      4      2      YSize
      6      1      Style
      7      1      Flags

50     4      Pointer to font
54     2      Font X character width
56     2      Font Y character height
58     2      Font baseline
60     4      Pointer to physical window (MainPW)
64     2      number of columns optimal
66     2      number of rows optimal
68     2      number of lines in buffer
70     2      number of columns per line in buffer
72     4      pointer to buffer
      These is a table of (68:2)+1
      pointers to lines. Each line is
      70:2 chars long (plus one for the
      attribute in the beginning of the
      line) If this attribute is non-null
      the line will be hilighted:
          1 = hilighted
          2 = inverse video
          3 = hilighted and inverse video
76     4      Log file (DOS file)
80     2      number of lines passed (for -MORE-
      check)
<82   4      >
86     4      Pointer to extra title (user of
      logical window is responsible for
      remembering and freeing the memory
      for this title)
90     1      if TRUE we are active
91     1      TopBorder used for statusline (10 if
      statusline or 0 if no statusline)
92     2      real top coordinate
      92:2 = 20:2-91:1

```

```

94     4     userdata (used by PowerVisor)
98     2     The number of the hilghted line in
            the logical window (or -1 if no
            line is hilghted)

```

A box structure looks like this :

```

Offs  Size  Function
-----
0     4     Parent box or NULL if masterbox
4     4     Child A (not used if box is ATOMIC)
8     4     Child B
12    4     Logical window (only if box is
            ATOMIC)
16    4     Physical window
20    2     Share for child A (in % x 10)
22    1     Type
            0 UPDOWN
            1 LEFTRIGHT
            2 ATOMIC
23    1     If true our box needs a cleanup
24    1     Left border for inner box
25    1     Top border
26    1     Right border
27    1     Bottom border
28    2     x position after accounting for
            window and inner box. These
            variables define the box that we
            really can use for output (for the
            logwin)
30    2     y
32    2     w
34    2     h
36    2     x1 position for titlebar
38    2     y1
40    2     x2
42    2     y2
44    4     pointer to gadget (AmigaDOS 2.0)
            for scrollbar (GadTools)
48    4     pointer to NewGadget structure

96    4     Pointer to 'Refresh' logical window
100   4     Pointer to 'Debug' logical window
104   4     Pointer to 'Extra' logical window
108   4     Pointer to 'PPrint' logical window
112   4     Pointer to 'Rexx' logical window
116   4     Pointer to 'Source' logical window
120   4     Pointer to current logical window
124   2     location of horizontal prompt (default 1) relative
            to left side of window (plus border).
126   2     left location of stringgadget relative to
            left side of window (plus border) (default 50).
128   2     offset for right side of stringgadget relative
            to the rightside of the window (default 0).
130   4     Pointer to PowerVisor steal screen
            This is 0 if PowerVisor is on its own screen
134   4     Pointer to PowerVisor real screen

```

```

138      4      This is 0 is PowerVisor is on another screen
142      2      IntuiMsg class
144      4      IntuiMsg IAddress
148      2      IntuiMsg MouseX
150      2      IntuiMsg MouseY
152      2      IntuiMsg Qualifier
154      4      Pointer to Global

```

```

      Offs  Size  Function
-----

```

```

      0     4     ln_Succ
      4     4     ln_Pred
      8    14     Physical window list
     22     4     Pointer to active logical window
     26     4     Signal set for all physical windows
    <30     4     >

```

```

< 158      4      >
< 162      4      >
166      18*6

```

For each logical window except 'Main'.
(Note that this area is saved with 'saveconfig',
so any changes you make here are permanent when
you make a config-file)

The first 8 bytes of each entry contain the NULL
terminated string used to open the logical window
(with the predefined command). The string can be
something like :

```
'0110d ',0
```

which means :

```

go to master box
take child 0
take child 1 of this child
take child 1 of this child
take child 0 of this child
open logical window down this child

```

default strings are 'u ',0

the word after this string is the share that this
window should take (in percentages x10)
default is 300.

After the 8 bytes for the string and the word
for the share value follows the 4 words for the
position for the physical window if mode 'intui'
is true. If these positions are used, the other
share variables are ignored ('mode intui').

(Extra, Debug, Refresh, PPrint, Rexx, Source)

```

274      4      Startup flags (Updated and saved by 'saveconfig')
           bit 0 : if true we open on workbench screen
           bit 1 : if true we open on pv screen but with
                   non-backdrop screen
278      2*4      Four words describing the startup window (Updated
                   and saved by 'saveconfig').

```

		(x,y,w,h)
286	2*2	Two words describing the startup screen (like the 'prefs screen' command).
		(w,h)
290	24	24 pens (only 21 used at this moment) for fancy screens. (See the 'InstallingPowerVisor' file for more information about these pens.
314	24	24 pens for no-fancy screens.
338	4	Pointer to current pen table (one of the above tables, but you may make your own pen table and let this variable point to it)
342	6	string with -BUSY- prompt
348	6	string with -MORE- prompt
354	6	string with -WAIT- prompt
360	6	string with ----- prompt
366	4	string with ??? prompt
370	2	feedback prompt '> '
372	4	the locked logical window (this is the logical window that is waiting for input)
376	4	the pointer to the prompt string for the locked logical window
380	1	lock state, the state of the stringgadget for the locked logical window (1 is no stringgadget, 0 is normal stringgadget)
381	1	Busy mode (0 = normal, 1 = -BUSY-, 2 = a window is waiting for input)
* 382	1	GadgetExists. If 1 the stringgadget exists
< 383	1	>
384	34	Fontname (default topaz.font), area is saved with the 'saveconfig' command
418	4	Start of TextAttr. Pointer to 384:34 (fontname)
422	4	Size of font (word), style (byte) and flags (byte)
		This area is saved with the 'saveconfig' command
426	2	Height of all logical window borders
< 428	2	>
430	2	Drag tolerancy at the left of the bar between two logical windows. This value indicates the amount of pixels at the left side of this line that PowerVisor will accept as the area used to drag this line
432	2	Drag tolerancy at the top of the bar between two logical windows
434	2	Drag tolerancy at the right of the bar between two logical windows
436	2	Drag tolerancy at the bottom of the bar between two logical windows. This tolerancy value is normally larger (or just as large) as the height of the logical window border (426:2)
438	2	Horizontal size tolerancy. This is the minimum width in pixels allowed for a logical window
440	2	Vertical size tolerancy. This is the minimum height in pixels allowed for a logical window
442	4	Pointer to requester structure allocated with rtAllocRequestA in reqtools.library
* 446	4	Pointer to reqtools.library (or 0 if no reqtools found)
* 450	4	Pointer to shared window port for IDCMP messages

* 454 4 Pointer to snap buffer (120 bytes). You may use this buffer for other purposes. Note that this buffer will be corrupted when the user snaps something

1.14 The Wizard Corner : memory base (pvcall 41)

Offset	Size	Function
0	4	List with all automatic clear memory. You can add things to this list with 'pvcall 49'. This pointer is actually the pointer to the first element in the list, and the first element in the autoclear list is the LAST element that was added (this is the oldest entry). Each entry in this list contains a pointer to the next entry (at offset 0) and a pointer to a PV block (at offset 4).
4	4	Pointer to the last element in the autoclear list (previous list).
8	2	The number of entries in the autoclear list.
10	2	The maximum number of entries in the autoclear list. You change this number (default 10) but you must make sure that the list contains less entries than the number you supply as a maximum.
12	8	PV memory block containing the pointers to all allocated memory (with the 'alloc' function and the 'pvcall 55' command).
< 20	4	>
24	8	PV memory block for the current tag list. Format for one element in this PV memory block : <pre><Address>.L <Bytes>.L <Flags>.W <Type>.W <Extra>.L</pre> <pre><Address> is start of memory block <Bytes> is number of bytes for memory block <Type> is one of 1 = BYTEASCII BA 2 = WORDASCII WA 3 = LONGASCII LA 4 = ASCII AS 5 = CODE CO 6 = STRUCT ST</pre> <pre><Flags> has the following bits bit 0 = write protect bit 1 = read protect bit 2 = ignore global protection bit 3 = print bus error information bit 4 = freeze (not supported yet)</pre> <pre><Extra> is the pointer to the structure</pre>

definition if <Type> = 6.

32	4	Number of current default tag list (0..15)
36	16*8	16 PV memory blocks containing all tag lists.
< 164	4	>
168	4	Pointer to next memory to list (with 'memory', 'unasm' or 'view')
172	4	Pointer to address to continue the search with 'next'.
176	4	Remaining number of bytes to search.
180	4	Pointer to string to search (PV block).
< 184	1	>
< 185	1	>
186	8	PV memory block for the list containing all resident code fragments loaded with the 'resident' command
< 194	4	>
< 198	10	>
208	4	Last number of bytes used with 'memory' or 'view' (default 320)
212	4	Last number of lines used with 'unasm' (default 20)
216	4	Pointer to first region for PowerVisor internal memory management. A region (or PV memory header) looks like this (it looks a bit like an Exec memory header) :

Offs	Size	Function
0	4	Next
4	4	Prev
8	4	Pointer to first free block in this region
12	4	Number of bytes free in this region
16	4	Pointer to start of region
20	4	Total size of region
24	4	Attributes for this region (like MEMF_CHIP)
<28	4	>