

Slot Manager

Contents

Introduction to Slots and Cards	2-3
Slot Address Allocations	2-5
Firmware	2-7
The sResource	2-7
Type and Name Entries	2-9
The Board sResource and Functional sResources	2-11
The sResource Directory	2-12
The Format Block	2-13
About the Slot Manager	2-15
Using the Slot Manager	2-16
Enabling and Disabling NuBus Cards	2-17
Deleting and Restoring sResources	2-17
Enabling and Disabling sResources	2-18
Searching for sResources	2-19
Obtaining Information From sResources	2-20
Installing and Removing Slot Interrupt Handlers	2-22
Slot Manager Reference	2-22
Data Structures	2-22
Slot Manager Parameter Block	2-23
Slot Information Record	2-24
Format Header Record	2-26
Slot Parameter RAM Record	2-27
Slot Execution Parameter Block	2-27
Slot Interrupt Queue Element	2-28
Slot Manager Routines	2-29
Determining the Version of the Slot Manager	2-30
Finding sResources	2-31
Getting Information From sResources	2-40
Enabling, Disabling, Deleting, and Restoring sResources	2-51
Loading Drivers and Executing Code From sResources	2-58

Getting Information About Expansion Cards and Declaration ROMs	2-61
Accessing Expansion Card Parameter RAM	2-67
Managing the Slot Interrupt Queue	2-70
Low-Level Routines	2-72
Summary of the Slot Manager	2-87
Pascal Summary	2-87
Constants	2-87
Data Types	2-87
Slot Manager Routines	2-90
Low-Level Routines	2-91
C Summary	2-92
Constants	2-92
Data Types	2-92
Slot Manager Functions	2-94
Low-Level Functions	2-96
Assembly-Language Summary	2-97
Data Structures	2-97
Trap Macros	2-99
Result Codes	2-100