

# SCSI Manager 4.3

---

## Contents

About SCSI Manager 4.3	4-3
Transport	4-5
SCSI Interface Modules	4-6
System Performance	4-6
Compatibility	4-6
Using SCSI Manager 4.3	4-7
Locating SCSI Devices	4-8
Describing Data Buffers	4-9
Handshaking Instructions	4-9
Error Recovery Techniques	4-10
Optional Features	4-10
Writing a SCSI Device Driver	4-11
Loading and Initializing a Driver	4-11
Selecting a Startup Device	4-12
Transitions Between SCSI Environments	4-12
Handling Asynchronous Requests	4-13
Handling Immediate Requests	4-13
Virtual Memory Compatibility	4-14
Writing a SCSI Interface Module	4-15
SIM Initialization and Operation	4-15
Supporting the Original SCSI Manager	4-16
Handshaking of Blind Transfers	4-18
Supporting DMA	4-18
Loading Drivers	4-18
SCSI Manager 4.3 Reference	4-19
Data Structures	4-19
Simple Data Types	4-19
Device Identification Record	4-19
Command Descriptor Block Record	4-20
Scatter/Gather List Element	4-20

SCSI Manager Parameter Block Header	4-21
SCSI I/O Parameter Block	4-23
SCSI Bus Inquiry Parameter Block	4-28
SCSI Abort Command Parameter Block	4-33
SCSI Terminate I/O Parameter Block	4-33
SCSI Virtual ID Information Parameter Block	4-34
SCSI Load Driver Parameter Block	4-34
SCSI Driver Identification Parameter Block	4-35
SIM Initialization Record	4-36
SCSI Manager 4.3 Functions	4-37
Client Functions	4-37
SIM Support Functions	4-54
SIM Internal Functions	4-60
Summary of SCSI Manager 4.3	4-65
C Summary	4-65
Constants	4-65
Data Types	4-70
Functions	4-75
Pascal Summary	4-75
Constants	4-75
Data Types	4-79
Routines	4-85
Assembly-Language Summary	4-86
Data Structures	4-86
Trap Macros	4-89
Result Codes	4-90