

**RANIER 99**

*"99/4A Products to Rave About"*

**MODEL MX01**

**MACRO LOADER**

**INSTALLATION AND OPERATING MANUAL**

C O P Y R I G H T

COPYRIGHT 1989 by RAVE 99 Co. All rights reserved. No part of this publication may be reproduced without the written permission of RAVE 99 Co., 112 Rambling Road, Vernon CT 06066

(203) 871-7824

TI/Registered TM Texas Instruments Corp.  
MYARC/Registered TM MYARC, Inc.

=====
TABLE OF CONTENTS

Introduction . . . . . 1
Requirements . . . . . 1
MACRO LOADER . . . . . 2
Installing the "MACRO LOADER". . . . . 2
Load Programs onto the First RAMDISK . . . . . 2
Loading a Programs using the MACRO LOADER. . 2
Figure 1, RAVE\_OS Main menu screen . . . . . 3
"MACRO LOADER" WARNING . . . . . 4
>Loading" the SAMPLE MACROs . . . . . 4
XB Keyboard MACRO Manager. . . . . 5
Loading XB Keyboard MACRO Manager . . . . . 5
XB Keyboard MACRO Manager Menu. . . . . 5
Loading MACROs . . . . . 5
Erasing ALL MACROs . . . . . 5
Listing MACROs . . . . . 6
Modifying single MACROs . . . . . 6
List single MACRO . . . . . 6
Modify single MACRO . . . . . 6
Delete single MACRO . . . . . 6
Exiting Keyboard MACRO Manager. . . . . 6
MACRO FILE FORMAT. . . . . 7
MACRO Example. . . . . 8
Warranty . . . . .W1
Warranty Registration Form . . . . .W2

-----  
INTRODUCTION  
-----

The RAVE 99 MX01 Keyboard MACRO Loader program allows multiple key presses to be defined as a group or "MACRO". This MACRO is associated with a "single" keypress, which, when pressed, causes the keypresses defined in the group to be sent to the computer as if they were being typed one at a time.

Typical use for a MACRO would be to define the printer setup of your printer. The string "RS232.BA=4800.DA=8" could be defined as MACRO "Control-P". Whenever "Control-P" is pressed, the above string would be sent to the computer. It may now be clear as to the power of this system.

The Keyboard MACRO's are active on any E/A 5 type program "LOADED" using the MACRO LOADER. Programs of this type include TI-WRITER and Editor. Keyboard MACRO's are NOT available in BASIC or Extended BASIC.

Once a MACRO is loaded into memory, it is retained even when the power is turned Off because of the memory protection provided by the MX01 Memory Enhancement System. MACRO's may be SAVED and LOADED from disk so that custom MACRO's may be defined for different programs. The file MAC/SAMPLE contains a set of MACRO's for demonstration purposes.

Requirements  
-----

To use the MX01 Keyboard MACRO Loader you need:

- a) TI-99/4A console and TV or monitor.
- b) 99/4A Perpherial Expansion System (PEB).
- c) TI compatible Disk controller card.
- d) At least one floppy disk drive.
- e) The following Command Modules:
  - TI Extended BASIC
  - Editor/Assembler
- f) MX01 Memory Enhancement System
- g) MX01 RAMDISK SOFTWARE
- h) MX01 RAVE\_OS SOFTWARE

=====

"MACRO LOADER"

-----

The MACRO LOADER is the program which reads in the E/A type 5 files and modifies them so that the key presses are checked to see if they are MACRO's. Only programs loaded with the MACRO LOADER will have the use of MACRO's.

The MACRO LOADER must be installed before program loading will take place. This program is loaded into the backed-up memory and only needs to be loaded once.

Installing the "MACRO LOADER"

-----

The "MACRO LOADER" is normally installed as part of the "LOADING" sequence of the RAVE\_OS Software. No other steps are required. Should it become necessary to reload the this program, the steps below load only the "MACRO LOADER". This reloading operation erases all currently defined "MACRO's" in memory.

To install the MACRO LOADER, use the E/A Cartridge option #3. With the MACRO's disk located in Drive #1, enter "DSK1.MACRO" then enter. Press FUNCTION-9 twice to exit the E/A Cartridge. The MACRO LOADER is now installed.

Load Programs onto the First RAMDISK

-----

The MACRO LOADER always looks for programs to load from the first MX01 RAMDISK drive. All programs that wish to use the MACRO LOADER must therefore be copied onto the first RAMDISK drive. Refer to the MX01 RAMDISK Manual if the RAMDISK software is not currently installed.

\*LOADING A PROGRAM using the "MACRO LOADER"

-----

The Main menu screen of the RAVE\_OS program allows loading of E/A type 5 program with or without MACRO support. See figure 1.

Option 3 of the Main menu screen loads programs without searching for keyboard MACRO's. This loader is similar to option 5 of the E/A cartridge.

Option 4 of the Main menu screen loads programs using the MACRO LOADER". Programs loaded with this option are modified to search for "MACRO's" when key's are being pressed.


User program names in the RAVE\_OS main menu screen may use either loader when loading that program. An "M" near the program number selects the MACRO LOADER. A "SPACE" uses the standard loader. Pressing F7 with the program highlighted toggles loaders.

Programs may also be loaded using the "MACRO LOADER" from the Directory Command of the Main menu screen. Pressing "R" during a disk catalog loads the program highlighted in the directory. Refer to the RAVE\_OS manual for additional directory commands.

=====

FIGURE 1  
RAVE\_OS main menu screen

RAVE 99 Co. V1.3



- [1] Show Directory
- [2] Display File
- [3] Run Program, STD Loader
- [4] Run Program, MACRO Loader
- [5] Editor
- [6] DM1000
- [7] option 3
- [8] option 4
- [9] option 5
- [C] TI EXTENDED BASIC

=====

=====

"MACRO LOADER" WARNING

-----

The "MACRO LOADER" must modify the program loaded into memory to provide the necessary "HOOKS" required for the keyboard MACRO operation. Under most circumstances, this doesn't present a problem unless the program which was loaded has the ability to save it's memory image. If it does, it will save away the "HOOKS" that were made to the program when loaded. This will cause the program to crash if used in a system without a MX01 card and MACRO software. To avoid this, use the standard loader when "configuring" programs which save their memory image.

-----

"LOADING THE SAMPLE MACRO's"

-----

After the MACRO LOADER is installed, the next step in using MACRO's is to load them from file. MACRO's may be defined by the user to meet specific requirements and the format for the creation of MACRO's is discussed later in this manual. For now, lets load the sample MACRO's supplied on disk with the file name MAC/SAMPLE. The XB Keyboard Manager (MLOAD) is the program that performs this.

Select XB and type RUN "DSK1.MLOAD" . This RUNs Keyboard MACRO Manager.

Select "1: Load Macros" from the option screen.

Type DSK1.MAC/SAMPLE to select the sample MACRO file. Notice the screen while the MACRO's are loading into memory.

Select "5: Exit" to exit the Keyboard MACRO Manager.

At this point, the sample MACRO's have been loaded into memory. Go to the Main menu screen and "press" 5 to select TI-Writer. Press "E" to enter the edit mode. Press "CTRL-T. Notice that the string "TI-99/4A" is displayed. Press "ENTER". Press "CTRL-P". This time the printer setup for a serial printer is typed. Press "ENTER". Press "CTRL-H". RAVE's address and telephone number is typed. Now exit TI-Writer.

Select the directory from the main menu screen. Select the first RAMDISK drive # which contains the MAC/SAMPLE file. Using the arrow keys, highlight the MAC/SAMPLE filename. Press "CTRL-Q". Notice that this MACRO string EXITS the directory, "LOADs" the editor program, selects the LOAD FILE option, types in the filename HIGHLIGHTED in the directory program, and "PRESSES" enter to LOAD the file for editing. All of the above with 1 Keystroke.

The "filename" in the previous example was picked up as part of a MAILBOX operation. Whenever the directory is exited, the filename highlighted is moved to the MAILBOX. The MAILBOX is accessed from the KEYBOARD MACRO definition by the string [\$M]. Study the MAC/SAMPLE file to see how they are defined.

Now that you understand Keyboard MACRO's better, the next section describes the Keyboard MACRO Manager in greater detail.

## XB Keyboard MACRO Manager

The MLOAD file is the XB Keyboard Macro Manager. It allows the MACRO's to be Listed, Created, Modified, Deleted, Loaded and Saved to disk. It runs under TI Extended BASIC or MYARC XBII. In either case, to use the program you must first have the MACRO LOADER file loaded.

## Loading the XB Keyboard MACRO Manager

Select Extended Basic or MYARC XBII from the TI Title Screen. With the MACRO disk in drive 1, type RUN "DSK1.MLOAD" and enter. The program shall start and display the XB Keyboard MACRO Manager menu selections.

## XB Keyboard MACRO Manager Menu

The Macro Manager has a main menu with five options:

- 1: Load Macros
- 2: Erase All Macros
- 3: List Macros
- 4: Modify Single Macro
- 5: Exit

## LOADING MACROS

Option 1, Load Macros, will load a DIS/VAR 80 file from a device name which you are prompted for. This file is expected to be in the macro load format or all sorts of error messages will be generated and the load terminated. The Load Macro option loads macros into the current set of defined macros. If there is a macro in the file that is already defined in memory, the one in the file will over ride the one in memory. If you want to make sure there are no macros currently in memory use option 2 (Erase All Macros, explained below).

## ERASING ALL MACRO's

Option 2, Erase All Macros, will simply delete all macros currently stored in memory, to provide a clean slate to work from. It will prompt for erase verification before erasing the macros.

=====  
 LISTING MACRO's  
 -----

Option 3, List Macros, allows listing of all currently loaded macros. A filename for output is prompted for. To output to the screen simply press Enter. The program will list the macros to screen or the file in the Macro Format File so that they may be later reloaded. Note that a List Macro output file should not be edited in the TI-Writer Editor as it may contain control and function codes that could be lost during editing. If listing to the screen, output may be paused by holding down the space bar. At the end of a macro listing a count of the number of loaded macros is given for reference.

 MODIFYING SINGLE MACRO  
 -----

Option 4, Modify Single Macro, provides a method to list, modify, and delete an single macro. The command first prompts for the Keycode, which is of the same format as in the Macro Format File. It will then display the definition of that macro, if it is defined, or prompt for creation of a new macro if it does not exist. If you choose to create a new macro, you will procede to the Macro Editor, described below. If the macro exists, the definition is displayed at the bottom of the screen, and then a sub-menu:

 SINGLE MACRO SUB-MENU  
 -----

- 1: Modify Macro
- 2: Delete Macro
- 3: Return to Main Menu

Option 3 exits this command. Option 2 will delete the macro from the current list, after verification. Option 1 will take you to the Macro Editor with the current macro definition provided as a default.

 MACRO EDITOR  
 -----

The Macro Editor provides up to 8 screen lines to define the macro. The format is identical to the data lines in the Macro File Format. You may hold down up arrow to go to the previous line. To exit the Macro Editor, you must enter a line where the first character and only character is a period. You are then prompted to verify that this macro should be entered into the table. If you choose Yes, the macro will be written to the table and may then be used.

 EXITING Keyboard MACRO Manager  
 -----

Option 5 of the main menu EXITS the program. It is important to use this option to leave the program, as certain pointers may not be correctly updated if the program is exited by other means. Problems arising from such an exist may not manifest themselves immediately.

=====  
 MACRO FILE FORMAT  
 -----

The Macro File Format is as follows:

Keycode:  
 macro data  
 more macro data  
 .

The Keycode must be followed by a colon, and the colon must be the last character on the line. The Keycode represents the key that the following macro will define. The Keycode can be a single character, or it can be a bracketed expression. For example, the ASCII code of the character can be given in brackets. [42] would be the same as an asterisk. Function and Control keys may also be named in bracketed expressions. For example, [F9] would define Function 9, just as [CB] would define Control B.

On the lines following the key code are the actual data for the macro. This can be literal data, bracketed data, or a combination. For example, since the ASCII code for the letter B is 67 the following would define a macro of "ABC":

A[67]C

A Macro can be multiple lines line, although no bracketed expression may be split across a line boundry. The macro is terminated with a line containing only a period in the first space.

A Macro Format File may be created in TI-Writer. It should be saved with the PF (Print File) option rather than SaveFile, to avoid the saving of the final tab record, which may confuse the Macro Manager software.

Other notes:

There is no real limit on the size of a macro, but the largest macro that the program can reasonably handle is about 250 characters, which should not pose a problem in most cases. Once a satisfactory macro load has been created in memory, it is advisable to List it to disk and reload it after erasing all macros in memory. This will tend to compact the data. Since the List file output is not the best format to edit in, the original Macro Format Files (if any exist) should be maintained for future changes.

The Function and Control code translation using the bracketed expressions assume that the program is using keyboard mode 5. If this is not the case, some codes may not be valid. In such cases, refer to the Users Reference Guide for keyboard layouts and enter the ASCII codes directly.

Also note, since ASCII codes may be entered directly for Keycodes is it possible to assign macros to the "missing" keys provided on the Rave 99 Keyboards, which means that some macros may be added to programs without losing any of the existing normal key presses.

=====  
 MACRO Examples  
 -----

The following examples are present here to demonstrate the possible uses for keyboard MACROs. All of the examples are available for immediate use by loading the file MAC/SAMPLE from the MACRO disk. We have documented each line of MACRO's use in the following examples. These comments are not part of the actual MACRO definition.

Example 1. This MACRO defines the phrase "TI-99/4A" as CONTROL-T.

```
[CT]:          § Defines the KEYCODE as CONTROL-T.
TI-99/4A      § Defines the MACRO contents as TI-99/4A.
.             § defines the end of this MACRO.
```

Example 2. This MACRO defines the printer setup RS232.BA=4800.DA=8 as CONTROL-P.

```
[CP]:          § Defines the KEYCODE as CONTROL-P.
RS232.BA=4800.DA=8 § Defines the MACRO as RS232.BA=4800.DA=8
.             § defines the end of this MACRO.
```

Example 3. This MACRO is like example 2 but includes the control characters to leave the edit mode and to start the printer. This MACRO's keycode is FUNCTION-Q.

```
[FQ]:          § Defines the KEYCODE as FUNCTION-Q.
[F9]           § FUNCTION-9, Leaves the editor.
PF[13]        § "PF" for PRINT FILE. [13] is ENTER.
RS232.BA=4800.DA=8 § Defines the MACRO as RS232.BA=4800.DA=8
[13]          § [13] is enter and starts the printer.
.             § defines the end of this MACRO.
```

Example 4. This MACRO could be used to define the heading of a letter. The keycode is CONTROL-H.

```
[CH]:          § Defines the KEYCODE as CONTROL-H.
RAVE 99 Co.[13] § first line of MACRO and enter.
112 Rambling Road[13] § second line of MACRO and enter
Vernon CT 06066[13] § third line of MACRO and enter
(203) 871-7824[13] § fourth line of MACRO and enter.
.             § defines the end of this MACRO.
```

## =====

## THREE-MONTH LIMITED WARRANTY

This RAVE 99 MX01 KEYBOARD MACRO LOADER Warranty Extends To The Original Consumer Purchaser of the Accessory.

## WARRANTY DURATION

This MX01 KEYBOARD MACRO LOADER is Warranted for a period of three(3) months from the date of the original purchase by the consumer.

## WARRANTY COVERAGE

This MX01 KEYBOARD MACRO LOADER is Warranted against defective materials or workmanship. THIS WARRANTY IS VOID IF THE ACCESSORY HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIALS OR WORKMANSHIP.

## WARRANTY DISCLAIMERS

ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE THREE-MONTH PERIOD. RAVE 99 SHALL NOT BE LIABLE FOR LOSS OF USE OF THE SOFTWARE OR OTHER INCIDENTAL OR CONSEQUENTIAL COSTS, EXPENSES, OR DAMAGES INCURRED BY THE CONSUMER OR ANY OTHER USER.

Some states do not allow the exclusion or limitation of implied warranties or consequential damages, so the limitations or exclusions may not apply to you in these states.

## LEGAL REMEDIES

This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

## WARRANTY PERFORMANCE

During the above three month period, your MX01 KEYBOARD MACRO LOADER diskette will be replaced with a new diskette of the same or equivalent model(at RAVE 99's option) when the diskette is returned by prepaid shipment to RAVE 99 at the address below. Other than the postage requirement, no charge will made for replacement of in-warranty units.

## REPLACEMENT AFTER WARRANTY

After the 90 day Warranty has expired you may return any original defective diskette, along with a check for \$5.00 to cover the shipping and diskette cost, and we will replace it.

SHIP TO : RAVE 99 CO.  
112 RAMBLING ROAD  
VERNON, CT. 06066

WARRANTY REGISTRATION

THE INFORMATION BELOW SHOULD BE COMPLETED AND RETURNED TO RAVE 99 IN ORDER TO SPEED REPLACEMENT OF YOUR DISK IF IT EVER SHOULD NEED WARRANTY SERVICE.

PLEASE ALSO INDICATE IF YOU DESIRE TO HAVE YOUR NAME ADDED TO THE RAVE 99 MAIL LIST IN ORDER TO BE INFORMED OF NEW PRODUCTS AND SPECIAL OFFERS.

\*\*\*\* NOTE \*\*\*\*

IN THE EVENT YOUR IN-WARRANTY UNIT REQUIRES SERVICE, PROOF OF PURCHASE MAY BE REQUIRED. DATED SALES SLIP, RECEIPT, OR INVOICE IS SATISFACTORY PROOF OF PURCHASE.

NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY \_\_\_\_\_ STATE \_\_\_\_\_ ZIP \_\_\_\_\_

# AA

RAVE 99 PRODUCT \_\_\_\_\_ SERIAL NUMBER \_\_\_\_\_

DATE OF PURCHASE \_\_\_\_\_ PURCHASED FROM \_\_\_\_\_

TYPE OF SYSTEM PRODUCT WILL BE USED WITH (99/4A,9640, ETC.) \_\_\_\_\_

I DO \_\_\_\_\_ / DO NOT \_\_\_\_\_ WISH TO BE ADDED TO THE RAVE 99 MAIL LIST.  
(PLEASE CHECK ONE)

MAIL TO: RAVE 99  
112 RAMBLING RD  
VERNON, CT. 06066  
ATTN: WARRANTY