

COMPUTER MUSIC BOX

Random Music - no changes

Composer - no changes

Advanced Composer:

	<u>99/4 Keys</u>	<u>99/4A Keys</u>
Amps	A	FCTN 7
End	E	FCTN E
Key	K	/
Manual	M	;
Number	N	SHIFT ;
Octave	O	SHIFT =
Record	R	FCTN 8
Tempo	T	FCTN 3
Voice	V	FCTN 6
Where	W	FCTN 5
Beginning	B	FCTN I
Delete	D	FCTN D
End	E	FCTN E
Fast	F	FCTN 1
Goto	G	FCTN 2
Backstep	H	SHIFT ,
Insert	I	SHIFT /
Play	P	FCTN P
Extend	X	FCTN X
Single Step	Y	SHIFT .
Zero	Z	FCTN 9
Load	L	=
Save	S	FCTN S
Unsave	U	FCTN U
Jump Back to	J	SHIFT 6
BASIC		
Rest	SPACE BAR	SPACE BAR
Repeat Factors:	SHIFT 1	SHIFT 1
	SHIFT 2	SHIFT 2
	SHIFT 3	SHIFT 3
	SHIFT 4	SHIFT 4
	SHIFT 5	SHIFT 5
	SHIFT 6	FCTN 0
	SHIFT 7	SHIFT 7
	SHIFT 8	SHIFT 8
	SHIFT 9	SHIFT 9