

## DCA IRMAtrac Driver for Windows NT

The following is a list of options available for DCA IRMAtrac token-ring adapters.

### Options

#### **BURST size**

Chooses the burst size--2, 4, 6, 8, 10, 12, or DEFAULT. Change this option only if you receive an error while trying to read a diskette or tape in a floppy drive or tape drive. If an error is displayed, change the burst size to 10. If the error persists, reduce the burst size until the error stops.  
Default: DEFAULT.

#### **Receive list**

Chooses the number of receive buffers in the IRMAtrac driver's Receive Buffer Pool--2 to 32.  
Default: 16.

#### **Xmit list**

Chooses the number of internal queue entries for outstanding transmits--1 to 64. This option is required for the MAC to support more than one transmit simultaneously. Default: 64.

#### **IRQ level**

Chooses the interrupt level--2, 3, 4, 5, 6, 7, 10, or 11. Each adapter in your PC should have a unique interrupt level. Default: 3.

#### **I/O address**

Chooses the I/O address. In an ISA PC, your choice must match the switch settings on the IRMAtrac adapter. Default: 0A20.

#### **DMA channel**

Chooses the DMA channel--3, 5, 6, or 7. Each adapter in your PC requires a unique DMA channel.

#### **Network address**

Sets the locally administered address--400000000000 to 47FFFFFFFFFFFF. This 12-digit hexadecimal value overrides the universal address. Default: 000000000000 (universal address).

#### **Early release**

Sets the early release option for 16 Mbps LANs.

**ON** Enables the early release option.

**OFF** Disables the early release option.

**Ring speed**

Chooses IRMAtrac's operating speed. This option applies only if you have the 4/16 software-selectable RIM attached to IRMAtrac.

**4 Mbps** Sets IRMAtrac's operating speed to 4 Mbps.

**16 Mbps** Sets IRMAtrac's operating speed to 16 Mbps.

**Cable type**

Choose the type of token-ring cable to which the IRMAtrac adapter will connect. This option applies only if you have the 4/16 software-selectable RIM attached to IRMAtrac.

**UTP** Sets the adapter to connect to UTP cable.

**STP** Sets the adapter to connect to STP cable.

