

## **Network Peripherals FDDI AT Adapters (AT1, AT2, AT3)**

### **Interrupt Number**

It defines the interrupt request line that the adapter will use to interrupt the system.

Interrupts supported for AT1 and AT2 are *10* and *11*.

Interrupts supported for AT3 are *9*, *10*, *11* and *15*.

### **I/O Port Base Addr**

It defines the I/O port base address that the adapter will use. The selected value must match the actual switch settings in on the adapter.

I/O ports supported are *0x160*, *0x180*, *0x260*, *0x280*, *0x360*, *0x380*.



