

Mainboard: HOT-557 Ver. 1.32^{SPACE WALKER}

Single Voltage Output (Vio = Vcore)

set AMD K5 ABx-Type to 3.5V

Voltage Output	J101	J102	J100
3.2 V $\pm 5\%$			
3.3 V $\pm 5\%$			
3.45 V $\pm 5\%$			
3.5 V $\pm 5\%$			
3.6 V $\pm 5\%$			
3.8 V $\pm 5\%$			

(You can find the complete manual on the Spacewalker-CDROM)

- 1) CPU configuration according to the tables. The voltage instructions of the CPUs may be changed without prior notification by the manufacturer.
- 2) Memory-Configuration: the 72pin sockets can be filled with pairs of same Fast-Page-Mode- and/or EDO-modules in sizes of 4, 8, 16 and 32 MB (60 or 70 ns). The 168pin sockets can be equipped with one or two DIMM-modules in size of 8, 16 or 32 MB (FPM, EDO or SDRAM). Do not populate both 5V SIMM modules and 3,3V DIMM modules at the same time!

All brand and product names referred to in this sheet are registered trademarks of their respective holders.

Dual Voltage Output (Vio, Vcore separated)

Intel P55C (MMX) & Cyrix/IBM 6x86L: 3,3V / 2,8V

Vio Output	J101	J102	Vcore Output	J100
3.2 V $\pm 5\%$			2.5 V $\pm 5\%$	
3.3 V $\pm 5\%$			2.7 V $\pm 5\%$	
3.45 V $\pm 5\%$			2.8 V $\pm 5\%$	
3.5 V $\pm 5\%$			2.9 V $\pm 5\%$	
3.6 V $\pm 5\%$			3.0 V $\pm 5\%$	
3.8 V $\pm 5\%$			3.2 V $\pm 5\%$	

