

Network Peripherals FDDI AT Adapters (AT1, AT2, AT3)

Interrupt Number

It defines the interrupt request line that the adapter will use to interrupt the system.

Interrupts supported for AT1 and AT2 are *10* and *11*.

Interrupts supported for AT3 are *9*, *10*, *11* and *15*.

I/O Port Base Addr

It defines the I/O port base address that the adapter will use. The selected value must match the actual switch settings in on the adapter.

I/O ports supported are *0x160*, *0x180*, *0x260*, *0x280*, *0x360*, *0x380*.

