

# Compex ReadyLINK ENET16 PnP Ethernet Adapters

## Cable Type

It defines the type of cable the adapter will use to connect to the network.

<i>Current Setting</i>	The driver will use the cable connection type stored in the configuration register.
<i>TPI</i>	The driver will set the configuration register to use twisted pair.
<i>BNC</i>	The driver will set the configuration register to use coax.
<i>AUI</i>	The driver will set the configuration register to use thicknet.
<i>Auto-Detect</i>	The driver will try to detect the cable type.

## IRQ

It defines the interrupt request line that the adapter will use to interrupt the system.

<i>Current Setting</i>	The driver will use the interrupt value stored in the configuration register.
<i>2,3,4,5,7,10,11,15</i>	The driver will set the interrupt to the assigned value.

## Memory Address

It defines the memory base address of the shared memory that will be mapped to the system memory space.

<i>Current Setting</i>	The driver will use the memory address stored in the configuration register.
------------------------	--

## Adapter Number

It defines the which adapter the driver will take over the control if there is more than one similar adapter in the system. Valid values are 1,2,3,4,5,6,7,8.



