

3Com TokenLink III ISA Token Ring Adapter (3C619B)

This adapter must be configured either by using the EISA configuration utility or the 3TOKDIAG utility on the *TokenDisk* diskette prior to this driver installation. Please refer to Chapter3 of the TokenLink III 16-Bit ISA Adapter Guide (3C619B) for configuration information.

Use this dialog box to configure settings for the 3Com TokenLink III ISA Token Ring adapter on ISA bus machines.

Network Address

To use a network address other than the one burned into the adapter card, enter the network address in hexadecimal form, in the following format:

XX-XX-XX-XX-XX-XX

For instance, 01-02-03-4E-2D-1F

If you leave the network address blank, the network address burned into the adapter card is used. If you do not know the network address, ask your network administrator.

