

You use this dialog box to choose settings for pictures that are scanned from within a TWAIN application. You can choose to scan color or black and white photos, or black and white line drawings. By clicking Advanced, you can display the Resolution and Brightness dialog box, where you can set scanning resolution and image brightness, and calibrate your scanner.

Click a button to select the type of document you are scanning.

Click this button to begin scanning a page. After you click this button, you will be prompted to insert a page in the scanner.

Click this button to close the dialog box without performing any action.

Click this button to display the Resolution and Brightness dialog box, where you can specify additional settings for your scanned image.

Click this button to display on-line help information.

Remove the check mark in this box if you do not want PageScan USB to automatically sense the edge of the document you are scanning.

Click this box to turn on the AutoDeskew option, which automatically straightens crooked scans.

Displays information or instructions about the currently selected field in the dialog box.

This dialog box lets you specify scanning resolution, image brightness (for Black Line Drawing only), and scanner calibration. You use it when scanning images from within a TWAIN application.

Click this button to calibrate the scanner. You may need to recalibrate the scanner if you see any streaks or other quality problems with your scanned images.

Click this button to return to the default settings for resolution and brightness.

Drag this slider to set the scanner resolution.

Drag this slider to set the brightness level. This option is only available if Black Line Drawing is the document type.

Click this button to save the information and close the dialog box.



