

[Click here to open the game controller programming software.](#)

Indicates version and copyright information.

Indicates the number of game controllers connected to the game pad.

Pressing the mode button will disconnect your game pad. Press the mode button again to reconnect.

Indicates which profile is active for this controller.

Click to open the Force Feedback Troubleshooter.

Use the slider to adjust the return-to-center spring strength.

Use the slider to adjust the force-feedback level of the controller.



Indicates whether the joystick is operating in digital or analog mode.

Press this button to turn force feedback on and off. When the button is lit, forces are on.

