

If you have a (or compatible)...	Select this in the setup in the Chooser:
Panasonic KX-P1080, KX-P1091, KX-P1092, KX-P1180, KX-P1191, KX-P1592	Panasonic 9-pin
Panasonic KX-P1123, KX-P1124, KX-P2130, KX-P2135	Panasonic 24-pin
Citizen 120, 120D, 180D, 5200, 5800 Epson FX-85, FX-105, FX-185, FX-286, FX-86e, FX-286e, FX-800, FX-1000, FX-850, FX-1050, EX-800, EX-1000, DFX-5000, T-750, AP-2500	Epson FX
Epson LQ-200, LQ-400, LQ-500, LQ-800, LQ-1500, L-750, L-1000, AP-3000	Epson LQ
Epson LQ-510/550/850, LQ-860/950/1010/1050/2500/2550, SQ-850/1050/2550, AP-4000/4500	Epson LQ enhanced
Epson EPI-4000, EPL-6000, EPL-7000, EPL-7100, ActionLaser printers in L-Jet2P emulation mode Panasonic KX-P4400, KX-P5400, KX-SP100	LaserJet
IBM Color Printer	IBM Color Printer
IBM Color Jetprinter	IBM Color Jetprinter