

# NEXTSTEP for Intel Processors

**Title:** Bus Logic BT-542 SCSI Controller

**Entry Number:** 1362

**Last Updated:** <<Date November 15, 1995>>

**Product Vendor:**

Bus Logic, Inc.

4151 Burton Drive

Santa Clara, CA 95054

USA

+1 (408) 492 9090 phone

+1 (408) 492 1984 bulletin board system

WWW: <http://www.buslogic.com/>

**Keywords:** Bus Logic, 542, 545, SCSI, ISA

## **Usage Commentary:**

The Bus Logic BT-54x line of SCSI controllers provides a bus-mastering ISA SCSI interface for NEXTSTEP for Intel Processors.

### **Release 3.3**

See NeXTanswers document 1771\_BusLogic\_family\_Driver\_Overview.rtf

### **Release 3.2**

The BT-545C requires the Bus Logic SCSI driver, now available from NeXTanswers via anonymous FTP (<ftp.next.com>) or email ([nextanswers@next.com](mailto:nextanswers@next.com)). Request NeXTanswers documents 1685\_BusLogicSCSIDriver.pkg.compressed and 1686\_BusLogicSCSIDriver.ReadMe.rtf.

While other models in the BT-54x line have been used successfully with the Bus Logic SCSI driver by our customers, the driver was written specifically for the BT-545C, and this is the only model tested by NeXT. If your card is a different model and does not work with the Bus Logic SCSI driver, use the Adaptec 154x SCSI driver instead. This driver is available in two versions: the original version on the NEXTSTEP Release 3.2 CD, and Update 1, available on NeXTanswers as documents 1521\_Adaptec154xDriver.pkg.compressed and 1520\_Adaptec154xDriver.ReadMe.rtf. The update provides enhanced functionality and bug fixes. If you are using either version of the Adaptec driver, see the note about firmware restrictions under "Known Problems" below. If you are installing a system with the update, request document 1541\_Installation\_Requiring\_Adaptec\_Driver\_Update.rtf as well.

### **Release 3.1**

The only driver which supports the BT-54x line under NEXTSTEP Release 3.1 is the Adaptec 154x driver which ships on the NEXTSTEP CD. See the note about firmware restrictions under "Known Problems" below.

## **Setup and Installation:**

If you plan to use the BT-54x with a pre-installed system, first obtain the Bus Logic SCSI

driver, then install and configure the driver according to the instructions in its ReadMe file. You can use the default driver settings.

If you are installing a system with the BT-54x, you will need to use the Bus Logic SCSI driver as a loadable boot driver. This requires a NEXTSTEP-formatted floppy with the plain driver, BusLogicSCSIDriver.config, in the /usr/Devices folder. You can create such a floppy yourself if you have access to a working NEXTSTEP system, or obtain one from NeXT Technical Support.

## **Known Problems:**

### **Releases 3.1 and 3.2:**

- While the integrated floppy controller on the BT-54x may work, it is not officially supported under NEXTSTEP Releases 3.1 and 3.2.
- Improper SCSI termination can cause strange, unreproducible errors. For maximum reliability be certain that the first and last devices on the SCSI bus are terminated. For more information on this topic see NeXTanswers document 1109\_SCSI\_Setup.
- If you are using the Adaptec 154x SCSI driver because you are using NEXTSTEP

Release 3.1 or because the Bus Logic SCSI driver does not support your card, you will need to change your Bus Logic BIOS and firmware to the following versions:

BIOS: 4.50

firmware: 3.31

Bus Logic technical support will assist you with this.

**See also:**

1109\_SCSI\_Setup

1118\_Bus\_Logic\_BT-747\_SCSI\_Adapter.rtf

1520\_Adaptec154xDriver.ReadMe.rtf

1521\_Adaptec154xDriver.pkg.compressed

1541\_Installation\_Requiring\_Adaptec\_Driver\_Update.rtf

1547\_Bus\_Logic\_BT-445\_SCSI\_Adapter.rtf

1685\_BusLogicSCSIDriver.pkg.compressed

1686\_BusLogicSCSIDriver.ReadMe.rtf