

Installing Version 3.35 of the EnsoniqSoundscape Audio/MIDI Device Driver for NEXTSTEP Release 3.2 and OPENSTEP Release 4.x for Mach Intel Processors

These instructions show you how to install the EnsoniqSoundscape device driver on an Intel-based computer running NEXTSTEP(TM) Release 3.2 or later, including OPENSTEP(TM) Release 4.x. The driver is distributed in an Installer package file named **EnsoniqSoundscape.pkg**.

Availability Information

All versions of this driver are available only from Sound Consulting directly. This driver is not produced, distributed or supported by Apple Computer.

Supported Audio Adapters

Gateway Soundscape VIVO
ENSONIQ SoundscapeVIVO 90 Plug-and-Play

Supported Audio/MIDI Adapters

ENSONIQ Soundscape
ENSONIQ Soundscape Elite
Gateway Soundscape 2, 2000, SS2000
Gateway Soundscape (OPUS based)
Gateway Soundscape Plug-and-Play (Revision 0, Revision 1, et al)
Gateway SoundscapeOFFICE Plug-and-Play
NEC Harmony Plug-and-Play
Spea Media FX 16
Reveal SC-600

Supported MIDI Interfaces

The driver will function will all MIDI interfaces which are supported by ENSONIQ or the manufacturer of the Soundscape compatible card. At this time, ENSONIQ supports the standard SoundBlaster MIDI interface which plugs into the joystick port of the sound cards. Other third-party MIDI interfaces which are designed to attach to a PC joystick port should also work, e.g. the "midiman" has been verified as compatible with the EnsoniqSoundscape.

Installing the Device Driver

1. Remove all other sound card drivers using Configure.app - there is currently only support for one active Audio Driver at a time under NEXTSTEP.
2. Shutdown your computer and remove all other sound card adaptors, then insert the Soundscape card, noting any jumper settings before you power up the computer.
3. Install the EnsoniqSoundscape Driver according to the instructions in **NeXTanswer 1824** *Installing Drivers Overview* - The EnsoniqSoundscape Driver provides a Help topic for Configure.app with additional hardware information.

For information about logging in and out, the Workspace Manager application, and the Installer application, see the *NEXTSTEP User's Guide*. For information about the Configure application, see *Installing and Configuring NEXTSTEP Release 3.2 for Intel Processors*.