

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

Chapter 1 Overview of TCP/IP Network Information

Part I

Setting Up Special PC/TCP Installations

Chapter 2 PC/TCP Installation Options

Chapter 3 Installing PC/TCP with Windows for Workgroups

Chapter 4 Installing PC/TCP with Novell NetWare

Chapter 5 Installing PC/TCP with LAN Manager

Chapter 6 Installing PC/TCP with Banyan VINES

Chapter 7 Installing PC/TCP with PATHWORKS

Chapter 8 Configuring NetBIOS

## Part II

### Managing Local PC/TCP Tasks

Chapter 9 [Configuring PC/TCP Remotely Using DHCP or Bootp](#)

Chapter 10 [Using PC/TCP with Memory Managers](#)

Chapter 11 [Managing the InterDrive Client](#)

Chapter 12 [Configuring Kerberos Security](#)

Chapter 13 [Configuring and Tuning the Kernel](#)

## Part III

### Setting Up PC/TCP Windows Servers

Chapter 14 [Managing PC/TCP Servers with Server Control](#)

Chapter 15 [Configuring a PC as a Windows SNMP MIB-II Agent](#)

Chapter 16 [Configuring a PC as a Windows Print Server](#)

## Part IV

### Setting Up PC/TCP DOS Servers

Chapter 17    [Configuring a PC as a DOS LPD Server](#)

Chapter 18    [Configuring Your PC as a DOS SNMP Agent](#)

## Part V

### Troubleshooting PC/TCP

Chapter 19    [Troubleshooting Host Connections](#)

Chapter 20    [Troubleshooting Name Resolution](#)

Chapter 21    [Troubleshooting the Network Interface Card](#)

Chapter 22    [Troubleshooting the Kernel and Driver Configuration](#)

Chapter 23    [Troubleshooting Windows Integration](#)

## Part VI

## Appendices

Appendix A [PC/TCP Configuration Parameters Reference](#)

Appendix B [Writing Scripts with SLANG](#)

Appendix C [The Standard MIB for SNMP Agents](#)

Appendix D [Downloading Programmable VT Function Keys](#)

# Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Chapter 1 Overview of TCP/IP Network Information

### 1.1 Before You Start Managing Network Information

### 1.2 The TCP/IP Protocol Family

### 1.3 The ISO/OSI Model

### 1.4 Identifying Hosts on the Network

#### 1.4.1 Obtaining a Network Number and Domain Name

#### 1.4.2 Preparing a Network Addressing Scheme

#### 1.4.3 Creating Subnets on the Network

#### 1.4.4 Specifying the Subnet Mask

#### 1.4.5 Specifying the Network Broadcast Address

#### 1.4.6 Preparing a Host Naming Scheme

1.4.7 Creating a Local Host Table

1.4.8 Using a Domain Name Service

1.5 Files for Managing Network Information

1.6 Related Information About Managing Network Information

# Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Chapter 2 PC/TCP Installation Options

### 2.1 Before You Choose an Installation Option

### 2.2 Customizing the Installation Program for Your Site

#### 2.2.1 Specifying Default Installation Information

#### 2.2.2 Defining Installation Program Dialog Boxes

#### 2.2.3 Specifying PC/TCP Components and Copied Files

#### 2.2.4 Configuring Program Manager Groups and Icons

#### 2.2.5 Specifying Multiple SETUP.INF Files for Multiple User Groups

#### 2.2.6 Configuring a Batch Install

### 2.3 Specifying a Central Configuration Method

### 2.4 Setting Up a Network Installation

## 2.5 Manually Copying PC/TCP Files

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 3 Installing PC/TCP with Windows for Workgroups

#### 3.1 Before You Install PC/TCP with Windows for Workgroups

#### 3.2 Configuring PC/TCP and Windows for Workgroups to Run over an NDIS Driver

#### 3.3 Configuring PC/TCP and Windows for Workgroups to Run over an ODI Driver

#### 3.4 Using PC/TCP Network Drivers with Other Network Operating Systems

#### 3.5 Configuring Windows for Workgroups to Use PC/TCP NetBIOS

##### 3.5.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

##### 3.5.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

#### 3.6 Loading PC/TCP NetBIOS and InterDrive

#### 3.7 Related Information About Installing PC/TCP with Windows for Workgroups

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 4 Installing PC/TCP with Novell NetWare

#### 4.1 Before You Install PC/TCP with Novell NetWare

#### 4.2 Configuring NetWare and PC/TCP over ODI Drivers

##### 4.2.1 Before You install PC/TCP over ODI Drivers

##### 4.2.2 Configuring NetWare and PC/TCP to Run over ODI Drivers — Procedure

#### 4.3 Configuring NetWare and PC/TCP over Token Ring and ASI Drivers

#### 4.4 Configuring NetWare/IP over PC/TCP

##### 4.4.1 Before You Configure PC/TCP LWPE to Work over NetWare/IP

##### 4.4.2 Configuring PC/TCP LWPE to Work over NetWare/IP — Procedure

#### 4.5 Configuring NetWare and PC/TCP over Ethernet and a Packet Driver

#### 4.6 Configuring PC/TCP and NetWare over NDIS Drivers

## 4.7 Modifying the Ethernet Frame Type on the NetWare Server

### 4.7.1 Modifying the Frame Type on a NetWare Client

### 4.7.2 Modifying the Frame Type through a NetWare 386 Server

## 4.8 Using PC/TCP Network Drivers with Other Network Operating Systems

## 4.9 Loading InterDrive

### 4.10 Related Information About Installing PC/TCP with NetWare

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 5 Installing PC/TCP with LAN Manager

#### 5.1 Before Configuring PC/TCP with LAN Manager

#### 5.2 Configuring PC/TCP with LAN Manager over an NDIS Driver

##### 5.2.1 Using PC/TCP Network Drivers with Other Network Operating Systems

#### 5.3 Configuring PC/TCP and LAN Manager to Use PC/TCP NetBIOS

##### 5.3.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

##### 5.3.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

#### 5.4 Loading InterDrive

#### 5.5 Related Information About Installing PC/TCP with LAN Manager

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 6 Installing PC/TCP with Banyan VINES

#### 6.1 Before You Install PC/TCP with Banyan VINES

#### 6.2 Installing PC/TCP with Banyan Ethernet

#### 6.3 Tunneling TCP/IP Packets within VINES Transport

#### 6.4 Using an NDIS Ethernet Driver with PC/TCP

#### 6.5 Using VINES with the PC/TCP Token Ring Kernel

#### 6.6 Loading InterDrive

#### 6.7 Using PC/TCP Network Drivers with Other Network Operating Systems

#### 6.8 Related Information About Installing PC/TCP with VINES

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 7 Installing PC/TCP with PATHWORKS

#### 7.1 Before Installing the PC/TCP DEPCA Kernel

#### 7.2 Installing PC/TCP to Run with PATHWORKS — Procedure Overview

#### 7.3 Loading the Scheduler for the DLL Driver

#### 7.4 Loading the DLL Driver

#### 7.5 Installing and Configuring PC/TCP to Use with PATHWORKS

#### 7.6 Loading InterDrive

#### 7.7 Using PC/TCP Network Drivers with Other Network Operating Systems

#### 7.8 Troubleshooting the PC/TCP DEPCA Kernel Installation

#### 7.9 Related Information About Installing PC/TCP with PATHWORKS

# Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Chapter 8 Configuring NetBIOS

### 8.1 Before You Start Using PC/TCP NetBIOS

### 8.2 Using NetBIOS in Windows

### 8.3 Configuring NetBIOS

### 8.4 Starting NetBIOS

#### 8.4.1 Starting the NetBIOS VxD

#### 8.4.2 Loading and Unloading the NetBIOS TSR

### 8.5 Setting PC/TCP NetBIOS Configuration Options

#### 8.5.1 Using Multiple NetBIOS Drivers

#### 8.5.2 Partitioning Your Network with Scope

#### 8.5.3 Communicating Across Routers

8.5.4 Creating and Using a Broadcast File

8.5.5 Creating and Using a Name File

8.5.6 Using Domain Scope

8.6 Tuning PC/TCP for NetBIOS

8.7 Programming with PC/TCP NetBIOS

8.7.1 NetBIOS Software Features and Limitations

8.8 Troubleshooting NetBIOS

8.9 Related Information About Configuring NetBIOS

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 9 Configuring PC/TCP Remotely Using DHCP or Bootp

#### 9.1 Before You Start Using DHCP and Bootp

#### 9.2 Understanding a Bootp and DHCP Client

#### 9.3 Configuring a DHCP Client in Windows

##### 9.3.1 Starting the DHCP Client in Windows

##### 9.3.2 Monitoring DHCP Client Status in Windows

#### 9.4 Configuring a DHCP Client in DOS

##### 9.4.1 DHCP Command Interface for DOS Clients

#### 9.5 Configuring a Bootp Client

#### 9.6 Troubleshooting DHCP Clients

#### 9.7 Related Information About the DHCP or Bootp Clients

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 10 Using PC/TCP with Memory Managers

#### 10.1 Before You Use PC/TCP with a Memory Manager

#### 10.2 Understanding Basic PC Memory Management Concepts

#### 10.3 Excluding Your Network Interface Card Buffer Space

#### 10.4 Conserving Conventional Memory

##### 10.4.1 Loading PC/TCP Kernels and TSRs into Upper Memory (UMB)

##### 10.4.2 Loading PC/TCP Kernels and TSRs into Expanded Memory (EMS)

#### 10.5 Using Memory Managers with Microsoft Windows

#### 10.6 Using the Memory Managers for DOS

#### 10.7 Using QEMM-386

##### 10.7.1 Using QEMM-386 with Windows

## 10.8 Using 386MAX

### 10.8.1 Using 386MAX with Windows

## 10.9 Related Information About Using Memory Managers

# Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Chapter 11 Managing the InterDrive Client

### 11.1 Before You Start to Manage InterDrive

### 11.2 Choosing the InterDrive TSR or VxD

### 11.3 Starting and Stopping InterDrive

### 11.4 Creating a Universal Configuration File

### 11.5 Using a Centralized Authentication Server

### 11.6 Managing InterDrive's Use of Memory

#### 11.6.1 Understanding How the VxD Uses Memory

#### 11.6.2 Adjusting How the TSR Uses Memory

### 11.7 Tuning InterDrive Network Performance

#### 11.7.1 Adjusting Packet Read and Write Size

11.7.2 [Tuning Stream Values](#)

11.7.3 [Improving Application Performance with Read-write Caching](#)

11.7.4 [Using TCP Connections](#)

11.8 [Troubleshooting InterDrive](#)

11.8.1 [Using the idprint Command to Identify Printing Problems](#)

11.9 [Related Information About Managing InterDrive](#)

# Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Chapter 12 Configuring Kerberos Security

### 12.1 Before You Start Using Kerberos Security

#### 12.1.1 Understanding Kerberos Terminology

### 12.2 Configuring Kerberos Security — Procedure Overview

#### 12.2.1 Editing the PC/TCP Configuration File

#### 12.2.2 Creating a Directory for Kerberos Files

#### 12.2.3 Creating the KRB.CON File

#### 12.2.4 Creating the krb.rea File

### 12.3 Obtaining Kerberos Credentials

#### 12.3.1 Understanding the Ticketing Process

#### 12.3.2 Obtaining and Listing Kerberos Tickets

12.3.3 [Changing Your Kerberos Password](#)

12.4 [Using Commands That Support Kerberos Security](#)

12.5 [Destroying Kerberos Credentials](#)

12.6 [Troubleshooting Kerberos Security](#)

12.7 [Related Information About Kerberos Security](#)

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 13 Configuring and Tuning the Kernel

#### 13.1 Before You Start Tuning and Configuring the PC/TCP Kernel

#### 13.2 Overview of Configuring the Kernel

##### 13.2.1 Configuring PC/TCP VxDs

##### 13.2.2 Configuring PC/TCP TSRs

#### 13.3 Tuning PC/TCP Performance

##### 13.3.1 Adjusting the TCP Window Size

##### 13.3.2 Adjusting the Number of Packet Buffers

##### 13.3.3 Adjusting the Number of TCP and UDP Connections

#### 13.4 Conserving Conventional Memory Usage

#### 13.5 Configuring IP Security

## 13.6 Related Information About Configuring and Tuning the Kernel

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 14 Managing PC/TCP Servers with Server Control

#### 14.1 Before You Start Using Server Control

#### 14.2 Starting the Server Control Application

#### 14.3 Configuring a Server

#### 14.4 Starting a Server

#### 14.5 Using a Session in Server Control

#### 14.6 Getting Help

#### 14.7 Stopping a Server

#### 14.8 Troubleshooting Server Control

#### 14.9 Related Information About Server Control

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 15 Configuring a PC as a Windows SNMP MIB-II Agent

#### 15.1 Before You Configure Your PC as a Windows SNMP MIB-II Agent

#### 15.2 Configuring the Windows SNMP MIB-II Agent Configuration Files

#### 15.3 Starting the Windows SNMP MIB-II Agent

#### 15.4 Stopping the Windows SNMP MIB-II Agent

#### 15.5 Related Information About Configuring Windows SNMP MIB-II Agents

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 16 Configuring a PC as a Windows Print Server

#### 16.1 Before You Start Configuring a Windows Print Server

#### 16.2 Configuring Print Server — Procedure Overview

#### 16.3 Configuring the Server

#### 16.4 Configuring Printer Queues

##### 16.4.1 Specifying Printer Control Sequences

##### 16.4.2 Creating a New Printer Queue

##### 16.4.3 Changing a Printer Queue Configuration

##### 16.4.4 Sending Output to a File

#### 16.5 Restricting Access to the Print Server

#### 16.6 Managing Print Server

16.6.1 Monitoring Server Status

16.6.2 Monitoring Printer Queues

16.6.3 Deleting Print Jobs

16.7 Troubleshooting Print Server

16.8 Related Information About Configuring Print Server

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 17 Configuring a PC as a DOS LPD Server

#### 17.1 Before You Start Configuring Your System as an LPD Server

#### 17.2 Configuring the LPD Server — Procedure Overview

#### 17.3 Adding LPD Sections to the Configuration File

##### 17.3.1 Adding the LPD Control Section

##### 17.3.2 Adding the Printer Control Section

#### 17.4 Customizing the Printer Control Section

##### 17.4.1 Controlling Printer Output

##### 17.4.2 Using Printer Control (Escape) Sequences to Control Printer Output

##### 17.4.3 Using Files to Specify Printer Control Sequences

##### 17.4.4 Using Applications to Specify Printer Control Sequences

17.4.5 [Controlling PostScript Printer Output](#)

17.5 [Restricting Access to the LPD Server](#)

17.6 [Sample PC/TCP LPD Configuration Sections](#)

17.7 [Managing LPD Services from the LPD Server](#)

17.7.1 [Starting and Stopping the LPD Server](#)

17.7.2 [Suppressing All Header Pages on a Printer](#)

17.7.3 [Deleting a Print Job in the Spooler Queue](#)

17.7.4 [Deleting the Current Print Job](#)

17.7.5 [Deleting All Print Jobs in a Spooler Queue](#)

17.7.6 [Examining Statistics on the Server](#)

17.7.7 [Displaying Verbose Console Messages](#)

17.7.8 [Maximizing Server Performance](#)

17.8 Troubleshooting the LPD Server

17.9 Related Information About Configuring a PC as a DOS LPD Server

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 18 Configuring Your PC as a DOS SNMP Agent

#### 18.1 Before You Configure Your DOS SNMP Agent

#### 18.2 Configuring the DOS SNMP Agent

#### 18.3 Starting the DOS SNMP Agent

#### 18.4 Stopping the DOS SNMP Agent

#### 18.5 Related Information About Configuring DOS SNMP Agents

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 19 Troubleshooting Host Connections

#### 19.1 Before You Start Troubleshooting Host Connections

#### 19.2 Testing Your PC's Network Connection

#### 19.3 Verifying Host and Network Connections

##### 19.3.1 Diagnosing Network Congestion and Problems

#### 19.4 Confirming That Your PC Sends ARP Requests

##### 19.4.1 Troubleshooting ARP Reply Failure

#### 19.5 Testing Router Configuration

#### 19.6 Testing Router Service

##### 19.6.1 Using Output as Debugging Information

##### 19.6.2 Testing Access to IP Hosts Beyond the Router

19.7 Interpreting ping Messages

19.8 Testing Telnet Server Connections

19.8.1 Interpreting Telnet Server Failure

19.9 Testing FTP Server Connections

19.9.1 Testing File Transfer to a Remote FTP Server

19.9.2 Interpreting FTP Server Failure

19.10 Testing Remote Connections Using the finger Command

19.11 Related Information About the Host Connections

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 20 Troubleshooting Name Resolution

#### 20.1 Before You Start Troubleshooting Name Resolution

#### 20.2 Isolating Name Resolution Problems

##### 20.2.1 Testing Name Resolution

#### 20.3 Correcting a Faulty Configuration

##### 20.3.1 Verifying Your Host Table Definition

##### 20.3.2 Verifying DNS Server Definitions

##### 20.3.3 Defining Your Local Domain

#### 20.4 Getting Additional Help

#### 20.5 Related Information About Name Resolution

## Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 21 Troubleshooting the Network Interface Card

#### 21.1 Before You Start Troubleshooting the Network Interface Card

#### 21.2 Testing the Network Interface Card

#### 21.3 Testing Hardware Changes

#### 21.4 Testing Hardware Interrupt Conflicts

#### 21.5 Testing Upper Memory Conflict

#### 21.6 Related Information About the Network Interface Card

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 22 Troubleshooting the Kernel and Driver Configuration

#### 22.1 Before You Start Troubleshooting the Kernel Configuration

#### 22.2 Resolving Kernel Configuration Problems

#### 22.3 Resolving Configuration File Problems

#### 22.4 Troubleshooting the Local Network Configuration

#### 22.5 Testing Driver Configuration

##### 22.5.1 Testing the Loading of a PPP or SLIP Packet Driver

##### 22.5.2 Testing the Loading of an Apple LocalTalk Packet Driver

##### 22.5.3 Testing the Loading of NDIS Drivers

##### 22.5.4 Testing the Loading of ODI Drivers

##### 22.5.5 Testing the Loading of IBM Token-Ring ASI Drivers

## 22.6 Isolating Software Interrupt Conflicts

## 22.7 Related Information About Kernel Configuration

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Chapter 23 Troubleshooting Windows Integration

#### 23.1 Before You Start Troubleshooting Windows Integration

#### 23.2 Verifying Required Windows Files

#### 23.3 Resolving Memory Conflicts

#### 23.4 Matching the Kernel and Windows File Versions

#### 23.5 Resolving PC/TCP DOS Application Failure

#### 23.6 Setting Runtime Priorities

#### 23.7 Interpreting Windows Startup Messages

#### 23.8 Related Information About Windows Integration

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

### Appendix A PC/TCP Configuration Parameters Reference

#### A.1 PC/TCP Command Cross-reference

#### A.2 List of Configuration File Sections

#### A.3 Parameter Descriptions

[PCTCP ADDRESSES]

[PCTCP ANSI]

[PCTCP BOOTP]

[PCTCP COMSCRPT remote\_hostname]

[PCTCP CTLAPP]

[PCTCP FTP]

[PCTCP FTPSRV]

[PCTCP GENERAL]

[PCTCP HOST]

[PCTCP IDPRINT print\_session]

[PCTCP IDRIVE]

[PCTCP IDRIVE filesystem]

[PCTCP IDRIVE-RESTORE]

[PCTCP IDRIVE-SERVERS]

[PCTCP IDRIVE-USER]

[PCTCP IDRIVE-VXD]

[PCTCP interface n]

[PCTCP IP-SECURITY]

[PCTCP IP-SECURITY n]

[PCTCP KERBEROS]

[PCTCP KERNEL]

[PCTCP KERNEL-VXD]

[PCTCP LPD]

[PCTCP LPD lpd\_printer\_name]

[PCTCP LPR]

[PCTCP LPR print\_session]

[PCTCP LWPE]

[PCTCP NETBIOS]

[PCTCP NETBIOS-VXD]

[PCTCP NNTP]

[PCTCP PCMAIL]

[PCTCP PCTCPNET]

[PCTCP PING]

[PCTCP POP2]

[PCTCP POP3]

[PCTCP PRINT]

[PCTCP PRINT-PROGRAMS]

[PCTCP QUERY]

[PCTCP SCREEN]

[PCTCP SERIAL\_n]

[PCTCP SESSIONS]

[PCTCP SMTP]

[PCTCP TAR]

[PCTCP 3270]

[PCTCP TIME]

[PCTCP TN]

[PCTCP VMAIL]

[PCTCP VPCTCP]

[PCTCP VT]

[PCTCP VXDINIT]

[PCTCP WMSG]

[CONTINUATION-FILE drive:\path\filename]

# Managing PC/TCP

PC/TCPâ OnNetâ 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

## Appendix B Writing Scripts with SLANG

### B.1 Conventions Used

### B.2 Overview

### B.3 Basic Concepts

#### B.3.1 All is Text

#### B.3.2 SLANG Syntax

#### B.3.3 Functions

#### B.3.4 Macros

#### B.3.5 The Interpreter

### B.4 The Define Primitive

### B.5 Arguments Containing Functions

B.6 White Spaces in Arguments

B.7 Commands, Calls, and Terminology

B.8 The Value Primitive

B.9 Cascading Value Strings

B.10 Storage and Retrieval Primitives

B.11 I/O Functions

B.11.1 The I/O Primitives

B.12 Looping and Flow Control Functions

B.12.1 The Loop Primitives

B.13 Arithmetic Functions

B.13.1 The Arithmetic Primitives

B.14 Comparison Functions

B.14.1 The Comparison Primitives

B.15 Miscellaneous Functions

B.15.1 The Miscellaneous Primitives

B.16 Remote I/O Functions

B.16.1 The Remote I/O Primitives

B.17 Storing Scripts with the Define Primitive

B.17.1 Examples of Writing SLANG Scripts

B.18 Creating Loops in Scripts

B.18.1 Exiting the Loop Statement Before Completing the Specified Number of

Iterations

B.18.2 To Display the Loop Number

B.18.3 Using Loops as a Case or Switch Statement

B.18.4 The Need for Curly Braces in Loop Statements

B.18.5 Nesting Loops

B.18.6 Creating a Script

B.18.7 Stopping Dialer Script Mode

B.19 Debugging with Debug Mode

B.20 Troubleshooting SLANG Scripts

B.21 Related Information About SLANG

## Managing PC/TCP

PC/TCPâ OnNetä 1.1 and PC/TCPâ Network Software 3.0 (July 1994)

Appendix C The Standard MIB for SNMP Agents

## Managing PC/TCP

PC/TCP® OnNet® 1.1 and PC/TCP® Network Software 3.0 (July 1994)

Appendix D [Downloading Programmable VT Function Keys](#)

## Chapter 1

### Overview of TCP/IP Network Information

This chapter provides an overview of the TCP/IP network information typically managed by a system administrator. The users, PCs, client applications, and servers of your network depend on this information to operate. Before you can configure PCs on your network to run PC/TCP<sup>®</sup> for example, you must assign names and addresses to them that enable them to access the network and allow you to monitor their network activity more easily.

With this chapter, you can learn

- What you are expected to know before you start to manage network information.
- What protocols are included in the TCP/IP protocol family.
- How both TCP/IP and PC/TCP compare to the International Organization for

Standardization's Open Systems Interconnection (ISO/OSI) model.

- The conventions and syntax of host identification on a network.
- What UNIX network server files are commonly used by system administrators to manage network information.
- Where to find related information about managing network information.

Note: This chapter is not intended to replace other UNIX and TCP/IP system administration manuals that you may use as guides. Use this chapter to get started with basic TCP/IP network administration tasks.

## 1.1 Before You Start Managing Network Information

This chapter assumes that you have planned for or have prepared for use

- The hardware (computers, cables, connectors, and so on) of your network.
- The routers, bridges, gateways, and other network components for routing

information over your network, or between your network and other networks.

- Personal computers (PCs) for your users.
- Computers to provide network services (network servers).

In addition, this chapter assumes that you have read or are familiar with the information

contained in [Getting Started](#). If you are unfamiliar with the prerequisite tasks listed in

this section, refer to your UNIX or TCP/IP network administration guides for more

information.

## 1.2 The TCP/IP Protocol Family

Networking protocols control communications between connected computers. The

TCP/IP group of protocols allows networks and machines with different operating

systems and machine architectures to communicate, making it a widely used standard

on the Internet. Figure 1-1 shows the TCP/IP architecture, including applications,

transport protocols, and the Internet Protocol (IP).




Figure 1-1 TCP/IP Protocols

Communication protocols are often grouped into hierarchies called “stacks,” “suites,” or

“families.” When two network hosts communicate, their protocol stacks perform

specified functions on data received from the other machine. Each protocol in the stack

relies on the protocols beneath it to perform specific functions or services on data

received from the other host, before relaying the data up the stack to the next level.

The hierarchical levels of the stack are referred to as "layers." At each layer, at least

one protocol performs a service related to the specified function of that layer.

These layers include:

P Desc

ro riptio

to n

c

ol

A TCP/

p IP

pl progr

ic ams

at inclu

io de

n file

s transf

er,

termi

nal

emul

ation,

mail,

netw

ork

mana

geme

nt,

printi

ng,

and

other

servi

ces.

Appli

catio

ns

gene

rally

rely

on

either

the

Trans

missi

on

Contr

ol

Proto

col

(TCP

) or

the

User

Data

gram

Proto

col

(UDP

) to

trans

port

data

to

their

peers

on

other

netw

ork

hosts

T Trans

C missi

P on

Contr

ol

Proto

col

provi

des

conn

ectio

n-

orient

ed,

reliab

le,

sequ

ence

d

data

transf

er

betw

een

netw

ork

hosts

. TCP

guar

antee

s that

data

reach

es its

desti

natio

n,

and

retra

nsmit

s any

data

that

fails

to do

so.

U User

D Data

P gram

Proto

col

provi

des

“unre

liable

”

data

trans

port

betw

een

local

or

remo

te

hosts

.

Unlik

e

TCP,

UDP

does

not

track

and

retra

nsmit

data

that

does

not

reach

its

desti

natio

n.

I Inter

C net

M Contr

P ol

Mess

age

Proto

col

send

s

error

and

contr

ol

mess

ages

from

route

rs or

hosts

to the

mess

age

origin

ator.

ICMP

also

gene

rates

and

replie

s to

echo

requ

est

pack

ets

(such

as

those

used

by

the

ping

progr

am).

ICMP

uses

the

basic

supp

ort of

the

Inter

net

Proto

col

(IP),

and

is

also

an

integr

al

part

of IP.

IPInter

net

Proto

col

recei

ves

data

bits

from

the

uppe

r

layer

s,

asse

mble

s the

bits

into

an

“IP

datag

ram”

pack

et (if

not

addr

esse

d to

the

local

host),

and

choo

ses

the

best

route

to

send

the

pack

et to

its

desti

natio

n.

A Addr

R ess

P Reso

lution

Proto

col

deter

mine

s the

mapp

ings

betw

een

the

physi

cal

hard

ware

addr

ess,

such

as an

Ether

net

addr

ess,

and

the

IP

addr

ess.

Local

area

netw

ork

(LAN

) PCs

use

ARP

as a

meth

od

for

locati

ng

each

other

on

the

LAN.

### 1.3 The ISO/OSI Model

The ISO/OSI (Open Systems Interconnection) model was developed by the International Organization for Standardization in the late 1970s to define a “universal” framework for a standard means of communication between different types of computers. The model’s seven “layers” define functions that take place when two machines communicate.

The ISO/OSI layers are described in Table 1-1:

Table 1-1 The ISO/OSI Layers

L NPur

a apos

y me

e e

r

7 Alncl

pude

ps

li user

cprog

aram

tis,

osuc

nh as

elec

troni

c

mail

or

file

tran

sfer

prog

ram

s.

6 PRes

r pon

esible

sfor

eform

nattin

t g

aappl

ti icati

oon

ndata

so it

can

be

displ

aye

d or

print

ed

on

the

net

wor

k.

Con

verti

ng

encl

ypti

on

cod

e or

tran

slati

ng

char

acte

r

sets

are

exa

mpl

es

of

the

activ

ities

at

this

laye

r.

5 SProv

eides

scon

snect

i ion

oserv

nices,

suc

h as

esta

blish

ing

and

mai

ntai

ning

a

sess

ion.

Net

BIO

S is

a

Ses

sion

-

laye

r

prot

ocol

.

4 TProv

r ides

auser

n-to-

suser

pcom

omun

r icati

t on

and

can

perf

orm

erro

r

che

ckin

g.

This

laye

r is

con

cern

ed

with

tran

smis

sion

relia

bility

.

Prot

ocol

s

that

oper

ate

at

laye

rs 4

and

3

are

ofte

n

refer

red

to

as

“co

mm

unic

atio

n

prot

ocol

s.”

TCP

is

an

exa

mpl

e of

a

Tran

spor

t-

laye

r

prot

ocol

.

3 NRes

epon

t sible

wfor

omak

r ing

kcert

ain

that

pac

kets

of

infor

mati

on

get

from

the

sour

ce

to

the

dest

inati

on.

IP is

an

exa

mpl

e of

a

Net

wor

k-

laye

r

prot

ocol

.

2 DProv

aides

t host

a-to-

Lhost

i deliv

nery

kacro

ss a

LAN

.

The

Dat

a

Link

laye

r

ass

emb

les

data

into

fram

es

and

tran

smit

s

the

m. It

may

also

prov

ide

low-

level

erro

r

and

flow

cont

rol.

This

laye

r

actu

ally

con

sists

of

two

subl

ayer

s:

the

Med

ia

Acc

ess

Con

trol

(MA

C)

laye

r

and

the

Logi

cal

Link

Con

trol

(LL

C)

laye

r.

Prot

ocol

s

that

oper

ate

at

this

laye

r

inclu

de

Ethe

rnet,

IEE

E

802.

5,

toke

n

ring,

and

PPP

(Poi

nt-

to-

Poin

t

Prot

ocol

).

1 Plnvo

hlves

ythe

selec

i trica

cl

aproc

l ess

of

getti

ng

data

from

one

host

or

poin

t in

a

net

wor

k to

anot

her.

Exa

mpl

es

of

laye

r 1

devi

ces

inclu

de

the

tran

smis

sion

med

ium,

net

wor

k

inter

face

card

, or

tran

scei

ver.

Since its development, the ISO/OSI model has become a prevalent way of classifying

networking functions; it often provides a helpful frame of reference when looking at such protocol architectures as TCP/IP and PC/TCP.

Figure 1-2 shows how the TCP/IP and PC/TCP layers correspond to the ISO/OSI

model:

ISO/OSI Model	PC/TCP Layers		TCP/IP Layers
Application	PC/TCP Applications	WFW Chat	TCP/IP Applications
Presentation		WFW	
Session		NetBIOS	
Transport	PC/TCP Kernel		TCP and UDP
Network			IP
Data Link	MAC Driver		Physical protocols, like Ethernet or token ring
Physical	Network Interface Card		

WFW – Windows for Workgroups

Figure 1-2 TCP/IP, the ISO/OSI Model, and PC/TCP

TCP/IP applications correspond to the top three layers (Session, Presentation, and Application) of the ISO/OSI model. TCP and UDP correspond to the ISO/OSI Transport layer, and the Internet Protocol is similar to the ISO/OSI Network layer.

PC/TCP contains driver, kernel, and application components that span the Data Link

layer through the Application layer of the ISO/OSI model.

## 1.4 Identifying Hosts on the Network

Every system or host that you want to connect to your network must have a unique identification, so that data can be routed accurately to the host. On TCP/IP networks, all network hosts have an IP address and hostname. This section describes

- Obtaining a network number and domain name.
- Preparing a network addressing scheme.
- Creating subnets and specifying the subnet mask.
- Specifying the network broadcast address.
- Preparing a host naming scheme.
- Creating a local host table.
- Using a Domain Name System (DNS).

### 1.4.1 Obtaining a Network Number and Domain Name

The InterNIC is an organization in the United States that assigns network addresses to networks, allowing the networks to connect to the Internet. (There are world organizations that perform a similar function in other countries.) If a host is part of the Internet, its address must be unique on the entire Internet, so that any packets of data routed to the host can reach their proper destination.

Even when a network is not connected to the Internet, the administrators responsible for its addressing scheme usually comply with the Internet addressing conventions. If your network uses its own network addresses, you cannot connect your network to any network that is connected to the Internet, unless your network address is not already in use on the Internet. If, as is usually the case, your network address is not unique, you have to reconfigure every address on your network before connecting to the Internet. In

addition, your network will be unable to receive packets from the Internet unless your network number has been registered in the Internet routing database. For these reasons, many administrators obtain an official network number application form from the InterNIC, then submit the completed form to the InterNIC to obtain their network addresses.

When the network number application is approved, the InterNIC assigns a unique “network number” to your network. The network number ensures that your network can be uniquely identified, and that your network’s hosts can be identified as belonging to it.

If you apply to the InterNIC for a network number, you should also obtain a domain name application form from the InterNIC, and return the completed form to the InterNIC for approval. A “domain name” is a unique network name that is associated with your network. (For example, FTP Software, Inc.’s domain name is ftp.com.) If the InterNIC

approves your domain name application, the InterNIC assigns your network a unique domain that is associated with your network's number, and that no other network can use.

Once you obtain a network number and domain name, you can assign IP addresses within the range of your assigned network number, and subdomain names as needed by your network. Information about contacting the InterNIC to obtain application forms appears in the Master Index, Glossary, Bibliography.

## 1.4.2 Preparing a Network Addressing Scheme

Each host machine on your network must be assigned a unique IP address to provide its network identification, which the host uses when communicating with any other network host. The address represents the host's connection to a particular network. If you were to disconnect a machine from one network and move it to another network, you would have to give it a different IP address that accurately identifies its new location.

IP addresses are 32-bit numbers. By convention, IP addresses are represented by four sequential fields of decimal integers, separated by dots (.). The value of each field, referred to as an "octet," or "byte," can be from 0 to 255. Some examples of IP addresses are 128.127.50.55, 128.127.51.30, and 10.0.0.21.

Each IP address contains the identity of both the network that a host belongs to (the

network ID or number) and the host itself (the host ID or number). Hosts on the same network have the same network number. For example, the IP addresses 128.127.50.55 and 128.127.51.30 belong to hosts in the same network, because their addresses begin with the same network number (128.127). The host with the IP address 10.0.0.21 belongs to a different network.

### Class A Internet Addresses

The InterNIC has defined five IP address forms, known as “classes,” denoted by letters A through E. Each byte in an IP address signifies either a network or a host, depending on the address class to which the IP address belongs. The format for a Class A

address appears in Figure 1-3.




Figure 1-3 Class A Internet Address

In a Class A address, the first byte represents the network number, and the remaining three bytes specify the host number. The highest order bit in the first byte is set to 0; the next seven bits identify the network; and the remaining 24 bits (the second, third, and fourth bytes) identify local hosts. This format allows 128 (2<sup>7</sup>) Class A networks, and over 16 million hosts on each of those networks. The InterNIC reserves numbers in this class for extremely large networks. The MILNET and some large commercial and university networks have Class A addresses.

The network portion of a Class A address (first byte) may use numbers 1 through 126 (the InterNIC reserves numbers 0 and 127) and its first bit must be set to 0. An example of a Class A address is 11.254.254.253.

### Class B Internet Addresses

The format for a Class B address appears in Figure 1-4.



Figure 1-4 Class B Internet Address

In a Class B address, the first two bytes represent the network number, and the remaining two bytes specify the host number. The highest order bits in the first byte are set to 10; the next 14 bits specify the network address; and the remaining 16 bits (the third and fourth bytes) specify the host address. It is possible to have over 16,000 Class B networks (2<sup>14</sup>), and over 64,000 hosts on each of those networks.

Class B network numbers, in the range 128.1 through 191.254, are used for the first two bytes of a Class B address. An example of a Class B address is 128.127.50.101. In this example, the network number is 128.127, and the host's number is 50.101.

### Class C Internet Addresses

The format for a Class C address appears in Figure 1-5.



Figure 1-5 Class C Internet Address

In a Class C address, the first three bytes represent the network number, and the fourth byte represents the host number. The highest-order bits of the first byte are set to 110; the next 21 bits specify the network number; and the remaining 8 bits (fourth byte) specify the host number. This allows just over 2 million Class C network numbers (2<sup>21</sup>) and 254 hosts on each of those networks.

Class C network addresses have the numbers 192.0.1 through 223.255.254. An example of a Class C address is 192.32.5.35. In this example, the network's portion is 192.32.5, and the host's portion is 35. Small networks often use class C addresses.

#### Class D and Class E Internet Addresses

The format for a Class D address appears in Figure 1-6.




Figure 1-6 Class D Internet Address

The highest order bits of the first byte are set to 1110, and the remaining 28 bits specify the “multicast address.” IP multicasting is the transmission of one or more packets at approximately the same time to a “multicast group,” a set of one or more hosts identified by a special destination address (the multicast address). For more information on using IP multicast addresses, refer to RFC 1112 or your TCP/IP administration guide. The InterNIC does not assign Class D addresses.

Although the InterNIC has defined Class E addresses, with the highest-order bits set to 1111, no Class E addresses are in use. The InterNIC reserves these addresses for future use.

### Assigning Host Addresses

Once you obtain a network number from the InterNIC, you can assign unique 32-bit addresses within the number's range to the hosts in your network. For example, if the InterNIC assigns a Class B network number to your network, you assign an IP address to each of your network's hosts with the same network number (the same first two bytes), but the last two bytes of each IP address must be unique for each host.

Note that the range of each field in the IP address is between 0 and 254 (255 is a broadcast address). You can assign your IP addresses one at a time, or you can assign a block of addresses to an organization at your site, and let that group assign the individual addresses to its machines. However you plan to perform this task, make certain that you avoid duplication of addresses, and that you record the addresses correctly on your network's domain name servers.

### 1.4.3 Creating Subnets on the Network

You can use part of the host number to identify “subnets” within the larger network. For efficient operation, you can partition a large physical network into separate logical parts, or subnets, and connect them to the rest of the network with IP routers. (IP routers translate data link or media protocols to allow different network media to communicate.)

You create subnets on networks to serve various purposes, which include

- Connecting different physical networks. The networks become subnets of a larger internetwork connected by routers.
- Distinguishing between different network LANs.
- Isolating parts of the network. You may want to isolate an unstable part of the network from other parts, or you may want to restrict the traffic of one subnet from the

others, to keep data secure.

- Delegating network administration to different groups. One way to delegate administrative tasks is to assign administrators to various subnets.

To create addresses for a network that will contain subnets, decide on the number of subnets that you need and how many hosts you plan to attach to each subnet. These numbers indicate how many bits of an IP address you can use for the subnet and host numbers.

For example, in a class B address, the last 2 bytes, or 16 bits, represent host numbers.

Without subnets, it is possible to support over 64,000 unique addresses on one network (216). However, you can decide to use the first 8 bits of the host portion of the address for subnet numbers, and the remaining bits for host numbers. This format allows you to create 254 subnets with over 250 hosts on each subnet. In addition, you

do not have to use all 8 bits to represent the subnet number; you can use just a portion of the bits, as in a 2-bit or 4-bit subnet number.

Machines on the same subnet share the same network and subnet numbers of their addresses. In the following list of examples,

128.127.50.2

128.127.50.36

128.127.52.7

if the entire third byte of each address is used as the subnet number, all three hosts belong to the same network (128.127), but only the first two hosts belong to subnet 50; the third host belongs to subnet 52.

Note: Do not use subnet numbers with bits set to 0000 0000 (0) or 1111 1111 (255);

the former number was once used as a broadcast address, and the latter is now used

as a broadcast address. For more information about the network broadcast address,

refer to section 1.4.5, [Specifying the Network Broadcast Address](#).

#### 1.4.4 Specifying the Subnet Mask

In a network composed of subnets, each network host uses the same “subnet mask.” A

subnet mask simplifies the routing of packets of information in a network by

- Concealing the host number of an IP address (all bits representing the host number are turned off, which gives them the value 0).
- Revealing the network and subnet bytes (all bits representing the network and subnet numbers are turned on).

A sending host compares its own network and subnet numbers to the revealed portion

(the network and subnet numbers) of the destination's subnet mask. If by comparison

the two addresses differ, PC/TCP sends the packet to the appropriate IP router for

forwarding to another subnet. If the revealed sections for the two addresses are the

same, indicating that the destination is on the same subnet as the sending host,

PC/TCP sends the packet directly to its destination.

When defining a subnet mask, note that the subnet bits must be both contiguous and

adjacent to the network number in the address. Once you have defined the subnet

mask, make certain that all hosts in the network have it, and make certain that all users

specify the correct subnet mask in the network driver interface section of their

PCTCP.INI files. For example, to specify an 8-bit subnet mask for a Class B address, a

user would enter the following information into the [PCTCP ifcust 0] section:

```
[PCTCP ifcust 0]
```

```
subnet-mask=255.255.255.0
```

In this example, the 16-bit network number is turned on (255.255), the 8-bit subnet

mask is turned on (255) and the host number is turned off (0).

#### 1.4.5 Specifying the Network Broadcast Address

The “network broadcast address” is used to send a packet to every host on the network. In a network broadcast address, all bits in the byte(s) pertaining to the host number in the address are turned on (set to 255). For example, in the network 128.127, the broadcast address might be

128.127.255.255

The default broadcast address for PC/TCP is 255.255.255.255.

All hosts on the network should use the same network broadcast address. Make certain that, if you plan to use a broadcast address other than the default, your network users enter the broadcast address in the network interface section of their PCTCP.INI files.

For example,

```
[PCTCP ifcust 0]
```

broadcast-address=128.127.255.255

#### 1.4.6 Preparing a Host Naming Scheme

Hostnames are assigned to machines in the network because people can remember names more easily than IP addresses. Once you obtain a domain name from the InterNIC, you can assign hostnames within that domain. All hostnames must be unique within a domain.

You can also create “subdomains” within your network’s domain. A subdomain is a domain contained within another domain. For example, company domains often fall into the Internet domain “com,” while military domains are categorized in the domain “mil.”

Within the domain xyz.com, you may want to have subdomains named admin.xyz.com, sales.xyz.com, and shipping.xyz.com. Within the subdomain sales.xyz.com, you may create more subdomains, such as eastern.sales.xyz.com, southern.sales.xyz.com, france.sales.xyz.com, and asia.sales.xyz.com. All subdomains must be unique within a

domain, and all hostnames must be unique within a subdomain.

A “fully qualified” domain name begins with a hostname and ends with a domain name.

For example, in the name chocolate.sales.xyz.com, the host’s name is chocolate, the subdomain is sales, and the domain is xyz.com. Subdomains are optional additions to hostnames.

Note that subdomains are not associated with subnets. A subdomain may include information about hosts from different networks or subnets.

When choosing a host name, try to use a word that is easy to remember, easy to type, and will not have to be changed once it is assigned (unless you must change the name, such as when you give the machine to a different user). Refer to RFC 1178 for guidelines on choosing host names.

#### 1.4.7 Creating a Local Host Table

A “host table” is a file that lists hostnames and their corresponding IP addresses. When the kernel is configured to have a local host table (there is a local host table path specified in the [pctcp kernel] section of the PCTCP.INI file), PC/TCP uses the local table to resolve hostnames first, then requests hostname resolution from a DNS server on the network if the local host table cannot satisfy the request.

In the PC/TCP host table, each entry describes one host by listing its IP address, one or more hostnames, and possibly any “aliases” associated with that address. (An alias is a short form of a fully qualified hostname. Both name servers and local host tables permit their use.) In this example,

```
#This machine is located in the network laboratory.
```

```
128.127.50.1 chocolate.xyz.com choc
```

the item

#This machine... Is a comment (a line of text that you do not intend to be interpreted as anything else), if preceded by a number sign (#).

128.127.50.1 Is the IP address of the host.

chocolate.xyz.com Is the hostname associated with the listed IP address. The hostname must be fully qualified. Note that hostnames are case insensitive.

choc Is the additional name, or alias, associated with the host's IP address. The alias can change frequently as users add and remove informal names for their machines.

Separate items in a host table by spaces or tabs. You can list a maximum of 20 names (or 100 characters) for each IP address in the table.

When an entry appears in the table twice, PC/TCP returns the address for the first entry. If a hostname is not fully qualified in this table, PC/TCP may not be able to

resolve the associated address.

Network administrators often rely on domain name servers to distribute host

information throughout the network. Users can rely on local host tables if their domain

name servers are temporarily unavailable, but these tables must be manually updated

and kept consistent with the information on the domain name servers.

#### 1.4.8 Using a Domain Name Service

A Domain Name System (DNS) server can also map hostnames to IP addresses. DNS often distributes current host information to network applications, like electronic mail programs or the ftp program, on remote hosts. Domain name servers keep the host information current for their domains, and share it with other domain name servers on a network or on other networks. DNS often makes the task of distributing host information on a network faster and easier, but the job of administering a DNS server is more complex than maintaining a local host table file.

For more information about guides on administering Domain Name System servers, refer to the Master Index, Glossary, Bibliography.

## 1.5 Files for Managing Network Information

After you have configured your network addresses and domain names, you can proceed to handle the administrative tasks involved in providing network services. The following table lists typical UNIX server files that an administrator uses most frequently during daily administrative tasks. If you are uncertain as to how to use these files, refer to your UNIX system administration manual for more information.

Note: The location and, in some cases, the names of these files may vary on your system. On some UNIX systems, the files can be found in the `/usr` or `/etc` directories.

Ad UN

mini IX

stratSe

ive rve

Tas r

k Fil

e

Us

ed

Con /

figuretc

e /

the ine

Intertd.

net co

dae nf

mon

that

start

s

vari

ous

net

wor

k

serv

ices

for

your

net

wor

k.

Set /

sub etc

net /

mas net

ks. ma

sks

Map/

net etc

wor /

k net

addrwo

ess rks

es

to

net

wor

k

nam

es.

Assi/

gn etc

and /

stor ser

e vic

serves

er

and

dae

mon

port

infor

mati

on.

Con/

figuretc

e /

syst sys

em log

logg.co

ing. nf

Assi/

gn etc

num/

berspro

to toc

prot ols

ocol

s.

Defi /

ne etc

net /

wor gro

k up

grou

ps;

assi

gn

sec

ond

ary

grou

p

me

mbe

rshi

p to

a

user

.

Defi /

ne etc

net /

wor ho

k sts

host

nam

es

and

addr

ess

es;

add

a

new

host

to

your

net

wor

k.

Allo /

w etc

rem /

ote ho

acc sts

ess .eq

to a uiv

host

with

out

requ

iring

a

pas

SWO

rd.

Assi/

gn etc

and /

stor pa

e ss

userwd

acc

ount

infor

mati

on

(pas

swo

rds

are

encl

ypte

d).

Con /

trol etc

whic/

h ex

loca por

l file ts

syst

ems

are

avai

labl

e to

rem

ote

host

s

usin

g

NFS

.

Con /

figuretc

e /

the file

file sys

syst te

em. ms

Ent /

er etc

rem /

ote fst

file ab,

syst /et

emsc/v

into fst

the ab

file

syst

em

conf

igur

atio

n

file.

Con /

figuretc

e /

termget

inal tyd

line efs

s. ,

/et

c/g

ett

yta

b, /

etc

/ter

mc

ap,

/et

c/tt

ys,

/et

c/tt

yta

b

Con /

figuretc

e /

printpri

ers ntc

on ap

the

net

wor

k.

List /

the etc

prog/

ram rpc

s,

by

proc

ess

nam

e

and

prog

ram

num

ber,

that

resp

ond

to

rem

ote

proc

edur

e

calls

.

Mai /

ntai usr

n a /

list lib/

of ali

elec as

tronies

c

mail

alia

ses

for

the

net

wor

k

and

its

mail

ing

lists.

Con /

trol etc

defa /

ult def

syst aul

em t

and

user

setti

ngs.

Kee /

p a etc

list /

of ftp

users

s ers

who

are

prev

ente

d

from

usin

g ftp

to

get

acc

ess

to

the

serv

er.

Kee /

p a etc

data/

bas ut

e of mp

user

s

curr

entl

y

logg

ed

in to

the

serv

er.

Rec /

ord etc

syst /

em wt

logi mp

ns

and

logo

uts.

Sen /

d a etc

mes /

sag mo

e of td

the

day

to

all

user

s

whe

n

they

log

in to

the

serv

er.

## 1.6 Related Information About Managing Network Information

For more information about managing network information, refer to the following

sources:

Topi So

c urc

e

BasiGe

c ttin

con g

ceptSta

s of rte

PC/ d

TC

P

Gui Ma

des ste

and r

manInd

uals ex,

that Glo

explssa

ain: ry,

TC Bib

P/IPliog

prot rap

ocol hy

s

ISO

/

OSI

Mod

el

Con

tacti

ng

the

Inte

rNI

C

Inte

rnet

add

ress

clas

ses

Net

wor

k

add

ress

ing

sch

eme

s

Net

wor

k

dom

ains

and

sub

dom

ains

Hos

t

nam

ing

sch

eme

s

DN

S

serv

ers

## Chapter 1 Overview of TCP/IP Network Information

### 1.1 Before You Start Managing Network Information

### 1.2 The TCP/IP Protocol Family

### 1.3 The ISO/OSI Model

### 1.4 Identifying Hosts on the Network

#### 1.4.1 Obtaining a Network Number and Domain Name

#### 1.4.2 Preparing a Network Addressing Scheme

#### 1.4.3 Creating Subnets on the Network

#### 1.4.4 Specifying the Subnet Mask

#### 1.4.5 Specifying the Network Broadcast Address

#### 1.4.6 Preparing a Host Naming Scheme

#### 1.4.7 Creating a Local Host Table

1.4.8 Using a Domain Name Service

1.5 Files for Managing Network Information

1.6 Related Information About Managing Network Information

## Chapter 2

### PC/TCP Installation Options

PC/TCP offers a variety of installation options for the system administrator. Using the procedures defined in this chapter, you can customize the PC/TCP installation program to meet the needs of your group or site.

Note that the default PC/TCP installation procedure is defined in [Getting Started](#).

Using the procedures in this chapter, you can

- Customize the installation program using the SETUP.INF file.
- Set up a network install.
- Specify a central network configuration method.
- Manually copy PC/TCP files.

This chapter also contains an overview of the network operating system chapters contained in Part II, [Setting Up Special PC/TCP Installations](#).

## 2.1 Before You Choose an Installation Option

Before you use an installation procedure in this chapter, you should

- Decide how users at your site will install or upgrade PC/TCP software.
- Read the instructions in the SETUP.INF file on disk 1 of the PC/TCP installation diskettes.

## 2.2 Customizing the Installation Program for Your Site

This section contains procedures for customizing the PC/TCP installation program using the SETUP.INF file. This file is located on disk 1 of your PC/TCP installation disks.

Using the SETUP.INF file, you can configure

- Defaults for required installation information, including which Packet Driver to install, IP addresses, and domain names.
- The installation program dialog boxes shown to the end user.
- The PC/TCP components that the end user can choose from and the sets of files copied for each component.
- The contents of Windows Program Manager groups.
- A no-questions-asked batch install.

- Multiple installation programs (multiple SETUP.INF files), each tailored to the needs of a specific user (client) group.

Note that any changes that you make to the PC/TCP installation program affect the accuracy of the client installation procedures defined in Getting Started. You may want to supply the clients at your site with only the Express Install card or appropriate sections of the Getting Started guide.

Refer to the instructions in the SETUP.INF file for more information about the options described in this section.

## 2.2.1 Specifying Default Installation Information

You can provide default installation information, the answers to the questions that the installation program asks the user, by configuring the [answers] section of the SETUP.INF file.

The following example shows how this section can be used to specify a PC/TCP destination directory for the PC/TCP Express installation method (in Windows and DOS):

```
[answers]
```

```
  destdir="c:\newpctcp"
```

You can also specify a default Packet Driver using the network-driver= parameter. You may want to use this parameter in conjunction with a batch install, if many or all of the systems at your site use the same network interface card.

The following example shows an [answers] section with the corresponding driver section for a 3C503 packet driver:

```
[answers]
```

```
destdir="c:\newpctcp"
```

```
network-driver=pd$3c503
```

Note that the card you specify must be defined in the [netcard] section of the

NETCONF.INF file (which can also be found on the PC/TCP installation disks).

## 2.2.2 Defining Installation Program Dialog Boxes

You can control the installation program dialog boxes that the user sees using parameters in the [options] section of the SETUP.INF file. Each dialog box has a parameter that determines if that dialog is shown. By default, all installation program dialog boxes are shown.

To “hide” a dialog box, set the show-screen-dialog parameter for that screen to no. The following example shows a configuration where the user does not see a destination directory or kernel type dialog:

```
show-license-dialog=yes
```

```
show-directory-dialog=no
```

```
show-kernel-type-dialog=no
```

```
show-components-dialog=yes
```

show-driverlist-dialog=yes

show-ipconfig-dialog=yes

show-dnsconfig-dialog=yes

You might use these parameters to hide a dialog box for which you have provided default information in the [answers] section of the SETUP.INF file, such as the destination directory or the Packet Driver to install.

Note: If you do not show an installation screen, you must provide the information required by that dialog, either by adding other entries to the SETUP.INF file or configuring user files manually after installation. Refer to the parameter descriptions in the SETUP.INF file for more information.

### 2.2.3 Specifying PC/TCP Components and Copied Files

The PC/TCP installation program provides a Custom installation that lets the user select which PC/TCP components, or file groups, they want to copy to their system (in addition to a base set of files that provide basic network connectivity). Each component contains a default set of files.

To change default PC/TCP components

Edit the [components] section of the SETUP.INF file. This section lets you control which components the user can choose from, and the name of those components. The

following example shows the default components and labels:

```
[components]
```

```
nfs-client= "Using Network Files and Printers (NFS Client)"
```

```
email= "Exchanging Mail and News"
```

remotelogin= "Logging in to a Remote Host (Telnet and Rlogin)"

filetrans= "Transferring Files (FTP)"

printing= "Printing {LPR}"

backup= "Archiving and Restoring Files (TAR and RMT)"

To change the files copied for a component

Edit the [install] or appropriate component section in the SETUP.INF file. These

sections determine which of the files specified in FILES.INF will be copied during

installation. FILES.INF is located on PC/TCP installation disk 1.

The [install] section defines the files copied as part of the base set of PC/TCP files

(which all users receive by default, regardless of other selected components).

Other sections define the files copied for a particular PC/TCP component. The entries

in these sections are used only if the user selects the appropriate component when

installing. For example, if a user selects the Remote Login and Printing components, the installation program uses the following sections to determine the appropriate files to copy:

[remote login]

files=drlogin, @dosfiles

files=wrlogin, @winfiles

files=rlogin

files=keymap

[printing]

files=dprint, @dosfiles

files=wprint, @winfiles

files=pctcpnet, @winfiles

## 2.2.4 Configuring Program Manager Groups and Icons

To configure which PC/TCP applications appear in Windows Program Manager groups, edit the [groups] and appropriate application section ([dosapps] or [winapps] ) . You can also use these sections to revise program group or item names, or to remove PC/TCP program groups altogether.

In the following example, the [groups] and [winapps] sections have been configured to install only the WinApps program group and the Windows Statistics and Ping program items within that group:

```
[groups]
```

```
dosapps= "PC/TCP DOSApps",dosapps,no
```

```
winapps= "PC/TCP WinApps",winapps,yes
```

```
[winapps]
```

winet= "Statistics",yes,@targetdir\winet

wping= "Ping",yes,@targetdir\wping

wdial= "Dialer",no,@targetdir\wdial

wtar= "Archiver",no,@targetdir\wtar

## 2.2.5 Specifying Multiple SETUP.INF Files for Multiple User Groups

You can configure multiple SETUP.INF files if you want to provide different installation programs for different groups of users. This option is especially useful when setting up a network install.

To use multiple SETUP.INF files

1. Create and configure the number of .INF files that you need and name each file uniquely. For example, GROUP1.INF, GROUP2.INF, and so on.
2. Instruct the end user to specify the /h parameter and the appropriate .INF file when they enter the command to run the PC/TCP installation program.

The following example shows a command line to run the PC/TCP Setup program in

Windows with an alternate .INF file:

```
a:\setup /h a:\GROUP1.INF
```

## 2.2.6 Configuring a Batch Install

To configure an installation program that does not require user input, set the parameter `batch-install=` to `yes` in the `[options]` section of `SETUP.INF`. (The default is `no`).

When you specify a batch install, the installation program searches the `[answers]` and `[components]` section of your `SETUP.INF` file for required information. Any required information not specified in the `SETUP.INF` must be entered manually (to the appropriate system file) before you can use PC/TCP.

The batch install completes the installation program based on the value specified for the `batch-end=` parameter. Possible values for this parameter are

`exit` End the program without rebooting (the default)

`exit-win` End the program and exit Windows.

Note: If you select this option, PC/TCP will not delete temporary files created during

installation; you must delete these files manually.

reboot      End the program and reboot the user's system.

The following example shows the configuration for a batch install that reboots the

user's PC upon completion:

[options]

batch-install=yes

batch-end=reboot

## 2.3 Specifying a Central Configuration Method

If you intend to set up a server from which your users can obtain network and PC/TCP

configuration information, you must set up the server and specify a central

configuration method in the [OPTIONS] section of SETUP.INF.

To enable central configuration

1. Configure a Bootp or DHCP server to provide configuration information.
2. Specify the central configuration method appropriate for your server in the [OPTIONS] section of SETUP.INF. Possible values are bootp, dhcp, and none (the default).

The following example shows the appropriate entry to enable use of a Bootp server:

```
[options]
```

```
central-configuration=bootp
```

For client configuration procedures, see Chapter 9, [Configuring PC/TCP Remotely](#)

[Using DHCP or Bootp.](#)

## 2.4 Setting Up a Network Installation

This section defines the procedure for configuring a network installation. You may choose to have your users install over a network in order to simplify and standardize the installation process. Users at sites that are licensed for multiple installations, and that have installed previous versions of PC/TCP and InterDrive, may do upgrades from a common server using InterDrive.

To make this possible, the network administrator must copy all the files from the distribution diskettes to the remote directory, then instruct each remote user to connect to that drive and directory and run the installation program.

To set up a network install

1. At the DOS prompt, enter the command to create a new directory.

The following example creates the directory \NEWPCTCP:

```
mkdir n:\newpctcp
```

2. Copy the PC/TCP distribution diskettes into a directory on a remote machine.

You should use the DOS XCOPY command to copy any subdirectories. Repeat the

following procedure for each PC/TCP distribution diskette:

```
xcopy /s a:\*.* n:\newpctcp
```

3. Delete any existing FILES.INF file, then rename the file NETFILES.INF to

FILES.INF:

```
del n:\newpctcp\files.inf
```

```
ren n:\newpctcp\netfiles.inf n:\newpctcp\files.inf
```

4. Instruct your end users (or clients) to configure (using Interdrive) drive N to point to the remote machine, then mount that drive.
5. Instruct your users to enter the following command lines.

For Windows users:

From the Windows Program Manager, select Run from the File Menu, then enter

```
n:\newpctcp\setup
```

For DOS users:

Enter the following at the DOS command prompt.

```
n:\newpctcp\install
```

This procedure also applies to other network operating systems, such as Banyan

VINES, Novell NetWare, and Microsoft LAN Manager.

## 2.5 Manually Copying PC/TCP Files

If you need to copy additional files from the PC/TCP distribution diskettes, use the following procedure.

Note: FTP Software recommends that you use the PC/TCP installation program to copy PC/TCP files.

To copy a file from the PC/TCP installation disks

1. Place the disk containing the file to be copied in your disk drive.
2. To copy files in Windows — Choose Run from the Program Manager. Type the drive letter and setup /z For example,

```
a:\setup /z a:\filename .ex_ c:\pctcp\filename .exe
```

To copy files in DOS — Type the drive letter and install at the DOS prompt. For example,

```
a:\install /z a:\filename .ex_ c:\pctcp\filename .exe
```

## Chapter 2 PC/TCP Installation Options

### 2.1 Before You Choose an Installation Option

### 2.2 Customizing the Installation Program for Your Site

#### 2.2.1 Specifying Default Installation Information

#### 2.2.2 Defining Installation Program Dialog Boxes

#### 2.2.3 Specifying PC/TCP Components and Copied Files

#### 2.2.4 Configuring Program Manager Groups and Icons

#### 2.2.5 Specifying Multiple SETUP.INF Files for Multiple User Groups

#### 2.2.6 Configuring a Batch Install

### 2.3 Specifying a Central Configuration Method

### 2.4 Setting Up a Network Installation

### 2.5 Manually Copying PC/TCP Files

## Chapter 3

### Installing PC/TCP with Windows for Workgroups

Windows for Workgroups is a network operating system developed by Microsoft Corporation.

This version of PC/TCP is compatible with Windows for Workgroups 3.11.

PC/TCP provides TCP transport and RFC NETBIOS transport in both TSR (terminate-and-stay-resident) and VxD (Windows virtual device driver) implementations.

Windows for Workgroups works with PC/TCP's VxD kernel via NDIS (Network Driver Interface Specification) over either NDIS3, NDIS2, or ODI (Open Datalink Interface) drivers.

Using this chapter you can learn the following:

- How to configure Windows for Workgroups with PC/TCP for use on a single LAN (local area network).

This system configuration supports NETBIOS services using Windows for Workgroups NETBEUI only. It does not use PC/TCP NetBIOS. Use this configuration with systems that do not need to support NETBIOS services across a router (that is, if all NETBIOS traffic is on a single LAN).

- How to configure Windows for Workgroups with PC/TCP NetBIOS for use over a router.

These system configurations provide RFC NETBIOS functionality beyond a local subnet (for example, with remote Windows for Workgroups workstations).

You can configure your system to use NETBEUI and PC/TCP NetBIOS (TCP/IP) in parallel, or you can configure Windows for Workgroups to use PC/TCP NetBIOS instead of NETBEUI.

To configure Windows for Workgroups with PC/TCP, you must first configure Windows

for Workgroups and PC/TCP to run over NDIS or ODI drivers. For detailed procedures

see section 3.2, Configuring PC/TCP and Windows for Workgroups to Run over an

NDIS Driver.

If you need to support NETBIOS services over a router, follow the additional

configuration instructions in section 3.5, Configuring Windows for Workgroups to Use

PC/TCP NetBIOS.

### 3.1 Before You Install PC/TCP with Windows for Workgroups

Verify Windows for Workgroups connectivity over NDIS drivers before you install PC/TCP.

This chapter assumes that you are configuring your system with NDIS3 drivers.

Note: You do not need to reinstall Windows for Workgroups if it is already configured on your system.

To use Windows for Workgroups with NetBEUI transport and NDIS drivers, you should configure Windows for Workgroups with the Real and Enhanced Mode (NDIS2/NDIS3) option.

To use Windows for Workgroups with PC/TCP NetBIOS and NETBEUI in parallel, select the LAN Manager option under the Options for Enterprise Networking menu in the Startup Settings dialog box of the Network icon of the Control Panel.

For more information on how to configure your Windows for Workgroups over NDIS

drivers, see the Windows for Workgroups technical documentation.

### 3.2 Configuring PC/TCP and Windows for Workgroups to Run over an NDIS Driver

With this configuration, Windows for Workgroups stack sends NETBEUI packets and the PC/TCP stack sends IP packets.

Figure 3-1 illustrates the layering of the protocol stacks when you configure your

system to use PC/TCP with Windows for Workgroups over an NDIS3 driver.




Figure 3-1 Windows for Workgroups and PC/TCP over an NDIS Driver

PC/TCP and Windows for Workgroups installation programs both modify the following

system initialization files:

- AUTOEXEC.BAT

- CONFIG.SYS
- PROTOCOL.INI
- SYSTEM.INI

Before you proceed to use PC/TCP with Windows for Workgroups, you should verify that each of these files is correct.

To review the AUTOEXEC.BAT file

Examine your AUTOEXEC.BAT file to verify that

- The Microsoft netbind command is deleted or commented out.
- The net start command precedes the line that any TSR programs (such as the TSR kernel or the VXDINIT.EXE VxD initialization TSR).

This example starts Windows for Workgroups with the PC/TCP ETHDRV TSR kernel:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP.INI
```

```
C:\WINDOWS\NET START
```

```
C:\PCTCP\ETHDRV
```

This example starts Windows for Workgroups with the PC/TCP VxD kernel:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP.INI
```

```
C:\WINDOWS\NET START
```

```
C:\PCTCP\VXDINIT
```

Note: This example does not load PC/TCP NetBIOS. It assumes that vnebp=no in the

[pctcp vxdinit] section of your PCTCP.INI file. (This is the default.)

For detailed procedures for loading PC/TCP NetBIOS and the PC/TCP Interdrive NFS

client, see section 3.6, [Loading PC/TCP NetBIOS and InterDrive.](#)

To review the CONFIG.SYS file

Examine your CONFIG.SYS file to verify that

- These device statements are deleted or commented out:
  - The Windows device driver
  - The PC/TCP NDIS2 packet-driver converter (DIS\_PKT.GUP)
  - The protocol manager (PROTMAN.DOS), and
  - Any NDIS card-specific driver
- This device statement appears.

```
device=c:\windows\lifshlp.sys
```

To review the PROTOCOL.INI file

Examine the PROTOCOL section of the PROTOCOL.INI file and verify that includes

the appropriate binding. For example,

[PKTDRV]

drivename=PKTDRV\$

BINDINGS=MS\$ELNKII

intvec=0X60

chainvec=0x65

Where BINDINGS= identifies the name of the Windows for Workgroups driver section

in this file.

Note: BINDINGS must be capitalized, and there should be no spaces around the equals sign.

To review the SYSTEM.INI file

Examine your SYSTEM.INI file to verify that

ThDoe

is s

se this

cti

on

[b Spe

oo cifie

t] s the

Win

dow

s for

Wor

kgro

ups

netw

ork

drive

r,

follo

wed

by a

line

ident

ifyin

g the

PC/

TCP

netw

ork

drive

r.

For

exa

mple

,

[boot

]

netw

ork.d

rv=w

fwne

t.driv

seco

ndne

t.driv

=c:

\pctc

p\pct

cpne

t.driv

[b Des

oo cribe

t s the

de Win

sc dow

rip s for

tio Wor

n] kgro

ups

3.11

drive

r.

For

exa

mple

,

[boot

.des

cripti

on]

netw

ork.d

rv=M

icros

oft

Win

dow

s for

Wor

kgro

ups

3.11

[3 Doe

86 s not

Encont

h] ain

entri

es

for

WF

WFT

P.38

6 or

VPC

TCP.

386.

Rem

ove

(or

com

ment

out)

thes

e

entri

es if

they

appe

ar.

[n Cont

et ains

woentri

rk es

dri spec

ve ifyin

rs]g the

nam

e of

your

netw

ork

drive

r.

For

exa

mple

,

[net

work

drive

rs]

netc

ard=

your

\_ND

IS\_d

river

\_file

nam

e.ext

trans

port

=ndi

shlp.

sys,\*

netb

eui

Load

RM

Driv

ers

= No

The

aster

isk

(\*) in

the

NET

BEU

I file

nam

e is

a

valid

char

acter

.

Note

:

Onl

y if

you

are

usin

g

NDI

S2

and

the

TSR

kern

el,

add

the

NDI

S2

pack

et-

drive

r-

conv

erter

(\pat

hna

me\d

is\_p

kt.gu

p) to

the

trans

port

=

line,

and

set

Load

RM

Driv

ers=

Yes.

### 3.3 Configuring PC/TCP and Windows for Workgroups to Run over an ODI Driver

ODI is a driver specification developed by Novell to provide the coexistence of NetWare and protocols other than Novell's proprietary IPX (such as TCP/IP and AppleTalk).

PC/TCP can communicate with NetWare 386 servers (3.x and above) using PC/TCP DIX Ethernet and IEEE 802.5 Token Ring kernels.

Note: If you want NETBIOS connectivity over routers (with PC/TCP and Windows for Workgroups over ODI drivers), you must configure the PC/TCP TSR kernel and the PC/TCP NetBIOS TSR.

For more information about configuring PC/TCP NetBIOS, see section 3.5, [Configuring Windows for Workgroups to Use PC/TCP NetBIOS.](#)

This is a sample AUTOEXEC.BAT file:

Ent To

er loa

thisd

linethis

SE PC/

T TC

PC P

TC con

P= figu

C: rati

\P on

CT file

CP pat

\P hna

CT me.

CP.

INI

C: Star

\WIt

ND the

O net

WSwor

\N k.

ET

ST

AR

T

C: Link

W Sup

W port

CLILay

EN er.

TL (Thi

SL. s

COfile

M co

me

s

with

the

Net

War

e

dist

ribu

tion

.)

C: MLI

W D

W laye

CLIr.

EN (Thi

T\3 s is

C5 the

03. ODI

CO driv

M er

that

co

me

s

with

you

r

net

wor

k

ada

pter

car

d.)

Thi

s

pro

gra

m

usu

ally

has

the

sa

me

na

me

as

you

r

net

wor

k

inte

rfac

e

with

a .C

OM

ext

ensi

on.

C: Nov

W ell

W prot

CLlocol

EN stac

TI k

PX file.

OD

I.C

OM

C: ODI

\P -to-

CT pac

CP ket

\O driv

DI er

PK con

T.C vert

OMer.

You

can

use

co

mm

and

line

opti

ons

to

furt

her

spe

cify

the

bin

din

gs

that

ODI

PKT

.CO

M

sho

uld

perf

orm

.

For

exa

mpl

e,

odi

pkt

[?]

[unl

]

[sint

=

xx]

[mli

d=

na

me]

[fra

me

=

fra

me-

stri

ng]

Her

e is

an

exa

mpl

e of

loa

din

g a

driv

er

at

inte

rrup

t

65:

C:

\>0

dipk

t

sint

=65

mlid

=3c

503

fra

me

=ET

HE

RN

ET\_

SN

AP

C: Net

W War

W e

CLiredi

EN rect

TVor.

LM Not

.EXe:

E

You

can

alte

rnat

ivel

y

loa

d

the

NE

T X

Net

War

e

shel

I

file.

C: For

\P the

CT PC/

CP TC

\ETP

HD TS

RV.R

EX ker

E nel.

C: Win

\WIdow

ND s

O for

WSWor

\O kgr

DI oup

HL s

P.E ODI

XE inte

rfac

e.

For detailed procedures for configuring PC/TCP over ODI drivers, see section 4.2,

[Configuring NetWare and PC/TCP over ODI Drivers.](#)

### 3.4 Using PC/TCP Network Drivers with Other Network Operating Systems

The PC/TCP Network Driver (PCTCPNET.DRV) allows you to access remote files and printing services through the Windows File Manager, Control Panel, and Print Manager.

If you use other network operating systems concurrently with PC/TCP software, these systems must be connected to enable access to each system's services. The configuration of these network operating systems is referred to as "chaining" one network to or from another.

The PC/TCP installation program detects other network operating systems on your system and makes the appropriate changes to the [BOOT] section of your SYSTEM.INI file, as outlined in the following table:

Net SY

wor ST

k E

Op M.

eratINI

ing en

Systri

tem es

(s)

PC/[B

TC O

P O

onl T]

y ne

tw

or

k.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P O

and T]

Winne

do tw

ws or

for k.d

Worrv

kgr =w

oup fw

s ne

t.d

rv

se

co

nd

ne

t.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P, O

WinT]

do ne

ws tw

for or

Work.d

kgr rv

oup=w

s, fw

and ne

anot.d

therrv

net se

wor co

k nd

ope ne

rati t.d

ng rv

syst=p

em ctc

(su pn

ch et.

as dr

Novv

ell pct

Net cp

Warch

e) ain

=n

et

wa

re.

dr

v

Note: You should verify that the [386EnH] section does not contain entries for

WFWFTP.386 or VPCTCP.386. Remove (or comment out) these entries if they appear.

### 3.5 Configuring Windows for Workgroups to Use PC/TCP NetBIOS

Configuring Windows for Workgroups with PC/TCP NetBIOS gives you RFC NETBIOS functionality over routers.

Note: PC/TCP supports RFC NetBIOS transport in both VxD and TSR implementations.

You can configure Windows for Workgroups to use PC/TCP NetBIOS in two ways:

- With PC/TCP NetBIOS and Windows for Workgroups NETBEUI in parallel.

Use this configuration to support a non-homogeneous NETBIOS environment. For example, if you need to interoperate with NETBEUI-compatible applications.

- With PC/TCP NetBIOS instead of Windows for Workgroups NETBEUI.

This configuration is most efficient if you do not need to interoperate with NETBEUI-compatible applications. Using this configuration you can reclaim memory that was

reserved for NETBEUI.

Note: In general, the default PC/TCP NetBIOS configuration is adequate for most operating environments. If necessary, you can customize PC/TCP NetBIOS by editing the [pctcp netbios] section of the PC/TCP configuration file (PCTCP.INI). For more information, see Chapter 8, [Configuring NetBIOS](#).

### 3.5.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

Before you begin, follow the steps in section 3.2, Configuring PC/TCP and Windows for Workgroups


Workgroups to Run over an NDIS Driver.

Figure 3-2 illustrates the protocol stack when you configure Windows for Workgroups

(NETBEUI) and PC/TCP NetBIOS in parallel. Using this configuration, you can support a non-homogeneous NETBIOS environment.

Windows for Workgroups sends/receives NETBIOS traffic via

- RFC NETBIOS (using PC/TCP NetBIOS).
- NETBEUI (using Windows for Workgroups).



### Figure 3-2 Windows for Workgroups (NETBEUI) and PC/TCP NetBIOS in Parallel

Follow these steps to edit your system initialization files to use PC/TCP NetBIOS with

Windows for Workgroups(NETBEUI) in parallel:

1. Revise entries in your PROTOCOL.INI file to use PC/TCP NetBIOS.

In the [network.setup] section, change the lana0= entry to lana n, where n is the next

available adapter number. For example,

```
[network.setup]
```

```
lana2=ms$lnk3,1,ms$netbeui
```

In the [ms\$netbeui] section, change LANABASE=0 to LANABASE= n, where n is the

same number as the adapter number specified in the [network.setup] section. For

example,

```
[ms$netbeui]
```

lanabase=2

2. Revise entries in your PCTCP.INI file to configure PC/TCP NetBIOS.

If you need to support NETBIOS access over routers, you must configure PC/TCP

NetBIOS to specify a name file and a broadcast file (using the namefile= and

broadcastfile= parameters in the [pctcp netbios] section of your PCTCP.INI file).

For example,

```
[netbios]
```

```
namefile=c:\pctcp\namefile.txt
```

```
broadcastfile=c:\pctcp\broadcast.txt
```

Where namefile.txt and broadcast.txt contain entries that identify NETBIOS hosts

beyond your local LAN.

For more information about customizing your NetBIOS configuration, see Chapter 8,

## Configuring NetBIOS.

Note: When you configure your system to use PC/TCP NetBIOS, you may need to configure the kernel with additional TCP connections. As a general rule, one NetBIOS session requires one TCP connection. For a detailed procedure for configuring the kernel with additional TCP connections, see section 13.3.3, Adjusting the Number of

TCP and UDP Connections.

### 3.5.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

This configuration lets you use PC/TCP NetBIOS instead of Windows for Workgroups (NETBEUI).

Figure 3-3 illustrates the layering of the software stack.




Figure 3-3 Windows for Workgroups with PC/TCP NetBIOS (only)

Follow these steps to configure your system to use PC/TCP NetBIOS (instead of NETBEUI):

1. Follow the steps for configuring your system with Windows for Workgroups over

NDIS drivers. For more information, see section 3.2, Configuring PC/TCP and

Windows for Workgroups to Run over an NDIS Driver.

2. Follow the steps for configuring your system to use PC/TCP NetBIOS. For more information, see section 3.5.1, Configuring Your System to Use PC/TCP NetBIOS and

NETBEUI in Parallel.

3. Edit the netmisc= and transport= entries in the [386Enh] section of your

SYSTEM.INI file to remove references to netbeui.386. For example,

[386Enh]

netmisc=ndis.386,ndis2sup.386

transport=nwlink.386,nwnblink.386

### 3.6 Loading PC/TCP NetBIOS and InterDrive

This section describes how you can edit your AUTOEXEC.BAT file to automatically load

PC/TCP NetBIOS and the PC/TCP InterDrive NFS client each time that you start your

PC. The loading procedures differ based on your kernel implementation (TSR or VxD).

To load the NetBIOS TSR

1. Ensure that the AUTOEXEC.BAT file contains a line that loads your PC/TCP TSR

kernel.

2. Add a line to your AUTOEXEC.BAT file to load PC/TCP NetBIOS.

Load PC/TCP NetBIOS (NETBIOS.COM) before you start the network

(net start workstation) and after you load the PC/TCP kernel.

This example loads the PC/TCP DIX Ethernet TSR kernel and the PC/TCP NetBIOS

TSR (NETBIOS.COM):

```
C:\WINDOWS\NET START
```

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
ETHDRV
```

```
NETBIOS.COM
```

```
NET START WORKSTATION
```

If you are also using InterDrive, you must start the workstation (and log in, if you are using user security) before you load InterDrive.

To load the NetBIOS VxD

Ensure that the AUTOEXEC.BAT file contains a line specifying the VXDINIT VxD

initialization program. For example

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
NET START
```

```
VXDINIT +n
```

Alternatively, you can use the vxdinit command without the +n option and set

vnbep=yes in the [pctcp vxdinit] section of your PCTCP.INI file.

For more information on using PC/TCP NetBIOS, refer to Chapter 8, Configuring

NetBIOS.

To load the InterDrive TSR

The InterDrive TSR is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify that the idrive command appears after the

command that loads the PC/TCP kernel in your AUTOEXEC.BAT file.

The following AUTOEXEC.BAT file fragment includes commands that set the path of

the PCTCP.INI file, load the PC/TCP TSR kernel for a DIX Ethernet network, and start

InterDrive:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
C:\PCTCP\3C503.COM 0x60 3 0x280
```

```
C:\PCTCP\ETHDRV.EXE
```

```
C:\PCTCP\IDRIVE
```

To load the InterDrive VxD

The InterDrive VxD is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify the vxdinit command appears in your

AUTOEXEC.BAT file before you start Windows. This command starts the VxD kernel

and VxD InterDrive (by default). For example,

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
VXDINIT
```

This assumes that vidrive=yes in the [pctcp vxdinit] section of your PCTCP.INI file. (This is the default.)

For more information on using the InterDrive client program, refer to Using PC/TCP in

Windows Chapter 6, Sharing Network Files.

### 3.7 Related Information About Installing PC/TCP with Windows for Workgroups

Refer to the following sources for more information about installing PC/TCP with

Windows for Workgroups:

TopiSo

c urc

e

Inst Get

allin ting

g Sta

and rte

confd

iguri

ng

PC/

TC

P

ove

r an

NDI

S

driv

er.

Loa Ch

dingapt

and er

conf8,

iguriCo

ng nfig

PC/ uri

TC ng

P Net

Net Bl

BIO OS

S.

Inst Do

allincu

g me

and nta

confion

igurisup

ng plie

Win d

dowwit

s h

for you

Worr

kgr dist

oup rib

s. utio

n

of

Wi

nd

ow

s

for

Wo

rkg

rou

ps

## Chapter 3 Installing PC/TCP with Windows for Workgroups

### 3.1 Before You Install PC/TCP with Windows for Workgroups

### 3.2 Configuring PC/TCP and Windows for Workgroups to Run over an NDIS Driver

### 3.3 Configuring PC/TCP and Windows for Workgroups to Run over an ODI Driver

### 3.4 Using PC/TCP Network Drivers with Other Network Operating Systems

### 3.5 Configuring Windows for Workgroups to Use PC/TCP NetBIOS

#### 3.5.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

#### 3.5.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

### 3.6 Loading PC/TCP NetBIOS and InterDrive

### 3.7 Related Information About Installing PC/TCP with Windows for Workgroups

## Chapter 4

### Installing PC/TCP with Novell NetWare

To use PC/TCP and NetWare concurrently, you can use shared drivers to run a

NetWare stack and a PC/TCP stack simultaneously on a single card. You can also use

PC/TCP and NetWare concurrently using NetWare/IP.

With this chapter, you can learn how to configure to use NetWare and PC/TCP

concurrently

- Over an ODI (Open Data Link Interface) Ethernet or token ring driver.
- Over an ASI (Adapter Support Interface) token ring driver.

You can also learn how to configure your system to run PC/TCP and NetWare

concurrently

- Over the Internet Protocol using NetWare/IP.
- Over an Ethernet packet driver.

- Over an NDIS (Network Driver Interface Specification) driver.

#### 4.1 Before You Install PC/TCP with Novell NetWare

Before you install PC/TCP with Novell NetWare, you or your system administrator

should

- Ensure that you meet all of the PC/TCP system requirements in [Getting Started](#).
- Install Novell NetWare and verify that the installation is operational.

## 4.2 Configuring NetWare and PC/TCP over ODI Drivers

ODI is a driver specification developed by Novell to provide the coexistence of NetWare and protocols other than Novell's proprietary IPX (such as TCP/IP and AppleTalk).

PC/TCP can communicate with NetWare 386 servers (3.x and above) using PC/TCP DIX Ethernet and IEEE 802.5 Token Ring kernels.

The ODI architecture consists of the Multiple Link Interface Driver (MLID) layer and the Link Support Layer (LSL) layers:

- The MLID handles the sending and receiving of packets to and from a physical or logical media.
- The LSL handles the communication between protocol stacks and MLIDs by determining which protocol stacks to pass a packet to, when one is received by the MLID.

PC/TCP requires an ODI-to-packet driver converter (ODIPKT.COM) to provide an interface between the Link Support Layer and the PC/TCP kernel. The ODI converter supports the DIX Ethernet, IEEE Ethernet, and IEEE 802.5 token ring kernels.

ODI drivers do not require a NetWare shell. Using ODI, you also do not need to modify the Ethernet frame type. The workstation sends DIX encapsulation from the PC/TCP side, and 802.3 packets from the Novell side.

Figure 4-1 shows how PC/TCP and NetWare can work together with ODI. The left half of the figure illustrates the general layering of ODI drivers within the PC/TCP architecture.




Figure 4-1 Layering of ODI Drivers with PC/TCP

#### 4.2.1 Before You install PC/TCP over ODI Drivers

Make sure that you

1. Install NetWare and verify the installation.
2. Perform the PC/TCP installation steps described in Getting Started Chapter 1,

##### Installing PC/TCP Software.

Select one of these PC/TCP kernels: DIX Ethernet, IEEE 802.3 Ethernet, or IEEE

802.5 Token Ring.

## 4.2.2 Configuring NetWare and PC/TCP to Run over ODI Drivers — Procedure

These are the steps to run PC/TCP over ODI drivers:

1. Create or update your NET.CFG file.

This file contains configuration information for each ODI module. The NET.CFG file may be supplied with your driver.

2. Configure the [pctcp interface n] section of your PCTCP.INI file.
3. Edit the AUTOEXEC.BAT file to load the appropriate drivers.

Reboot your system and test your configuration by communicating with a remote host on the network using the ping command.

To create the NET.CFG file

The file consists of main headings followed by the entries for the section. These are the main headings: PROTOCOL, LINK SUPPORT, and LINK DRIVER.

NET.CFG configuration file entries take the following form:

link driver drivename

Note: Precede each configuration entry line with spaces or a tab.

This is a description of the lines in the NET.CFG file:

link driver drivename      Specifies the filename of your vendor-supplied MLID driver.

int int\_vector Changes the interrupt (IRQ) to the number you specify.

port port\_#      Changes the board's base I/O address from the default to the number you specify (in hexadecimal).

mem base\_mem\_addr      Specifies the base memory address for this interface.

frame type      The "frame" entry (sometimes called "envelope type") specifies your

network media type. The frame type can be any of the following:

P P Net

C/CWa

T / re

C T fra

P C me

k P typ

er fr e

n a

el m

e

ty

p

e

E E Eth

T T ern

H Het\_

D E 80

R R2.3

V N

E

T

\_J

I

IEE Eth

E T ern

E Het\_

D E 80

R R 2.3

V Nan

E d

T Eth

\_ ern

S et\_

N 80

A 2.2

P

T T Tok

O Oen-

K K Rin

D Eg\_

R N80

V - 2.5

R

I

N

G

-

S

N

A

P

If they are needed for other tasks, you can use both the NetWare and the PC/TCP frame type entries. Specify the NetWare frame type before the PC/TCP frame type in the NET.CFG file.

Note: Some network interface adapter cards may require additional parameters (such as, interrupt vector, port number, base memory address, or frame type). For more detailed information about the syntax of NET.CFG file entries, see the Novell NetWare technical documentation.

Here is a sample NET.CFG file for Ethernet 802.3 running over a 3Com 3C503 adapter:

```
link driver 3c503
```

```
int 3
```

port 280

mem D8000

frame ETHERNET\_802.3

frame ETHERNET\_802.2

frame ETHERNET\_II

Note that ODIPKT.COM consumes two protocol stack entries in the internal LSL tables.

By default, LSL supports four protocol stacks. If you need more than two protocol

stacks, add a line in the following form to the LINK SUPPORT section of your NET.CFG

file:

max stacks int

where int is the number of stacks that LSL should support.

Note: If you are using a Cabletron network interface card, you must set max stacks to

6.

To configure the network interface in the PCTCP.INI file

Use a text editor to modify the [pctcp ifcust n] section of the PCTCP.INI file so that it

describes your PC/TCP kernel interface. For example,

```
[pctcp ifcust 0]
```

```
ip-address= 128.127.50.1
```

```
router=128.127.50.2
```

```
subnet-mask=255.255.255.0
```

If you are using the VxD kernel, add these lines to specify the network interface and

frame type. For example, these lines specify the packet driver interface using the DIX

Ethernet frame type:

```
frame-type= DIX-Ethernet
```

interface-type= PKTDRV

To modify the AUTOEXEC.BAT file

Use a text editor to load the following programs in the order indicated.

The following lines load both PC/TCP DIX Ethernet kernel and NetWare over ODI on a

3Com 3c503, Ethernet network interface card:

En To

ter load

thi this

s

lin

e

C: Link

\N Sup

W port

CL Lay

IE er.

NT(Thi

\L s file

SL com

.C es

O with

M the

Net

War

e

distr

ibuti

on.)

C: MLI

\N D

W laye

CLr.

IE (Thi

NTs is

\3 the

C5 ODI

03.driv

C er

O that

M com

es

with

your

net

wor

k

ada

pter

card

.)

This

prog

ram

usu

ally

has

the

sam

e

nam

e as

your

net

wor

k

inter

face

with

a .C

OM

exte

nsio

n.

C: Nov

\N ell

W prot

CLocol

IE stac

NTk

\IP file.

XO

DI.

C

O

M

C: ODI

\P -to-

CTpac

CPket

\O driv

DI er

PKcon

T. vert

C er.

O You

M can

use

com

man

d

line

opti

ons

to

furth

er

spe

cify

the

bind

ings

that

ODI

PKT

.CO

M

sho

uld

perf

orm.

For

exa

mpl

e,

odip

kt

[?]

[unl]

[sint

=

xx]

[mli

d=

nam

e]

[fra

me=

med

ia\_t

ype]

Whe

re

med

ia\_t

ype

is

one

of

the

follo

wing

:

ETH

ER

NET

\_II,

ETH

ER

NET

\_SN

AP,

or

TOK

EN-

RIN

G\_S

NAP

.

Not

e:

Ente

r the

fram

e

med

ia\_t

ype

in

upp

er

cas

e.

Her

e is

an

exa

mpl

e of

load

ing

a

driv

er at

inter

rupt

65:

C:

\>od

ipkt

sint

=65

mlid

=3c

503

fram

e=E

THE

RN

ET\_

SNA

P

For

a

brief

des

cript

ion

of

eac

h

ODI

PKT

.CO

M

opti

on

ente

r

odip

kt -?

at

the

DO

S

com

man

d

line

pro

mpt.

C: Net

\N War

W e

CL redir

IE ecto

NTr.

\V Not

LMe:

.E

XE You

can

alter

nati

vely

load

the

NET

X

Net

War

e

shell

file.

C: For

\P the

CTPC/

CPTCP

\E TSR

THkern

DRel.

V.

For

EX

the

E

PC/

- TCP

or-VxD

C: .

\P This

CTass

CPume

\V s

XDthat

INI fram

T e-

type

=ET

HD

RV

and

inter

face

-

type

=PK

TDR

V in

the

[pct

cp

ifcus

t 0]

secti

on

of

your

PCT

CP.I

NI

file.

For more information about loading the PC/TCP InterDrive NFS client, see section 4.9,

## Loading InterDrive.

For more information about configuring the VxD kernel, see Chapter 13, Configuring

and Tuning the Kernel.

### 4.3 Configuring NetWare and PC/TCP over Token Ring and ASI Drivers

NetWare and PC/TCP can work together over token ring through the IBM LAN Support

program and the PC/TCP token ring kernel IBMTR.EXE. The IBM LAN Support

program is an implementation of the ASI (Adapter Support Interface) specification.

Like the packet driver interface, the ASI driver can identify packets from different

protocol types and pass them to the appropriate protocol stack.

Figure 4-2 shows how PC/TCP and NetWare work over token ring.




Figure 4-2 PC/TCP and NetWare over Token Ring and ASI

Follow these steps to configure PC/TCP and NetWare over an ASI driver:

1. Install the IBM LAN Support program according to instructions in Chapter 22,

Troubleshooting the Kernel and Driver Configuration.

2. Install PC/TCP using the procedures in Getting Started.
3. Generate a NetWare shell.

To use NetWare and PC/TCP over the same network interface card, you must

generate a new NetWare IPX shell for the packet driver interface. For more

information, see section 4.2, Configuring NetWare and PC/TCP over ODI Drivers.

Note: The NetWare shell generation and linker program is called WSHGEN.EXE for

NetWare 3.x and later.

4. Add statements to your CONFIG.SYS file to support PC/TCP and NetWare over token ring. The following is an example:

```
device=c:\asi\dxma0mod.sys
```

```
device=c:\asi\dxme0mod.sys
```

```
device=c:\asi\dxmt0mod.sys ES=2 O=Y
```

The ES= option makes the driver allocate more Service Access Points (SAP). Each protocol type running over a token ring board needs a SAP. By default, each driver is allocated one SAP. If you use more than one protocol over a board, set ES= to a number greater than or equal to the number of protocols used.

Before you proceed, you must verify that the shell is loaded properly, and that the IPX.COM loader is running for the ASI driver.

#### 4.4 Configuring NetWare/IP over PC/TCP

PC/TCP provides emulation of the LAN WorkPlace TCP/IP application programming interface (API) using the PC/TCP LWPE.COM program. This TSR (terminate-and-stay-resident) program allows you to run LAN WorkPlace applications, including Novell's NetWare/IP application, over any PC/TCP TSR kernel.

The LWPE program works by intercepting calls from a LAN WorkPlace application or NetWare/IP and redirecting these calls to a PC/TCP kernel. To support NetWare/IP, LWPE.COM must be run over the ODIPKT driver. This is due to dependencies between NetWare/IP, the NetWare redirector (VLM), and the Link Support Layer (LSL).

Figure 4-3 illustrates the protocol stack when you configure PC/TCP with NetWare/IP support.




Figure 4-3 PC/TCP with NetWare/IP

As with the standalone NetWare/IP product, the NWIP.COM module will not load unless it finds both a Domain Name System (DNS) server and a Domain SAP Server (DSS) on the network.

For NetWare 3.11 and later servers, PC/TCP and NetWare can run concurrently over any network media supported by PC/TCP through an IP tunnel. The tunnel lets PC/TCP encapsulate, or carry NetWare IPX packets inside IP.

For a description of how to configure an IP tunnel with PC/TCP, consult the anonymous

FTP server ftp.ftp.com.

#### 4.4.1 Before You Configure PC/TCP LWPE to Work over NetWare/IP

Make sure that

- You install the Novell NetWare/IP software on your system.

For more information on NetWare/IP and NetWare commands, refer to the NetWare/IP

and NetWare client manuals.

- You follow the steps defined in section 4.2, Configuring NetWare and PC/TCP over ODI Drivers to install PC/TCP and Novell NetWare with ODI drivers.

#### 4.4.2 Configuring PC/TCP LWPE to Work over NetWare/IP — Procedure

Follow these steps to configure PC/TCP LWPE to work over NetWare/IP:

1. Edit your AUTOEXEC.BAT file to load the appropriate programs in the order indicated.

Note: Comment out or delete any line that starts the NetWare/IP STARTNET.BAT file.

This line was added to your AUTOEXEC.BAT file by the NetWare/IP client installation procedure.

The following lines load both PC/TCP DIX Ethernet TSR kernel (ethdrv.exe) and

NetWare over ODI on a 3Com 3c503, Ethernet network interface card. You should

modify these lines to specify your network interface.

EntTo

er load

thi this

s

lin

e

C: LSL

\N laye

W r.

CL

IE

NT

\LS

L.

CO

M

C: MLI

\N D

W laye

CL r.

IE This

NT pro

\3 gra

C5 m

03.usu

COally

M has

the

sam

e

nam

e as

your

net

wor

k

inter

face

with

a .C

OM

exte

nsio

n.

C: ODI

\P -to-

CT pac

CP ket

\O driv

DI er

PK con

T.Cvert

O er.

M

C: PC/

\P TC

CTP

CPTS

\E R

TH kern

DRel.

V.

EX

E

C: PC/

\P TC

CTP

CPLW

\L PE.

W CO

PEM

.C TS

O R

M pro

gra

m

that

ena

bles

you

to

run

Nov

ell

Net

War

e IP

over

the

PC/

TC

P

stac

k.

C: Net

\N War

W e/IP

CL appl

IE icati

NT on

\N pro

WI gra

P. m.

CO

M

C: Net

\N War

W e

CL redi

IE rect

NT or.

\VLNot

M. e:

CO

M You

can

alter

nati

vely

load

the

NE

T X

Net

War

e

shel

I

file.

For more information about loading the PC/TCP InterDrive NFS client, see section 4.9,

### Loading InterDrive.

2. Edit the CONFIG.SYS file to includes the following line:

```
LASTDRV=Z
```

3. Edit your PCTCP.INI file to contains a [PCTCP LWPE] section that at least identifies

the pathname of your RESOLV.CFG file (config-path= ). You can customize your LWPE configuration by entering new default values for other [ptcp lwpe] parameters.

This example shows the default [ptcp lwpe] settings:

```
[ptcp lwpe]
```

```
rcbs=40
```

```
sockets=32
```

```
loadhigh=yes
```

```
config-path=C:\your_RESOLV.CFG_filename
```

4. Verify that your NET.CFG file contains an NWIP\_DOMAIN entry.
5. Edit your RESOLV.CFG file to specify your name server environment.

This is a sample RESOLV.CFG file.

```
domain abc.xyz.com
```

nameserver 128.127.50.123

nameserver 128.127.51.789

For more information on the file syntax, see your NetWare/IP technical documentation.

## 4.5 Configuring NetWare and PC/TCP over Ethernet and a Packet Driver

PC/TCP and NetWare work together through shared drivers that let both protocols share a single interface card. One of these shared driver specifications is the packet driver.

Figure 4-4 shows the protocol stack for this configuration.




Figure 4-4 PC/TCP and NetWare over a Packet Driver

To use PC/TCP and NetWare concurrently over Ethernet, you must follow these steps:

1. Copy the packet driver software to your PC.

Tested and supported drivers reside on the "Supported Packet Driver" disk of the

PC/TCP distribution. You may also use a packet driver provided by the interface card manufacturer.

Unsupported packet drivers are available via anonymous FTP from host ftp.ftp.com.

2. Follow the instructions in Getting Started to install PC/TCP with the ETHDRV DIX

Ethernet kernel.

3. Verify that your AUTOEXEC.BAT file loads these programs in this order:

Ent To

er loa

this d

line this

3C Th

503 e

.COap

M pro

0x6 pri

0 5 ate

0x2 pac

80 ket

0xCdriv

800 er.

For

mo

re

info

rm

atio

n

ab

out

pac

ket

driv

er

opti

ons

,

see

its

tec

hni

cal

doc

um

ent

atio

n.

C: Th

W e

WC Net

LIE Wa

NT\re

PDI pro

PX. toc

CO ol

M sta

ck

file

tha

t

you

ge

ner

ate

d

spe

cifi

call

y

for

the

pac

ket

driv

er.

C: Th

W e

WCNet

LIE Wa

NT\re

VL red

M. irec

CO tor.

M Not

e:

Yo

u

can

alte

rna

tive

ly

loa

d

the

NE

T X

Net

Wa

re

she

ll

file.

C: Th

\PCe

TC PC

PIE /TC

TH P

DR TS

V.E R

XE ker

- nel.

or-  
For

C:  
the

\PC  
PC

TC  
/TC

PW  
P

XDI  
Vx

NIT  
D

ker

nel.

Thi

s

ass

um

es

tha

t

you

hav

e

set

fra

me

-

typ

e=

an

d

inte

rfa

ce-

typ

e=

in

the

[pct

cp

ifcu

st

0]

sec

tion

of

you

r

PC

TC

P.I

NI

file.

For

mo

re

info

rm

atio

n

ab

out

con

figu

rin

g

the

PC

/TC

P

ker

nel,

see

Ch

apt

er

13,

Co

nfig

uri

ng

an

d

Tu

nin

g

the

Ker

nel.

Note: You may need to modify the server or packet driver Ethernet frame type. Refer to section 4.7, Modifying the Ethernet Frame Type on the NetWare Server for instructions.

For more information about loading the PC/TCP InterDrive NFS client, see section 4.9,

Loading InterDrive.

## 4.6 Configuring PC/TCP and NetWare over NDIS Drivers

The NDIS driver is another shared driver interface that can support multiple protocols.

Version 1.15 and later of the NDIS-to-Packet Driver converter program, DIS\_PKT.GUP,

supports the BYU (Brigham Young University) and Intel shells so that you can use

PC/TCP and Novell NetWare concurrently over NDIS drivers.

Follow these steps to configure your system to use NDIS Drivers with NetWare:

1. Perform the PC/TCP installation steps described in Getting Started Chapter 1,

Installing PC/TCP Software.

2. Install and configure the NDIS driver according to instructions in Getting Started.

3. Generate a BYU shell, as described in section 4.5, Configuring NetWare and

PC/TCP over Ethernet and a Packet Driver.

To use NetWare and PC/TCP over the same network interface card, you must

generate a new NetWare IPX shell for the packet driver interface. You can use either an unsupported shell utility from BYU (Brigham Young University), or a supported shell utility from Intel.

You can obtain this software via anonymous FTP from host ftp.ftp.com.

Note: The NetWare shell generation and linker program is called WSHGEN.EXE for NetWare 3.x and later.

4. If you are using Ethernet, modify your CONFIG.SYS file to change the Ethernet packet type so the NDIS driver will accept packets from the NetWare server.

Version 1.30 of the DIS\_PKT.GUP converter program provides an /N option that lets you receive NetWare frames. Add the following line to your CONFIG.SYS file:

```
device=C:\pctcp\dis_pkt.gup /N
```

5. Add commands to your AUTOEXEC.BAT file to automatically load both PC/TCP

and NetWare over an NDIS driver when you boot your PC.

Here is a sample set of commands:

NETBIND.EXE

IPX.COM

VLM.COM

ETHDRV.EXE

For more information about loading the PC/TCP InterDrive NFS client, see section 4.9,

[Loading InterDrive.](#)

4.7 Modifying the Ethernet Frame Type on the NetWare Server

The Ethernet frame type (also referred to as a “packet type”) causes incompatibility between PC/TCP and NetWare. Novell uses IEEE 802.3 Ethernet, but without standard 802.2 headers. PC/TCP uses DIX Ethernet as defined in RFC 894. As shown in Figure 4-5, these two frame types do not carry the same information. For the two systems to communicate, both must recognize the same frame type. You can correct this on the client side or on the server side.



Figure 4-5 Comparison of DIX and 802.3 Ethernet

#### 4.7.1 Modifying the Frame Type on a NetWare Client

From the client side, you can configure the Crynwr packet driver to receive both Novell 802.3 Ethernet packets and DIX packets. Starting with Version 7.1, the Crynwr packet drivers have an -n switch that lets you use the driver without having to change the frame type on NetWare server. If you load the packet driver with the -n option, the driver accepts standard Novell 802.3 Ethernet packets when communicating with workstations running NetWare, or DIX type 8137 packets when communicating with TCP/IP.

## 4.7.2 Modifying the Frame Type through a NetWare 386 Server

This procedure supports NetWare versions 3.1x and later.

To use DIX 8137 type frames with a NetWare 386 server, modify the frame type when

you load the LAN driver. Follow these steps:

1. At the Novell server prompt, enter the load command, specifying the .LAN file for a network interface card installed on the server.
2. Select the appropriate frame type from the list of available frame types displayed by the server software.
3. Bind the LAN drivers to a communication protocol after you modify the frame type. Use the bind command at the NetWare prompt.

This supports a NetWare environment in which all workstations run both PC/TCP and

NetWare 386, using both IP and IPX packets. If you also have workstations on the

network that run NetWare 386 and not PC/TCP, you must configure an additional LAN driver with an IEEE 802.3 frame type. Load the same LAN driver again, this time selecting Ethernet\_802.3 as the frame type.

## 4.8 Using PC/TCP Network Drivers with Other Network Operating Systems

The PC/TCP Network Driver (PCTCPNET.DRV) allows you to access remote files and printing services through the Windows File Manager, Control Panel, and Print Manager.

If you use other network operating systems concurrently with PC/TCP software, these systems must be connected to enable access to each system's services. The configuration of these network operating systems is referred to as "chaining" one network to or from another.

The PC/TCP installation program detects other network operating systems on your system and makes the appropriate changes to the [BOOT] section of your SYSTEM.INI file, as outlined in the following table:

Net SY

wor ST

k E

Op M.

eratINI

ing en

Systri

tem es

(s)

PC/[B

TC O

P O

onl T]

y ne

tw

or

k.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P O

and T]

ano ne

ther tw

net or

wor k.d

k rv

ope =p

rati ctc

ng pn

systet.

em dr

(su v

ch pct

as cp

Novch

ell ain

Net =n

Waret

e) wa

re.

dr

v

PC/[B

TC O

P, O

WinT]

do ne

ws tw

for or

Work.d

kgr rv

oup=w

s, fw

and ne

anot.d

therrv

net se

wor co

k nd

ope ne

rati t.d

ng rv

syst=p

em ctc

(su pn

ch et.

as dr

Novv

ell pct

Net cp

Warch

e) ain

=n

et

wa

re.

dr

v

Note: You should verify that the [386EnH] section does not contain entries for

WFWFTP.386 or VPCTCP.386.Remove (or comment out) these entries if they appear.

## 4.9 Loading InterDrive

This section describes how you can edit your AUTOEXEC.BAT file to automatically load the PC/TCP InterDrive NFS (Network File System) client. The loading procedures differ based on your kernel implementation (TSR or VxD).

To load the InterDrive TSR

The InterDrive TSR is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify that the idrive command appears after the command that loads the PC/TCP TSR kernel in your AUTOEXEC.BAT file.

The following AUTOEXEC.BAT file fragment includes commands that set the path of the PCTCP.INI file, load the PC/TCP TSR kernel for a DIX Ethernet network, and start

InterDrive:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
C:\PCTCP\3C503.COM 0x60 3 0x280
```

```
C:\PCTCP\ETHDRV.EXE
```

```
C:\PCTCP\IDRIVE
```

To load the InterDrive VxD

The InterDrive VxD is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, verify that the vxdinit command appears in your AUTOEXEC.BAT

file before you start Windows. This command starts the VxD kernel and VxD Interdrive

(by default). For example,

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
C:\PCTCP\VXDINIT
```

For more information on using the InterDrive client program, refer to Using PC/TCP in

Windows Chapter 6, Sharing Network Files.

## 4.10 Related Information About Installing PC/TCP with NetWare

For more information about configuring PC/TCP with Novell NetWare, refer to the

following sources:

TopiSo

c urc

e

Inst Ge

allin ttin

g g

PC/ Sta

TC rte

P d

with

a

Pac

ket

Driv

er.

Inst Do

allincu

g me

and nta

conftio

igurin

ng su

Net ppli

Wared

e. wit

h

yo

ur

dist

rib

uti

on

of

No

vell

Net

Wa

re

ConNet

figu Wa

ring re

Eth 38

ern 6

et Sy

fra ste

me ms

typeAd

s. mi

nist

rati

on

Gui

de

## Chapter 4 Installing PC/TCP with Novell NetWare

### 4.1 Before You Install PC/TCP with Novell NetWare

### 4.2 Configuring NetWare and PC/TCP over ODI Drivers

#### 4.2.1 Before You install PC/TCP over ODI Drivers

#### 4.2.2 Configuring NetWare and PC/TCP to Run over ODI Drivers — Procedure

### 4.3 Configuring NetWare and PC/TCP over Token Ring and ASI Drivers

### 4.4 Configuring NetWare/IP over PC/TCP

#### 4.4.1 Before You Configure PC/TCP LWPE to Work over NetWare/IP

#### 4.4.2 Configuring PC/TCP LWPE to Work over NetWare/IP — Procedure

### 4.5 Configuring NetWare and PC/TCP over Ethernet and a Packet Driver

### 4.6 Configuring PC/TCP and NetWare over NDIS Drivers

### 4.7 Modifying the Ethernet Frame Type on the NetWare Server

4.7.1 Modifying the Frame Type on a NetWare Client

4.7.2 Modifying the Frame Type through a NetWare 386 Server

4.8 Using PC/TCP Network Drivers with Other Network Operating Systems

4.9 Loading InterDrive

4.10 Related Information About Installing PC/TCP with NetWare

## Chapter 5

### Installing PC/TCP with LAN Manager

LAN Manager is a network operating system used by many network products such as 3Com 3+Open, AT&T StarGROUP, the Hewlett-Packard LAN Manager, and others. You can use PC/TCP together with any of these LAN Manager products.

The PC-210 kernel lets you use both LAN Manager and PC/TCP over Network Driver Interface Specification (NDIS) drivers. This lets PC/TCP and a LAN Manager product work together over network topologies based on IEEE 802.3 Ethernet, DIX Ethernet, and 802.5 Token Ring.

PC/TCP is compatible with LAN Manager with NDIS3 (and NDIS2) drivers.

PC/TCP provides TCP transport and RFC NETBIOS transport in both TSR (terminate-and-stay-resident) and VxD (Windows virtual device driver) implementations.

To configure LAN Manager with PC/TCP, you must first configure LAN Manager and

PC/TCP to run over NDIS drivers.

If you need to support NETBIOS services over a router, follow the additional

configuration instructions in section 3.5, [Configuring Windows for Workgroups to Use](#)

[PC/TCP NetBIOS](#).

Using this chapter, you can learn the following:

- How to configure LAN Manager (and NETBEUI) over NDIS drivers without

[PC/TCP NetBIOS](#).

This configuration supports NETBIOS services using LAN Manager NETBEUI only. It

does not use PC/TCP NetBIOS. Use this configuration with systems that do not need

to support NETBIOS services across a router (that is, if all NETBIOS traffic is on a

single LAN).

- How to configure LAN Manager with PC/TCP NetBIOS.

These configurations provide RFC NETBIOS functionality over a router.

You can configure your system to use NETBEUI and PC/TCP NetBIOS (TCP/IP) in

parallel, or you can configure LAN Manager to use PC/TCP NetBIOS instead of

NETBEUI.

To verify your installation, refer to Getting Started Chapter 1, [Installing PC/TCP](#)

[Software](#).

## 5.1 Before Configuring PC/TCP with LAN Manager

Verify LAN Manager connectivity over NDIS drivers before you install PC/TCP.

This chapter assumes that you are configuring your system with NDIS2 drivers.

Note: You do not need to reinstall LAN Manager if it is already configured on your system.

For more information about how to install LAN Manager over NDIS drivers, see the LAN Manager technical documentation.

## 5.2 Configuring PC/TCP with LAN Manager over an NDIS Driver

With this configuration, the LAN Manager stack sends NETBEUI packets and the

PC/TCP stack sends IP packets. Figure 5-1 illustrates the protocol layers using

PC/TCP with LAN Manager over an NDIS2 driver.




Figure 5-1 Using PC/TCP and a LAN Manager over an NDIS Driver

Note: This chapter assumes that you are configuring your system with NDIS2 drivers.

When you configure PC/TCP to use NDIS2 drivers, you must load the DIS\_PKT.GUP

packet-driver-converter after you load the packet driver and before you load the

PC/TCP kernel.

PC/TCP and LAN Manager installation programs both modify these system initialization

files:

- AUTOEXEC.BAT
- CONFIG.SYS
- PROTOCOL.INI

If you are using LAN Manager in Windows, you should also review your SYSTEM.INI

file.

Before you proceed, you should verify that each of these files is correct.

To verify your configuration, make sure that your kernel is loaded and that you have

established connectivity by using the ping command. For more information, refer to

Getting Started Chapter 1, [Installing PC/TCP Software.](#)

To review the AUTOEXEC.BAT file

Examine your AUTOEXEC.BAT file to verify that the PC/TCP kernel loads before you start the network (net start workstation).

This example illustrates using the PC/TCP Ethernet TSR kernel (ETHDRV.EXE):

```
c:\windows;c:\;c:\dos;c:\pctcp
```

```
set pctcp=c:\pctcp\pctcp.ini
```

```
ethdrv
```

```
rem ===== lanman 2.2 === do not modify between these lines === lanman 2.2 ===
```

```
set path=c:\lanman.dos\netprog;%path%
```

```
load netbeui
```

```
net start workstation
```

```
rem ===== lanman 2.2 == do not modify between these lines === lanman 2.2 ===
```

To load the PC/TCP VxD kernel, replace ethdrv in the preceding example with vxdinit

```
c:\windows;c:\;\c:\dos;c:\pctcp
```

```
set pctcp=c:\pctcp\pctcp.ini
```

```
vxdinit
```

```
rem ===== lanman 2.2 === do not modify between these lines === lanman 2.2 ===
```

```
set path=c:\lanman.dos\netprog;%path%
```

```
load netbeui
```

```
net start workstation
```

```
rem ===== lanman 2.2 == do not modify between these lines === lanman 2.2 ===
```

Note: This example does not load PC/TCP NetBIOS. It assumes that vnebp=no in the

[pctcp vxdinit] section of your PCTCP.INI file. (This is the default.)

For detailed procedures for loading PC/TCP NetBIOS and the PC/TCP Interdrive NFS

client, see section 5.4, Loading InterDrive.

To review the CONFIG.SYS file

Examine your CONFIG.SYS file to verify that these device statements appear in the proper sequence.

In this configuration, you load LAN Manager over NETBEUI, and you do not need to run the NDIS driver program NETBIND. Loading NETBEUI performs the NETBIND operation automatically.

This is a sample of relevant entries in your CONFIG.SYS file:

```
DEVICE=C:\LANMAN\PROTMAN.DOS /I:C:\LANMAN
```

```
DEVICE=C:\LANMAN\SMARTND.DOS
```

```
DEVICE=C:\PCTCP\DIS_PKT.GUP
```

If you are using NDIS3, drivers delete the DIS\_PKT.GUP device statement.

To review the PROTOCOL.INI file

Examine the PROTOCOLS section of the PROTOCOL.INI file and verify that it includes the appropriate driver section (such as [PKTDRV] ) with the appropriate network driver and binding. For example,

```
[PKTDRV]
```

```
drivename=PKTDRV$
```

```
BINDINGS=MS$ELNKII
```

```
intvec=0X60
```

```
chainvec=0x65
```

Where BINDINGS= identifies the name of the LAN Manager driver section in this file.

Note: BINDINGS must be capitalized, and there should be no spaces around the equals sign.

To review your SYSTEM.INI file

If you are using LAN Manager and PC/TCP in Windows, you should verify that your

SYSTEM.INI file contains these entries:

This section Has this entry

```
[386Enh]    TimerCriticalSection=5000
```

```
[boot]      network.driv=lanman22.driv
```

Note: The PC/TCP installation program replaces the existing network driver with its own network driver. If you want to make connections with LAN Manager, you must specify the LAN Manager driver instead. Use a semicolon to comment out any other networkdrv= statements in the file.

### 5.2.1 Using PC/TCP Network Drivers with Other Network Operating Systems

The PC/TCP Network Driver (PCTCPNET.DRV) allows you to access remote files and printing services through the Windows File Manager, Control Panel, and Print Manager.

If you use other network operating systems concurrently with PC/TCP software, these systems must be connected to enable access to each system's services. The configuration of these network operating systems is referred to as "chaining" one network to or from another.

The PC/TCP installation program detects other network operating systems on your system and makes the appropriate changes to the [BOOT] section of your SYSTEM.INI file, as outlined in the following table:

Net SY

wor ST

k E

Op M.

eratINI

ing en

Systri

tem es

(s)

PC/[B

TC O

P O

onl T]

y ne

tw

or

k.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P O

and T]

ano ne

ther tw

net or

wor k.d

k rv

ope =p

rati ctc

ng pn

systet.

em dr

(su v

ch pct

as cp

LA ch

N ain

Ma =l

nag an

er) m

an

21

.dr

v

Note: You should verify that the [386EnH] section does not contain entries for

WFWFTP.386 or VPCTCP.386. Remove (or comment out) these entries if they appear.

### 5.3 Configuring PC/TCP and LAN Manager to Use PC/TCP NetBIOS

Configuring LAN Manager with PC/TCP NetBIOS gives you RFC NETBIOS

functionality over routers.

PC/TCP NetBIOS can communicate only with other systems that also have versions of NetBIOS that comply with RFC 1001 and RFC 1002.

Note: The PC/TCP NetBIOS VxD cannot run in parallel with the NETBEUI TSR. To configure NetBIOS and NETBEUI in parallel, you must configure the PC/TCP TSR kernel.

You can configure LAN Manager to use PC/TCP NetBIOS in two ways:

- With PC/TCP NetBIOS and LAN Manager NETBEUI in parallel.

Use this configuration to support a non-homogeneous NETBIOS environment. For example, if you need to interoperate with NETBEUI-compatible applications.

- With PC/TCP NetBIOS instead of Windows for Workgroups NETBEUI.

This configuration is most efficient if you do not need to interoperate with NETBEUI-compatible applications. Using this configuration, you can reclaim memory that was reserved for NETBEUI.

Note: In general, the default PC/TCP NetBIOS configuration is adequate for most operating environments. If necessary, you can customize PC/TCP NetBIOS by editing the [pctcp netbios] section of the PC/TCP configuration file (PCTCP.INI). For more information, see Chapter 8, [Configuring NetBIOS](#).

After you are satisfied that these files are correct, you can configure PC/TCP NetBIOS and boot your system.

### 5.3.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

You can use LAN Manager and PC/TCP simultaneously through NetBIOS. The

NetBIOS application program interface (API) is standard with PC/TCP. It provides a

session layer interface that lets a LAN Manager product communicate with the PC/TCP

kernel.

Before you begin, follow the steps in section 5.2, Configuring PC/TCP with LAN

Manager over an NDIS Driver.

Figure 5-2 illustrates the protocol stack when you configure LAN Manager (NETBEUI)

and PC/TCP NetBIOS in parallel. Using this configuration, you can support a non-

homogeneous NETBIOS environment. LAN Manager sends/receives NETBIOS traffic

via

- RFC NETBIOS (using PC/TCP NetBIOS), and

- NETBEUI (using LAN Manager).



Figure 5-2 LAN Manager (NETBEUI) and PC/TCP NetBIOS in Parallel

Follow these steps to edit your system initialization files to use PC/TCP NetBIOS with

Windows for Workgroups(NETBEUI) in parallel:

1. Add a line to your AUTOEXEC.BAT file to load PC/TCP NetBIOS.

Load PC/TCP NetBIOS before you start the network (net start workstation) and after

you load the PC/TCP kernel.

Do not attempt to load NetBIOS within a DOS Windows session. Load NetBIOS before

you load Windows.

If you are using InterDrive, you must start the workstation (and log in, if you are using

user security) before you load InterDrive. For more information about loading

InterDrive, see Using PC/TCP in DOS Chapter 7, Sharing Network Files with

InterDrive.

This example loads the PC/TCP DIX Ethernet TSR kernel and the PC/TCP NetBIOS

TSR (NETBIOS.COM):

```
C:\WINDOWS\NET START
```

```
C:\PCTCP\ETHDRV
```

```
C:\PCTCP\NETBIOS.COM
```

```
C:\WINDOWS\NET START WORKSTATION
```

2. Revise entries in your PROTOCOL.INI file to use PC/TCP NetBIOS.

In the [network.setup] section, change the lana0 entry to lana n, where n is the next

available adapter number. For example,

```
[network.setup]
```

```
lanabase=ms$lnk3,1,ms$netbeui
```

In the [ms\$netbeui] section, change LANABASE=0 to LANABASE= n, where n is the same number as the adapter number specified in the [network.setup] section. For example,

```
[ms$netbeui]
```

```
lanabase=2
```

3. If you are using a version of LAN Manager prior to 2.1, edit the net1= parameter in your LANMAN.INI file to specify PC/TCP NetBIOS:

```
net1=netbios$, 0
```

4. Revise entries in your PCTCP.INI file to configure PC/TCP NetBIOS.

If you need to support NETBIOS access over routers, you must configure PC/TCP

NetBIOS to specify a name file and a broadcast file (using the namefile= and broadcastfile= parameters in the [pctcp netbios] section of your PCTCP.INI file). For

example,

```
[netbios]
```

```
namefile=c:\pctcp\namefile.txt
```

```
broadcastfile=c:\pctcp\broadcast.txt
```

Where namefile.txt and broadcast.txt contain entries that identify NETBIOS hosts beyond your local LAN.

For more information about customizing your NetBIOS configuration, see Chapter 8,

### Configuring NetBIOS.

Note: When you configure your system to use PC/TCP NetBIOS, you may need to configure the kernel with additional TCP connections. As a general rule, one NetBIOS

session requires one TCP connection. For a detailed procedure for configuring the

kernel with additional TCP connections, see section 13.3.3, Adjusting the Number of

TCP and UDP Connections.

### 5.3.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

This configuration lets you use PC/TCP NetBIOS instead of LAN Manager (NETBEUI).

Figure 5-3 illustrates the layering of the software stack.




Figure 5-3 LAN Manager with PC/TCP NetBIOS (only)

Follow these steps to configure your system to use PC/TCP NetBIOS (instead of NETBEUI):

1. Follow the steps for configuring your system with Windows for Workgroups over

NDIS drivers. For more information, see section 5.2, Configuring PC/TCP with LAN

Manager over an NDIS Driver.

2. Follow the steps for configuring your system to use PC/TCP NetBIOS. For more information, see section 5.3.1, Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel.

3. Edit your system initialization files to remove references to NETBEUI, and to replace it with PC/TCP NetBIOS.

To edit the AUTOEXEC.BAT file

Examine your AUTOEXEC.BAT file and, if necessary, modify the file to remove lines that load LAN Manager's reference NETBEUI.

This sample AUTOEXEC.BAT file illustrates using PC/TCP NetBIOS with the Ethernet

TSR kernel (ETHDRV):

```
set pctcp=c:\pctcp\pctcp.ini
```

```
ethdrv
```

netbios.com

rem === lanman 2.2 === do not modify between these lines === lanman 2.2 =====

set path=c:\lanman.dos\netprog;%path%

rem load netbeui

net start workstation

rem === lanman 2.2 === do not modify between these lines === lanman 2.2 =====

To edit the PROTOCOL.INI file

Revise entries in your PROTOCOL.INI file to remove references to NETBEUI.

1. In the [network.setup] section, remove ms\$netbeui from the lana n = entry. For

example,

```
[network.setup]
```

```
; lana2=ms$lnk3,1,ms$netbeui
```

lana2=ms\$elnk3,1

2. Remove the [ms\$netbeui] section.

To edit the LANMAN.INI file

You can use the adapter= parameter in the PCTCP.INI file to configure NetBIOS to use

the alternative 0x2A interrupt interface (in addition to the 0x5C default interrupt

interface). This option lets you remove MINSES.EXE from the LAN Manager network

services list (thus saving approximately 2K of conventional memory).

To remove MINSES.EXE from your LAN Manager network services list, edit your

LANMAN.INI file to delete minses from the netservices= entry.

To edit the SYSTEM.INI file

If you are using LAN Manager in Windows, edit the netmisc= and transport=

parameters in the [386Enh] section to remove references to NETBEUI.

## 5.4 Loading InterDrive

The InterDrive TSR is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify that the idrive command appears after the

command that loads the PC/TCP kernel in your AUTOEXEC.BAT file. The loading

procedures differ based on your kernel implementation (TSR or VxD).

The following AUTOEXEC.BAT file fragment includes commands that set the path of

the PCTCP.INI file, load the PC/TCP TSR kernel for a DIX Ethernet network, and start

InterDrive:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
C:\PCTCP\3C503.COM 0x60 3 0x280
```

```
C:\PCTCP\ETHDRV.EXE
```

C:\PCTCP\IDRIVE

To load the InterDrive VxD

The InterDrive VxD is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify the vxdinit command appears in your

AUTOEXEC.BAT file before you start Windows. This command starts the VxD kernel

and VxD InterDrive (by default). For example,

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
VXDINIT +n +i
```

Alternatively, you can use the vxdinit command without command line options, and set

vn bep=yes, and vidrive=yes (the default) in the [pctcp vxdinit] section of your

PCTCP.INI configuration file.

## 5.5 Related Information About Installing PC/TCP with LAN Manager

For more information about installing PC/TCP with LAN Manager, see the following

sources:

TopiSo

c urc

e

Inst Do

allincu

g me

LA nta

N tion

Ma sup

nag plie

er. d

wit

h

you

r

dist

rib

utio

n

of

LA

N

Ma

na

ger

SettCh

ing apt

Net er

BIO 8,

S Co

confnfig

igur uri

atio ng

n Net

opti BI

ons OS

in

the

PC

TCP

.INI

conf

igur

atio

n

file.

Usi Usi

ng ng

the PC

Inte /TC

rDri P

ve in

clie Wi

nt nd

pro ow

gra s

m. Ch

apt

er

6,

Sh

ari

ng

Net

wor

k

File

s

## Chapter 5 Installing PC/TCP with LAN Manager

### 5.1 Before Configuring PC/TCP with LAN Manager

### 5.2 Configuring PC/TCP with LAN Manager over an NDIS Driver

#### 5.2.1 Using PC/TCP Network Drivers with Other Network Operating Systems

### 5.3 Configuring PC/TCP and LAN Manager to Use PC/TCP NetBIOS

#### 5.3.1 Configuring Your System to Use PC/TCP NetBIOS and NETBEUI in Parallel

#### 5.3.2 Configuring Your System to Use PC/TCP NetBIOS (instead of NETBEUI)

### 5.4 Loading InterDrive

#### 5.5 Related Information About Installing PC/TCP with LAN Manager

## Chapter 6

### Installing PC/TCP with Banyan VINES

VINES is the network operating system developed by Banyan Systems, Inc. FTP

Software, Inc. and Banyan have cooperated to produce versions of PC/TCP and

VINES that are completely compatible.

PC/TCP requires Banyan VINES version 2.10 or greater.

Using the procedures in this chapter, you can configure your system to

- Use the PC/TCP EBANYAN kernel to run over Banyan Ethernet.
- Use the PC/TCP IBANYAN kernel to send encapsulated IP packets within VINES

transport services.

- Use the PC/TCP ETHDRV or IEEEEDRV kernel and VINES with an NDIS

(Network Driver Interface Specification) driver.

- Use the PC/TCP IBMTR kernel and VINES over Token Ring with an ASI (Adapter

Support Interface) driver.

With any of these schemes, you can alternate between VINES services and PC/TCP applications without rebooting your PC.

Use the procedures in this chapter to verify your configuration.

## 6.1 Before You Install PC/TCP with Banyan VINES

Before you install PC/TCP with VINES, you or your system administrator should ensure that

- Banyan VINES software version 2.10 or greater is loaded on both the PC and the file server.
- A network interface card and drivers supported by the VINES are installed.
- The Banyan ban command has been run on this PC to initialize the interface with the VINES driver. Refer to the documentation provided by Banyan Systems.
- You follow the steps in Getting Started for installing PC/TCP. The installation program automatically detects your network drivers and edits your initialization files appropriately.

## 6.2 Installing PC/TCP with Banyan Ethernet

FTP Software and Banyan support a PC/TCP kernel (EBANYAN) that lets VINES and PC/TCP share a single Ethernet network interface card. With this configuration you can use PC/TCP to access TCP/IP services and VINES to access VINES services.

For this configuration, you must have Banyan VINES (version 2.10 or later) loaded on both the PC and the file server.

Figure 6-1 illustrates the general layering of a Banyan Ethernet driver within the

PC/TCP architecture.




Figure 6-1 Layering of a Banyan Ethernet Driver with PC/TCP

Follow these steps to verify your system configuration:

This procedure shows how to configure your system to run the PC/TCP kernel to run Banyan VINES over Ethernet.

1. Examine the AUTOEXEC.BAT file to ensure that it loads the appropriate Banyan VINES drivers and the PC/TCP kernel.

This example shows how to load the EBANYAN.EXE PC/TCP TSR kernel:

```
set path=c:\pctcp;%path%
```

```
set pctcp=c:\pctcp\pctcp.ini
```

```
cd \drivers\banyan
```

```
ban
```

```
cd \
```

```
ebanyan
```

To instruct Windows to load the PC/TCP VxD kernel instead, replace the ebanyan

statement with

```
vxdinit
```

This loads the VxD kernel when you start Windows.

Note: This assumes that you have set the appropriate network frame-type and interface-type in the [pctcp ifcust 0] section of your PCTCP.INI file.

2. Examine your PCTCP.INI configuration file to ensure that it includes entries describing your kernel and network interface.

Verify that the [pctcp ifcust 0] section specifies the appropriate IP addresses and subnet mask. For example,

```
[pctcp ifcust 0]
```

```
ip-address = 128.127.50.100
```

```
subnet-mask = 255.255.255.0
```

router = 128.127.50.6

To configure the PC/TCP VxD kernel you must also specify the appropriate network

frame-type and interface-type.

frame-type=DIX-Ethernet

interface-type=EBANYAN

Verify that the [pctcp kernel] section identifies the appropriate network interface section

in the PCTCP.INI file. For example,

[pctcp kernel]

interface=ifcust 0

The CONFIG.SYS file is not modified for this configuration.

### 6.3 Tunneling TCP/IP Packets within VINES Transport

The IBANYAN kernel developed by FTP Software and Banyan Systems encapsulates PC/TCP network packets within VINES network packets. This product lets PC/TCP and VINES run concurrently on any media supported by VINES (such as DIX Ethernet or IEEE 802.5 Token Ring).

Encapsulated PC/TCP is only available from Banyan Systems under a server-based license. For information about installing this software, refer to your Banyan Systems documentation. For this installation, you must have Banyan VINES (version 3.0 or later) loaded on both the PC and the file server.

- The IBANYAN kernel encapsulates TCP/IP packets within VINES packets and transports them between the network and the PC/TCP applications.
- The Banyan redirector passes the IP packets over the VINES network to the VINES

server specified in the PCTCP.INI file. The VINES server then routes the TCP/IP packets to their final destination. It also allows communication between the PC/TCP stack and the VINES services.

Figure 6-2 illustrates the protocol stack with a Banyan driver and the IBANYAN kernel.




Figure 6-2 PC/TCP Running over a VINES Redirector

This procedure describes how to configure your system with the PC/TCP kernel running over a BANYAN VINES redirector.

1. Examine the AUTOEXEC.BAT file to ensure that it loads the appropriate Banyan

VINES drivers and the PC/TCP kernel:

This example shows how to load the IBANYAN TSR kernel:

```
set path=c:\pctcp;%path%
```

```
set pctcp=c:\pctcp\pctcp.ini
```

```
cd \drivers\banyan
```

```
ban
```

```
cd \
```

```
ibanyan
```

To instruct Windows to load the PC/TCP VxD kernel instead, replace the `ibanyan`

statement with

```
vxdinit
```

This loads the VxD kernel when you start Windows.

Note: This assumes that you have set the appropriate network frame-type and

interface-type in the [pctcp ifcust 0] section of your PCTCP.INI file.

2. Examine your PCTCP.INI configuration file to ensure that it includes entries describing your kernel and network interface.

AddTo

the sp

se eci

stat fy

em thi

ent s

s

[pct  
Th

cp  
e

iba na

nya me

n] of

bse the

rverBa

=m ny

yse an

rverser

ver

.

[pct Th

cp e

ifcu IP

st ad

0] dre

ss,

su

ip- bn

add et-

res ma

s = sk,

128 an

.12 d

7.5 rou

0.1 ter

00 ad

sub dre

net-ss.

ma For

sk mo

= re

255 inf

.25 or

5.2 ma

55. tio

0 n

routab

er =out

128 co

.12 nfi

7.5 gur

0.6 ing

fra yo

me-ur

typ IP

e=i an

band

yan rou

inter

rfacad

e- dre

typ ss

e=i es,

banse

yan e

the

Ba

ny

an

TC

P/I

P

Gu

ide

.

Th

e

net

wo

rk

fra

me

an

d

int

erf

ac

e

typ

es

(if

yo

u

are

usi

ng

the

PC

/T

CP

Vx

D).

[pct Th

cp e

ker PC

nel] TC

inte P.I

rfac NI

e=if file

cus se

t 0 cti

on

tha

t

de

scr

ibe

s

thi

s

ker

nel

int

erf

ac

e.

## 6.4 Using an NDIS Ethernet Driver with PC/TCP

One way to use PC/TCP and VINES together is with an NDIS driver. The NDIS driver provides a common interface that both PC/TCP and VINES can use over a single network card. With this scheme, data does not have to go through a VINES server or router to access other TCP/IP hosts. Your PC transmits TCP/IP packets with no VINES encapsulation.

This installation requires Banyan VINES (version 4.1 or later) loaded on both the PC and the file server.

PC/TCP is compatible with NDIS3 and NDIS2 drivers. NDIS drivers are available from your interface card supplier. In addition, FTP Software, Inc. has a repository of NDIS drivers available via anonymous FTP from the host <ftp.ftp.com> in the subdirectory /NDIS.

Before you begin, you should refer to the VINES technical documentation to configure the ban driver to use NDIS drivers.

Figure 6-3 illustrates the protocol stack when you configure the NDIS driver with VINES

and PC/TCP.




Figure 6-3 PC/TCP and VINES with an NDIS Driver

Follow these steps to configure the DIX Ethernet kernel and NDIS drivers:

1. Examine the AUTOEXEC.BAT file to ensure that it loads the appropriate Banyan

VINES drivers and the PC/TCP kernel.

This example shows how to load the DIX Ethernet PC/TCP TSR kernel:

```
set path=c:\pctcp
```

```
set PCTCP=c:\pctcp\pctcp.ini
```

```
cd \drivers\banyan
```

```
ban
```

```
cd \
```

```
ethdrv
```

Note: You do not need the NETBIND program. The VINES ban command performs the same function as NETBIND.

To instruct Windows to load the PC/TCP VxD kernel instead, replace the ethdrv statement with vxdinit.

This loads the VxD kernel when you start Windows.

Note: This assumes that you have set the appropriate network frame-type and

interface-type in the [pctcp ifcust 0] section of your PCTCP.INI file.

2. Examine your PCTCP.INI configuration file to ensure that it includes entries describing your kernel and network interface.

Verify that the [pctcp ifcust 0] section specifies the appropriate IP addresses and subnet mask. For example,

```
[pctcp ifcust 0]
```

```
ip-address = 128.127.50.100
```

```
subnet-mask = 255.255.255.0
```

```
router = 128.127.50.6
```

To configure the PC/TCP VxD kernel, you must also specify the appropriate network

frame-type (IEEE, DIX-Ethernet, or Token-Ring) and interface-type(PKTDRV).

```
frame-type=IEEE
```

```
interface-type=PKTDRV
```

Verify that the [pctcp kernel] section identifies the appropriate network interface section

in the PCTCP.INI file. For example,

```
[pctcp kernel]
```

```
interface=ifcust 0
```

Note: The installation procedure does not modify your CONFIG.SYS or

PROTOCOL.INI files.

## 6.5 Using VINES with the PC/TCP Token Ring Kernel

Banyan Systems makes a version of VINES that runs over the implementation of the

ASI specification for Token Ring. You can use this with the FTP Software IBMTR 802.5

kernel to let PC/TCP and VINES run simultaneously over Token Ring.

- The IBM LAN Support program ASI provides an interrupt arbitrator and a device

driver to provide communication between the IBMTR kernel and the Token Ring

network card.

- The IBMTR kernel is designed to run over the IBM LAN Support program to allow

communication between the PC/TCP applications and connecting hosts on the Token

Ring network.

Before you begin, you should refer to the VINES technical documentation to configure

the BAN driver to use TOKUIBAN.

Figure 6-4 illustrates how PC/TCP and VINES coexist with the ASI drivers and Token

Ring.




Figure 6-4 VINES over an ASI Driver

Follow these steps to configure the IBM Token Ring (IBMTR) kernel:

1. Examine the AUTOEXEC.BAT file to ensure that it loads the appropriate drivers and the PC/TCP kernel.

This example shows how to load the IBM Token Ring PC/TCP TSR kernel:

```
set path=c:\pctcp
```

```
set PCTCP=c:\pctcp\pctcp.ini
```

```
cd \drivers\banyan
```

```
ban
```

```
cd \
```

```
ibmtr
```

To instruct Windows to load the PC/TCP VxD kernel instead, replace the `ibmtr`

statement with

```
vxdinit
```

This loads the VxD kernel when you start Windows.

Note: This assumes that you have set the appropriate network frame-type and

interface-type in the `[pctcp ifcust 0]` section of your `PCTCP.INI` file.

2. Examine the `PCTCP.INI` file to ensure that it configures the kernel and the IBMTR

kernel interface.

Add To

thes sp

e ec

stateify

mentthi

s s

[pctc Th

p e

kern ke

el] rn

seriael

I- co

num nfi

ber gu

= rat

your io

\_serin.

al\_n

umb

er

auth

entic

ation

-

key=

your

\_aut

henti

catio

n\_ke

y

interf

ace

=ibm

tr 0

wind

ow =

2048

low-

wind

ow =

0

[pctc Th

p e

ifcus Vx

t 0] D

fram ke

e- rn

type el

=IB int

MTRerf

interfac

ace- e.

type

=IB

MTR

[pctc Th

p e

ibmtrIB

0] M

ip- T

addr R

ess=ke

128. rn

127. el

50.1 int

broa erf

dcas ac

t- e

addr ch

ess= ar

255. ac

255. ter

255. ist

255 ic

rout s.

er=1 S

28.1 ub

27.5 sti

0.6 tut

subne

et- th

mas e

k=25ad

5.25 dr

5.25 es

5.0 se

s,

su

bn

et

m

as

k,

et

c.,

as

ap

pr

op

ria

te.

3. Examine the CONFIG.SYS file to verify that it includes the appropriate device drivers.

To run multiple protocols over the IBM LAN Support program, you must allocate an additional Service Access Point (SAP) for each protocol. To do this:

- Add device statements to load the parts of the IBM LAN Support program:

DXMA0MOD.SYS, DXMC0MOD.SYS, DXMT0MOD.SYS.

- Set the Extra SAPs variable to add Service Access Points for each protocol that you are running.

You must load the DXMT0MOD.SYS driver with the Extra SAPs (ES) variable set to a number greater than or equal to the number of protocols used.

To set the ES variable, use a text editor to add a line to your CONFIG.SYS file in the following form, after loading the interrupt arbitrator (DXMA0MOD.SYS):

```
device= drive:\directory\dxmt0mod.sys ES= n
```

where n stands for the number of additional SAPs that you want to allocate.

This is a sample section of your CONFIG.SYS file:

```
device=c:\asi\dxma0mod.sys
```

```
device=c:\asi\dxmc0mod.sys
```

```
device=c:\asi\dxmt0mod.sys ES=2
```

## 6.6 Loading InterDrive

This section describes how you can edit your AUTOEXEC.BAT file to automatically load

PC/TCP InterDrive NFS client. The loading procedures differ based on your kernel

implementation (TSR or VxD).

To load the InterDrive TSR

The InterDrive TSR is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify that the AUTOEXEC.BAT file loads the

appropriate programs in the appropriate order. The loading procedures differ based on

your kernel implementation (TSR or VxD).

Before you proceed, you should verify that the idrive command appears after the

command that loads the PC/TCP kernel in your AUTOEXEC.BAT file.

The following AUTOEXEC.BAT file fragment includes commands that set the path of

the PCTCP.INI file, load the PC/TCP TSR kernel for a DIX Ethernet network, and start

InterDrive:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
C:\PCTCP\3C503.COM 0x60 3 0x280
```

```
C:\PCTCP\ETHDRV.EXE
```

```
C:\PCTCP\IDRIVE
```

To load the InterDrive VxD

The InterDrive VxD is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify the vxdinit command appears in your

AUTOEXEC.BAT file before you start Windows. This command starts the VxD kernel

and VxD Interdrive (by default). For example,

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
VXDINIT
```

For more information on using the InterDrive client program, refer to Using PC/TCP in

Windows Chapter 6, [Sharing Network Files](#).

## 6.7 Using PC/TCP Network Drivers with Other Network Operating Systems

The PC/TCP Network Driver (PCTCPNET.DRV) allows you to access remote files and printing services through the Windows File Manager, Control Panel, and Print Manager.

If you use other network operating systems concurrently with PC/TCP software, these systems must be connected to enable access to each system's services. The configuration of these network operating systems is referred to as "chaining" one network to or from another.

The PC/TCP installation program detects other network operating systems on your system and makes the appropriate changes to the [BOOT] section of your SYSTEM.INI file, as outlined in the following table:

Net SY

wor ST

k E

Op M.

eratINI

ing en

Systri

tem es

(s)

PC/[B

TC O

P O

onl T]

y ne

tw

or

k.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P O

and T]

ano ne

ther tw

net or

wor k.d

k rv

ope =p

rati ctc

ng pn

systet.

em dr

(su v

ch pct

as cp

Banch

yan ain

VIN=vi

ES)ne

s.d

rv

PC/[B

TC O

P, O

WinT]

do ne

ws tw

for or

Work.d

kgr rv

oup=w

s, fw

and ne

anot.d

therrv

net se

wor co

k nd

ope ne

rati t.d

ng rv

syst=p

em ctc

(su pn

ch et.

as dr

Banv

yan pct

VIN cp

ES) ch

ain

=vi

ne

s.d

rv

Note: You should verify that the [386EnH] section does not contain entries for

WFWFTP.386 or VPCTCP.386. Remove (or comment out) these entries if they appear.

## 6.8 Related Information About Installing PC/TCP with VINES

For more information about installing PC/TCP with VINES, refer to the following

sources:

TopSou

ic rce

InstBan

alli yan

ng VIN

the ES

Ba doc

nyaum

n ent

VINatio

ES n

soft

war

e.

IP VIN

addES

res TC

sin P/I

g P

andOpt

rou tion

ing Gui

pac de

ket

s

acr

oss

net

wor

ks.

## Chapter 6 Installing PC/TCP with Banyan VINES

### 6.1 Before You Install PC/TCP with Banyan VINES

### 6.2 Installing PC/TCP with Banyan Ethernet

### 6.3 Tunneling TCP/IP Packets within VINES Transport

### 6.4 Using an NDIS Ethernet Driver with PC/TCP

### 6.5 Using VINES with the PC/TCP Token Ring Kernel

### 6.6 Loading InterDrive

### 6.7 Using PC/TCP Network Drivers with Other Network Operating Systems

### 6.8 Related Information About Installing PC/TCP with VINES

## Chapter 7

### Installing PC/TCP with PATHWORKS

PATHWORKS is a network operating system produced by Digital Equipment Corporation. This network operating system works on top of DECnet protocols as well as supporting other protocol implementations, such as TCP/IP. This chapter discusses how to install PC/TCP with PATHWORKS and a network interface card supplied by Digital Equipment Corporation.

Using procedures in this chapter, you can

- Load and configure the appropriate scheduler and DLL driver software.
- Install and configure the PC/TCP DEPCA kernel.

Note: PC/TCP supports a DEPCA TSR kernel only. (PC/TCP does not provide a DEPCA VxD kernel.)

Alternatively, you may install PC/TCP with PATHWORKS over NDIS drivers using a

DIX Ethernet kernel. For detailed procedures for installing PC/TCP over NDIS drivers, see Getting Started.

Figure 7-1 illustrates the general layering of a DLL driver within the PC/TCP

architecture using the DEPCA kernel.




Figure 7-1 Layering of a DLL Driver with PC/TCP

The DLL scheduler provides timing services and background multitasking under DOS.

The Data Link Layer (DLL) driver is a software device driver that provides an interface

between the Ethernet controller on the computer and higher software levels. The type

of data link depends on the Ethernet controller. A DLL driver is not included with

PC/TCP; you must supply the DLL driver.

The DEPCA kernel is specially built for use with a Data Link Layer (DLL) driver. The

PC/TCP kernel DEPCA.EXE exchanges data with the DLL driver.

## 7.1 Before Installing the PC/TCP DEPCA Kernel

Ensure that

- You meet all of the requirements in Getting Started.
- PATHWORKS is installed and operational.

## 7.2 Installing PC/TCP to Run with PATHWORKS — Procedure Overview

Follow these steps to configure your system to run PATHWORKS with PC/TCP:

1. Load the scheduler.
2. Load the DLL driver.
3. Install and configure PC/TCP.

### 7.3 Loading the Scheduler for the DLL Driver

The scheduler SCH.EXE is a terminate-and-stay-resident (TSR) program that is loaded into memory once, then remains. The scheduler is included in the STARTNET.BAT file that comes with the DLL driver distribution. If you have a STARTNET.BAT file, and you are going to use it to load the scheduler, make sure the line startnet is in your AUTOEXEC.BAT file. This loads the scheduler automatically every time that you start your system.

If you are not using a STARTNET.BAT file, copy the SCH.EXE that came with your DLL driver distribution into any directory in your path:

```
C:\>copy a:sch.exe
```

Note that the scheduler comes with Digital Equipment Corporation DECnet-DOS and PATHWORKS.

To load the scheduler at system startup

Put a line of the following form in your AUTOEXEC.BAT file:

```
sch /option
```

You can use the following options with the sch command. You can use these options

whether you issue the command from the DOS prompt, the AUTOEXEC.BAT file, or the

STARTNET.BAT file.

**/A** Configures the SCH.EXE timer automatically. The SCH program uses the CMOS

real-time clock if your machine is an IBM PC AT or compatible. Otherwise, the default

is to use the system clock as the timer.

**/H** Selects the hardware timer and uses hardware interrupt 08h, the default of the

STARTNET.BAT file.

**/N** Specifies that the Ethernet vector is not examined for interrupt activity during

loading.

`/S` Specifies that the system clock is used as the timer, without determining the system type.

The following line loads the scheduler from the DOS prompt, and does not examine the

Ethernet vector for interrupt activity:

```
C:\> sch /N
```

## 7.4 Loading the DLL Driver

A DLL driver is a TSR program that is loaded into memory once, then remains. Follow these instructions to load the DLL driver at system startup.

1. Locate the DLL driver on the diskette from your card vendor, or on the PATHWORKS distribution diskettes.

Below is a partial list of DLL drivers for various interface cards:

- DLLDEPCA.EXE
- DLL3C503.EXE
- DLL3C501.EXE
- DLL3C523.EXE
- DLLMICOM.EXE

Select the file that matches the card installed in your system. For example, if you are

using a 3COM 3c503 card, you need the DLL3C503.EXE file.

2. Copy the file to your system and change the name to DLL.EXE.

For example, copy the 3c503 data link file with a command like this:

```
A:\>copy dll3c503.exe C:\pctcp\dll.exe
```

3. To load the DLL driver at system startup, add a line of the following form to your

STARTNET.BAT (or AUTOEXEC.BAT) file:

```
dll /option
```

The /option refers to options that you can use with the DLL driver.

The following are the options that you can use:

/ADAPTER:name Identifies the adapter type.

/D:n Indicates the value set for the DMA channel. Do not change the default DMA

channel unless a conflict exists.

**/FAST** Loads the DLL into conventional memory rather than ROM. This action enhances performance but consumes more memory. This option is specific to the DEPCA interface.

**/IRQ:n** Selects the interrupt channel for the DLL software driver. The value of n should match interrupt number for your interface. Refer to the vendor's technical documentation.

**/M:n** Indicates the type of data transfer used by your computer, where n is the value of the type of data transfer. Use this switch if you have not changed the default jumper setting for the memory base address. This switch is optional; if you do not specify the /M switch, the DLL program selects a suitable default.

**/MEM:address** Specifies the memory base address.

**/PORT:n** Selects the I/O base address for the DLL software driver. The value of n

should match that specified on the settings on the interface card. Refer to the vendor's technical documentation.

/T:n Indicates the transceiver type, where n is either 1 for BNC (thin wire) or 2 for DIX (standard).

Some DLL drivers (such as DLL3C503.EXE) require that you specify this switch. See your card vendor's technical documentation for more information about your DLL driver.

Note: The options may vary, depending on your particular driver software.

## 7.5 Installing and Configuring PC/TCP to Use with PATHWORKS

To install and configure the depca kernel to run with PATHWORKS, follow these steps:

1. Follow all of the installation steps listed in Getting Started Chapter 1, Installing

PC/TCP Software.

2. Examine the resulting PCTCP.INI file and ensure that there is a [pctcp ifcust n]

section similar to this example, substituting the addresses and subnet mask

appropriate for your system. (If you have one card, n is 0; if you have two network

interface cards, the second interface section is 1, and so on.)

```
[pctcp ifcust 0]
```

```
ip-address = 128.127.50.100
```

```
subnet-mask = 255.255.255.0
```

```
router = 128.127.50.6
```

3. Ensure that you have an entry like the following in the [pctcp kernel] section of your PCTCP.INI file:

```
[pctcp kernel]
```

```
interface=ifcust 0
```

Note: If you are familiar with an older version of PC/TCP, and you used the DEPCA kernel, you may have used a [pctcp depca 0] section in the PCTCP.INI file. This changed in PC/TCP version 2.2 to use the [pctcp ifcust 0] section instead.

4. Examine your AUTOEXEC.BAT and ensure that the environment variable is set, as follows:

```
set PCTCP=c:\pctcp\pctcp.ini
```

5. Modify your AUTOEXEC.BAT file to load the scheduler, the DLL driver, and the kernel every time that you start your system. These lines should use the following form:

drive:\path\sch /option

drive:\path\dll /options

drive:\path\DEPCA.EXE

Here is an example:

C:\etc\sch /N

C:\etc\dll /MEM:d000 /IRQ:5 /ADAPTER:DE2000

C:\pctcp\depca.exe

This example illustrates using the DEPCA kernel with the 3Comn 3C503 network

interface card:

c:\drivers\dll\sch.exe

c:\drivers\dll\dll /IRQ:3 /ADAPTER:3c503 /D:1 /T:1

c:\pctcp\depca.exe

6. After you complete these steps, start your system and verify the network connection

by using the ping command as described in Getting Started section 2.1, Using the

PC/TCP Configuration Utility.

## 7.6 Loading InterDrive

This section describes how you can edit your AUTOEXEC.BAT file to automatically load

PC/TCP InterDrive NFS client.

To load the InterDrive TSR

The InterDrive TSR is configured by default when you install the PC/TCP TSR kernel.

Before you proceed, you should verify that the idrive command appears after the

command that loads the PC/TCP kernel in your AUTOEXEC.BAT file.

The following AUTOEXEC.BAT file fragment includes commands that set the path of

the PCTCP.INI file, load the PC/TCP TSR kernel for a DIX Ethernet network, and start

InterDrive:

```
PATH C:\PCTCP
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

C:\PCTCP\3C503.COM 0x60 3 0x280

C:\PCTCP\ETHDRV.EXE

C:\PCTCP\IDRIVE

For more information on using the InterDrive client program, refer to Using PC/TCP in

Windows Chapter 6, [Sharing Network Files](#).

## 7.7 Using PC/TCP Network Drivers with Other Network Operating Systems

The PC/TCP Network Driver (PCTCPNET.DRV) allows you to access remote files and printing services through the Windows File Manager, Control Panel, and Print Manager.

If you use other network operating systems concurrently with PC/TCP software, these systems must be connected to enable access to each system's services. The configuration of these network operating systems is referred to as "chaining" one network to or from another.

The PC/TCP installation program detects other network operating systems on your system and makes the appropriate changes to the [BOOT] section of your SYSTEM.INI file, as outlined in the following table:

Net SY

wor ST

k E

Op M.

eratINI

ing en

Systri

tem es

(s)

PC/[B

TC O

P O

onl T]

y ne

tw

or

k.d

rv

=p

ctc

pn

et.

dr

v

PC/[B

TC O

P O

and T]

ano ne

ther tw

net or

wor k.d

k rv

ope =p

rati ctc

ng pn

systet.

em dr

(su v

ch pct

as cp

PATch

HWain

OR =

KS)ms

ne

t.d

rv

PC/[B

TC O

P, O

WinT]

do ne

ws tw

for or

Work.d

kgr rv

oup=w

s, fw

and ne

anot.d

therrv

net se

wor co

k nd

ope ne

rati t.d

ng rv

syst=p

em ctc

(su pn

ch et.

as dr

PATv

HWpct

OR cp

KS)ch

ain

=

ms

ne

t.d

rv

Note: You should verify that the [386EnH] section does not contain entries for

WFWFTP.386 or VPCTCP.386. Remove (or comment out) these entries if they appear.

## 7.8 Troubleshooting the PC/TCP DEPCA Kernel Installation

Trailers are a nonstandard method of encapsulating data for Ethernet (and ProNET-10) installations. Trailers are often used by 4.2 Berkeley Standard Distribution (BSD) UNIX systems.

DLL drivers offer only eight portals and PC/TCP requires two of them. PC/TCP uses three more portals to support 4BSD UNIX trailer packet formats, if additional ones are available.

If you experience any of the following problems, trailer encapsulation may be the cause:

- An error message about “portals” appears.

A “portals” error message indicates that other software is also using portals, and there are not enough left for PC/TCP to use in supporting trailers.

- FTP get operations are slow, but FTP put operations are not.
- Telnet (tn) screen updates are slow when transferring large amounts of text from a remote host, but local screen updates and character echos occur quickly.

If you experience any of these problems, ask your UNIX system administrator to turn off trailers.

## 7.9 Related Information About Installing PC/TCP with PATHWORKS

Refer to the following documentation for more information about the installation:

TopSou

ic rce

Co Doc

nfigum

urinent

g atio

the n

DE sup

PC plie

A.Cd

OMon

pac the

ket "Su

driv ppo

er. rted

Pac

ket

Driv

er"

disk

.

If

you

are

usi

ng

the

PC/

TC

P

CD-

RO

M

dist

ribu

tion

,

see

the

/CR

WN

YR

sub

dire

ctor

y.

InstThe

alli doc

ng um

a ent

drivatio

er ifn

you sup

are plie

usi d

ng by

drivyou

er r

softinte

warrfac

e e

fro boa

m rd

an ven

intedor

rfac

e

car

d

ven

dor.

InstThe

alli PAT

ng HW

PA OR

TH KS

WOfor

RK DO

S S

for Clie

DO nt

S. Inst

alla

tion

and

Co

nfig

urat

ion

Gui

de

that

is

sup

plie

d

by

you

r

inte

rfac

e

boa

rd

ven

dor.

## Chapter 7 Installing PC/TCP with PATHWORKS

### 7.1 Before Installing the PC/TCP DEPCA Kernel

### 7.2 Installing PC/TCP to Run with PATHWORKS — Procedure Overview

### 7.3 Loading the Scheduler for the DLL Driver

### 7.4 Loading the DLL Driver

### 7.5 Installing and Configuring PC/TCP to Use with PATHWORKS

### 7.6 Loading InterDrive

### 7.7 Using PC/TCP Network Drivers with Other Network Operating Systems

### 7.8 Troubleshooting the PC/TCP DEPCA Kernel Installation

### 7.9 Related Information About Installing PC/TCP with PATHWORKS

## Chapter 8

### Configuring NetBIOS

PC/TCP NetBIOS is a session layer interface for local area networks (LANs) that lets you run applications over a variety of network protocols. It provides wide area connectivity for network operating systems (NOS), such as Microsoft LAN Manager.

Note that unless you plan to run a network operating system that uses the NetBIOS transport protocol, you do not need to load PC/TCP NetBIOS. A NetBIOS host can communicate only with other RFC-compliant hosts.

PC/TCP NetBIOS uses TCP/IP and is fully compliant with RFCs 1001 and 1002, and with the IBM NetBIOS Application Development Guide.

When you run NetBIOS with a compatible network operating system, your PC can

- Share resources with machines both within a LAN and across a TCP/IP network, using options specified in the PCTCP.INI configuration file.

- Interact with non-PC hosts that implement TCP/IP NetBIOS.

With this chapter, you can learn

- What you must do before you can use PC/TCP NetBIOS.
- How the default configuration addresses most user needs.
- How to start NetBIOS.
- How to set PC/TCP NetBIOS configuration options.
- How to tune PC/TCP for NetBIOS.
- What a NETBIOS programmer needs to know about PC/TCP NetBIOS.
- How to troubleshoot NetBIOS.
- Where to find more information about PC/TCP NetBIOS.

## 8.1 Before You Start Using PC/TCP NetBIOS

Perform these tasks before you use PC/TCP NetBIOS:

1. Install, configure, and load your network operating system.
2. Install and configure PC/TCP. (The distribution includes PC/TCP NetBIOS.)

Note: To support your network environment, you may need to configure your PC/TCP

kernel with additional TCP connections. See section 8.6, [Tuning PC/TCP for NetBIOS](#).

3. Verify that any other NetBIOS product that you are using is RFC-compliant and is compatible with PC/TCP NetBIOS (such as LAN Manager).

## 8.2 Using NetBIOS in Windows

PC/TCP provides a NetBIOS TSR (terminate-and-stay-resident program) and a

NetBIOS VxD (virtual device driver). The PC/TCP installation procedures install and

configure the appropriate PC/TCP NetBIOS for your system environment. As a rule, if

you are using the PC/TCP VxD kernel, you are also using the VxD NetBIOS.

Otherwise, you are using the PC/TCP NetBIOS TSR.

Both PC/TCP NetBIOS implementations provide the same functionality. However, some

configuration procedures may differ depending on which implementation is installed.

### 8.3 Configuring NetBIOS

The PC/TCP installation procedure provides a default NetBIOS configuration. In general, this initial configuration is adequate, and you should not need to override the default settings.

You must unload and reload PC/TCP NetBIOS for new configuration option settings to take effect.

The appropriate configuration option settings may differ depending on the characteristics of your PC/TCP operating environment. Before you begin, you should use the Statistics application (or the `inet version` command) to determine the type of kernel (TSR or VxD) that you are running.

## 8.4 Starting NetBIOS

This section provides detailed instructions for starting the NetBIOS VxD and the NetBIOS TSR.

NetBIOS displays these configuration settings when you load it:

Memory occupied: 15664, Network adapter number: 0

Local names: 016, Sessions: 010, CBs: 058, Name cache size: 010 names,

NetBIOS name scope "" 000 names

from name file

NetBIOS domain scope "" 000 addr-s

from bcast file

You can start and use LAN Manager or other NetBIOS applications after you load

NetBIOS.

#### 8.4.1 Starting the NetBIOS VxD

If your system is configured to use the VxD kernel and NetBIOS, you should enter the vxdinit command into your AUTOEXEC.BAT file.

Before you start Windows, you need to create an entry in your PCTCP.INI file for starting the NetBIOS VxD.

```
[pctcp vxdinit]
```

```
vnbeb=yes
```

To start the NetBIOS VxD

1. Before you start Windows, verify that the vnbeb=yes parameter is set in the

```
[pctcp vxdinit] section of your PCTCP.INI file.
```

This instructs Windows to load the PC/TCP NetBIOS VxD when you start Windows.

2. If the vnbeb=yes parameter does not exist, create it.

3. Enter `inet unload` to unload the PC/TCP VxD kernel.
4. Enter `vxinit` to restart the kernel with the new configuration.
5. Restart Windows.

The kernel loads the NetBIOS VxD, and any other VxDs specified in the `[pctcp vxinit]` section.

## 8.4.2 Loading and Unloading the NetBIOS TSR

Use these procedures to load and unload the NetBIOS TSR. PC/TCP NetBIOS loads

into upper memory by default. You can use the `loadhigh=no` parameter in the

PCTCP.INI file to load the NetBIOS TSR into conventional memory.

Note: You need to unload and reload NetBIOS for configuration changes to take effect.

To load the NetBIOS TSR

You load the PC/TCP NetBIOS TSR (NETBIOS.COM) either from the DOS prompt or

from your AUTOEXEC.BAT file. When you load the PC/TCP NetBIOS TSR with other

applications, you should load NetBIOS

- After you load the PC/TCP kernel.
- Before you load Windows (if you are using Windows).
- Before you load InterDrive.

If you are using InterDrive and LAN Manager, you must start the workstation (and log in, if you are using user security) before you load InterDrive. For more information about loading InterDrive, see Chapter 11, Managing the InterDrive Client.

- Before you start any NetBIOS application (for example, before you start a LAN Manager workstation).

If you are using a third-party NetBIOS application, you should start it after you load the PC/TCP kernel and PC/TCP NetBIOS.

This is a sample AUTOEXEC.BAT file section:

```
PATH C:\WINDOWS;C:\;C:\DOS;C:\LOCAL;C:\PCTCP;C:\LANMAN\NETPROG
```

```
SET PCTCP=C:\PCTCP\PCTCP.INI
```

```
ETHDRV
```

```
NETBIOS.COM
```

To unload the NetBIOS TSR

Before you unload NetBIOS, you should stop all network applications that you loaded

after NetBIOS, and close any active connections to remote machines made through

LAN Manager.

To unload NetBIOS (NETBIOS.COM), enter netbios -u at the system prompt:

```
C:\> netbios -u
```

The following message appears if you attempt to unload PC/TCP NetBIOS while there

are still active connections:

```
Unable to unload NetBIOS.
```

To avoid possible TSR problems, unload the applications in the reverse order in which

they were loaded.

## 8.5 Setting PC/TCP NetBIOS Configuration Options

PC/TCP NetBIOS configuration options are applied when you load PC/TCP NetBIOS.

A set of standard configuration option default values are supplied with PC/TCP

NetBIOS. For most network environments these defaults should be sufficient, and you should not need to reconfigure NetBIOS.

PC/TCP NetBIOS configuration option defaults are specified in the [pctcp netbios] section of your PC/TCP configuration file (C:\PCTCP\PCTCP.INI, by default).

You can change PC/TCP NetBIOS options using the standard PC/TCP configuration applications. For more information, see Getting Started section 2.1, Using the

PC/TCP Configuration Utility.

This is a sample PC/TCP NetBIOS configuration file section. When you do not specify a value for a configuration parameter, NetBIOS uses a default value.

[pctcp netbios]

adapter-number =

broadcastfile =

cache-elements =

domain-scope =

names =

loadhigh =

namefile =

ncbs =

scope =

sessions =

timeout =

You can use PC/TCP NetBIOS configuration options to

- Use multiple NetBIOS adapters.
- Logically partition your NetBIOS subnet.
- Communicate across routers.
- Identify hosts to automatically receive broadcast messages.
- Specify NetBIOS names.
- Use a Domain Name System (DNS) to resolve NetBIOS names.

### 8.5.1 Using Multiple NetBIOS Drivers

Some network operating systems allow their NetBIOS drivers to coexist with PC/TCP

NetBIOS. If you are using multiple NetBIOS stacks, you must set the adapter-number=

parameter in the [pctcp netbios] section of your PCTCP.INI file to specify which adapter

to use for PC/TCP NetBIOS. For example,

```
adapter-number = 1
```

Note: Some NetBIOS-based network operating system installation programs insert

information about their own NetBIOS drivers into the CONFIG.SYS or AUTOEXEC.BAT

file. Generally, you should remove any reference to a third-party NetBIOS network

driver to avoid conflicts with PC/TCP NetBIOS.

## 8.5.2 Partitioning Your Network with Scope

Scope is a naming scheme that NetBIOS uses to form a session-layer subnetwork on the LAN. This subnetwork (which differs from an IP subnet) divides hosts into discrete logical groups and limits those that receive broadcasts.

Your PC can communicate only with other NetBIOS hosts that share your scope. For example, if your PC is assigned to the kafka scope and you send a print request to a print server within the yeats scope, you receive the following error message:

```
Network name not found.
```

By default, PC/TCP NetBIOS names have no scope (commonly called a “null” scope).

Many NetBIOS vendors (such as 3Com, Bridge, and Excelan) also use a null scope because they design applications for single groups of users on small LANs.

Note: The default scope setting for previous releases was scope=FTP.

You can specify a name scope by editing the scope= parameter in the [pctcp netbios] section of your PCTCP.INI file. To specify a kafka scope, you would enter

```
scope=kafka
```

To specify the null scope, delete the entry from your configuration file, or leave the entry blank. Do not use empty quotation marks.

When you attempt to contact another NetBIOS host, PC/TCP NetBIOS appends your scope (with a leading dot (.)) to your local NetBIOS name (as defined in the computername= entry in your LAN Manager LANMAN.INI file). For example, if you set computername= chris in your LANMAN.INI file, and scope=kafka in your PCTCP.INI file, your host would identify itself as chris.kafka.

### 8.5.3 Communicating Across Routers

Generally, NetBIOS B-node implementations do not broadcast across IP routers.

PC/TCP NetBIOS provides the following mechanisms to transmit broadcasts across

routers:

- Broadcast file                      See section 8.5.4, [Creating and Using a Broadcast](#)

[File.](#)

- Name file                              See section 8.5.5, [Creating and Using a Name File.](#)
- Domain scope                        See section 8.5.6, [Using Domain Scope.](#)

To configure PC/TCP NetBIOS to communicate across routers

1. Create a broadcast file that identifies the remote hosts to receive NetBIOS

messages.

For example, this broadcast file (C:\PCTCP\NB-BCAST) identifies two remote hosts:

128.127.50.11

128.127.50.12

For detailed information about how to create and use a NetBIOS broadcast file, see

section 8.5.4, [Creating and Using a Broadcast File.](#)

2. Create a NetBIOS name file to associate host Internet addresses with a name.

For example, this NetBIOS name file (C:\PCTCP\NB-NAMES) associates names with

the hosts identified in the broadcast file:

```
SOMEHOST 128.127.50.11
```

```
ANOTHER1 128.127.50.12
```

For detailed information about how to create and use a NetBIOS name file, see section

8.5.5, [Creating and Using a Name File.](#)

3. Edit the [pctcp netbios] section of your PCTCP.INI configuration file to identify

your NetBIOS broadcast and name files:

```
[pctcp netbios]
```

```
broadcastfile=nb-bcast
```

```
namefile=nb-names
```

#### 8.5.4 Creating and Using a Broadcast File

A “broadcast file ” is an ASCII file containing a list of Internet host names or addresses to contact whenever you send information to the network. The broadcast file is read into memory when you load NetBIOS. To change the list of hosts in the broadcast file, you must edit the file and then unload and reload PC/TCP NetBIOS.

When you load PC/TCP NetBIOS, it displays the number of broadcast file entries. Note that PC/TCP NetBIOS does not recognize identical entries as duplicates.

Note: Use this file carefully. NetBIOS sends a message to all local hosts on your LAN and to all hosts in the broadcast file whenever it sends broadcast message or attempts to resolve a name. This can cause heavy network traffic.

This is a sample PC/TCP NetBIOS broadcast file:

```
128.127.55.103
```

lanmanserver1

lanmanserver2

128.127.55.120

alpha

Specify the path- or filename of the broadcast file by editing the broadcastfile=

parameter in the [pctcp netbios] section of your PCTCP.INI configuration file. For

example, use this entry to specify the C:\BFILES\MILLER broadcast file:

```
broadcastfile=C:\bfiles\miller
```

If you specify only a filename, PC/TCP NetBIOS searches the directory where your

PCTCP.INI file resides. (Use set at the DOS prompt to see the value of your PCTCP

environment variable.)

To create a broadcast file

1. Make a list of the names or IP addresses of the remote hosts that you want to add to a broadcast file.
2. Use a text editor to create a new file.
3. Create a name file entry for each name that you want to add.

Each broadcast file entry consists of one line that identifies the hostname or IP address. The maximum number of entries for a broadcast file is 128.

Do not enter a local IP address (such as your LAN Manager server's address) in the NetBIOS broadcast file.

For example, the following broadcast file (C:\PCTCP\MILLER) contains two entries.

The first host is specified by IP address, and the other is specified by a fully qualified Internet hostname.

128.127.50.1

anais.xyz.com

4. Verify that the broadcastfile= parameter in your [pctcp netbios] section of your

PCTCP.INI configuration file specifies the appropriate file- or pathname.

For example, this entry identifies the miller broadcast file in your PC/TCP home

directory (C:\PCTCP, by default):

```
broadcastfile=miller
```

If you specify the miller broadcast file, NetBIOS sends all broadcasts, name resolution

queries, and registration packets to the address 128.127.50.1 and the host

anais.xyz.com.

### 8.5.5 Creating and Using a Name File

A “name file” is an ASCII file that associates a list of NetBIOS names with their corresponding fully qualified hostnames or IP addresses. A name file does not consume network resources like a broadcast file does, because NetBIOS sends information to only one remote host at a time. The name file is read into memory when you load NetBIOS.

PC/TCP NetBIOS displays the number of name file entries when you load it. Note that it does not recognize identical entries as duplicates.

This is a sample NetBIOS name file:

```
LMN          128.127.55.103

LAN1ROOT     lanmanserver1

LAN2ROOT     lanmanserver1
```

LAN1PUBLIC           lanmanserver2

LAN2PUBLIC           lanmanserver2

PQR                   128.127.55.120

STUV                  128.127.55.120

Specify the path- or filename of the name file by editing the namefile= parameter in the

[pctcp netbios] section of your PCTCP.INI configuration file. This entry identifies the C:

\NFILES\PYTHON name file:

namefile=C:\nfiles\python

If you specify only a filename, PC/TCP NetBIOS searches the directory where your

PCTCP.INI file resides. (Use set at the DOS prompt to see the value of your PCTCP

environment variable.)

To create a name file

1. Make a list of the hostnames or IP addresses of the remote hosts that you want to add to a name file, together with the NetBIOS names that you want to assign to each.

A NetBIOS name is usually a synonym that you can use instead of a fully qualified hostname or Internet address.

2. Use a text editor to create a new file.
3. Create a name file entry for each NetBIOS name that you want to add.

For each entry, enter the NetBIOS name, press one or more spaces or tabs, then enter the IP address (or fully qualified hostname). Press Enter after each full entry.

To insert hexadecimal values in a NetBIOS name, use a text editor to insert the equivalent quoted control character. For example, to add the hexadecimal value 0x01 to a name, use your text editor to insert Ctrl+A.

Note: NetBIOS names in the name file are case-sensitive. If you are using this name file with LAN Manager, all names in the name file must be uppercase.

The following name file, PYTHON, contains name file entries for two different hosts:

```
idle 128.127.55.100
```

```
cleese monty.xyz.com
```

If you are using this name file with LAN Manager, the hostnames must be uppercase:

```
IDLE 128.127.5.100
```

```
CLEESE monty.xyz.com
```

NetBIOS names that contain spaces should be enclosed in double (or single) quotation

marks:

```
"MY HOST" 128.127.55.100
```

4. Verify that the namefile= parameter in your [pctcp netbios] section of your

PCTCP.INI configuration file specifies the appropriate pathname.

This example identifies the PYTHON name file:

```
namefile=C:\python
```

To use a NetBIOS name

Enter your network command (such as net view or net print), specifying the NetBIOS name associated with the remote hostname.

The following example shows how a LANtastic network user (after loading LANtastic) views the available resources on a remote host. This command connects the user to the remote host MONTY.XYZ.COM using the cleese NetBIOS name defined in the

PYTHON name file:

```
C:\> net view \\cleese
```

## 8.5.6 Using Domain Scope

If PC/TCP NetBIOS cannot resolve a hostname on the local network or through the broadcast file (broadcastfile= ) or name file (namefile= ) mechanisms, NetBIOS attempts to resolve the hostname by combining an encoded NetBIOS name with the specified domain scope string.

Using a domain scope is most practical if you communicate using a UNIX machine with the Domain Name System (DNS). You can store and update all the NetBIOS names for your network in one host table.

Specify a domain scope using the domain-scope= parameter in the [pctcp netbios] section of your PCTCP.INI configuration file. This entry specifies the xyz.com domain scope:

```
domain-scope=.xyz.com
```

To specify a null domain scope, delete the entry from your configuration file, or leave the entry blank. Do not use empty quotation marks.

PC/TCP NetBIOS uses an extension to the DNS to resolve NetBIOS names. This is an overview of how PC/TCP NetBIOS resolves names:

1. It searches the local PC/TCP NetBIOS name cache.

Initially, when you load PC/TCP NetBIOS, this cache is empty. When a NetBIOS name is resolved, PC/TCP NetBIOS adds the name to the local name cache.

2. It queries the local network for the NetBIOS name with the scope suffix. (See the `scope=` parameter in the `[pctcp netbios]` section of the PCTCP.INI configuration file.)

3. It searches for a match for the NetBIOS name in the name file. The name file associates a NetBIOS name with a fully qualified Internet name. (See the `namefile=` parameter in the `[pctcp netbios]` section of the PCTCP.INI configuration file.)

4. It queries the DNS for the encoded and then the unencoded NetBIOS name (if the domain scope suffix was specified).

PC/TCP NetBIOS DNS queries add the domain scope suffix to the NetBIOS name (see the domain-scope= parameter in your PCTCP.INI configuration file). These queries do not use the scope= suffix.

Domain name servers are identified in the domain-name-server= entries in the [pctcp addresses] section of your PCTCP.INI configuration file.

If you do not have a PC/TCP domain name server configured, PC/TCP NetBIOS does not query the DNS to resolve NetBIOS names.

The following example illustrates how to configure PC/TCP NetBIOS to communicate with the hosts, SOMEHOST and ANOTHER1 (by name) across routers.

This is a sample of the relevant entries in your PCTCP.INI file:

[pctcp netbios]

broadcastfile=nb-bcast

namefile=nb-names

This is a sample C:\PCTCP\NB-BCAST file:

128.127.50.10

128.127.50.11

This is a sample C:\PCTCP\NB-NAMES file:

SOMEHOST 128.127.50.10

ANOTHER1 128.127.50.11

To use NetBIOS domain scope

Enter your network command (such as net print or net use), specifying the NetBIOS

name associated with the remote hostname.

In this example, a LANtastic network user has defined the domain scope as .xyz.com.

The following command sequence sends the report1 file to printer1, which is attached

to the network print server fast.xyz.com:

```
C:\> net use lpt2 \\fast##printer1
```

```
C:\> net print report1 lpt2:
```

NetBIOS appends the domain scope .xyz.com to fast and the file is printed on the

remote printer using the server fast.xyz.com. (Note that the syntax of the print

command varies with each network operating system.)

## 8.6 Tuning PC/TCP for NetBIOS

Out of the total number of TCP connections configured for the PC/TCP kernel, NetBIOS must allot the following:

- One TCP connection for NetBIOS to monitor incoming session requests from remote hosts.
- One TCP connection for each active session with another host running NetBIOS.

For example, a remote host accessing a service on your machine requires one of your TCP connections.

If you are using the PC as a file or print server, you can rapidly use up the available TCP connections. This message (that appears when you load NetBIOS) indicates that you need to reconfigure the PC/TCP kernel with additional TCP connections:

Warning: The number of NetBIOS sessions was reduced to n.

If you want to have more sessions, configure more connections at kernel startup.

For a detailed description of the procedure for increasing the number of TCP

connections, see section 13.3.3, [Adjusting the Number of TCP and UDP Connections.](#)

Note: If you are using the NetBIOS TSR, first make sure that you stop all network applications that you loaded after PC/TCP NetBIOS, and close any active connections to remote machines made through a LAN manager or other NetBIOS applications.

(Unload the TSRs in the reverse order in which they were loaded.)

## 8.7 Programming with PC/TCP NetBIOS

The following information assumes that you are a NetBIOS programmer. Read it if you are writing an application program to run over PC/TCP NetBIOS and need to know details about the PC/TCP NetBIOS implementation.

To You

do need

this document

know

with

that

Use TCP

and P/

asy IP

nch Net

ron BIO

ous S

I/O allo

ws

bot

h

syn

chr

ono

us

(blo

cki

ng)

and

asy

nch

ron

ous

(no

nbl

ock

ing)

I/O

mo

des

. It

indi

cat

es

co

mpl

etio

n

by

two

met

hod

s:

by

upc

alli

ng

the

pos

t

rout

ine

s or

by

perf

orm

ing

co

mpl

etio

n

cod

e

veri

fica

tion

s in

the

Net

wor

k

Co

ntro

I

Blo

ck

(N

CB)

.

InteThe

rpr PC/

et TC

the P

INT ker

ER nel

FA and

CE Net

\_B BIO

US S

Y are

err not

or full

y

re-

entr

ant.

The

ker

nel

can

not

res

pon

d to

a

req

ues

ts

whil

e it

is

ser

vici

ng

ano

ther

req

ues

t. If

PC/

TC

P

Net

BIO

S

rec

eiv

es

a

req

ues

t

whil

e

ano

ther

req

ues

t is

in

pro

ces

s, it

reje

cts

the

NC

B

and

retu

rns

the

INT

ER

FA

CE

\_B

US

Y

err

or.

If

you

r

app

lica

tion

rec

eiv

es

this

err

or

on

a

WA

IT

NC

B, it

mu

st

try

the

co

mm

and

late

r.

InteSo

rpr me

et Net

nonBIO

sta S

ndaapp

rd lica

retution

rn s

val pro

ues vid

e

utili

ties

that

let

you

list

the

stat

us

of a

Net

BIO

S

ses

sio

n.

PC/

TC

P

Net

BIO

S

rep

orts

AD

AP

TE

R\_

ST

AT

US

and

SE

SSI

ON

\_ST

AT

US

val

ues

on

pen

din

g

ses

sio

ns,

pac

ket

s

sen

t,

pac

ket

s

rec

eiv

ed,

and

retr

ans

mis

sio

ns.

(Th

e

equ

ival

ent

fiel

ds

dis

pla

yed

on

the

scr

een

for

the

se

stat

us

con

diti

ons

var

y

wit

h

the

utili

ty.)

The following table describes the nonstandard PC/TCP NetBIOS return values:

N Descr

et iption

BI

O

S

C

o

n

dit

io

n

P The

e numb

n er of

di open

n and

g listeni

seng

ssessi

io ons.

ns

P The

acnumb

keer of

ts succe

sessful

nt sessi

on

and

datag

ram

send

comm

ands.

P The

acnumb

keer of

ts succe

re ssful

cesessi

iv on

e and

d datag

ram

packe

ts

receiv

ed.

R The

et numb

ra er of

nsname

miquery

ssretries

io (unsu

nsccess

ful

querie

s).

Note: In the Sytek NetBIOS specification, the ADAPTER\_STATUS function returns the hardware address of the network interface card. However, PC/TCP NetBIOS returns the IP address of the local PC.

For more information about NetBIOS application programming, refer to the IBM NETBIOS Application Development Guide.

### 8.7.1 NetBIOS Software Features and Limitations

These are some PC/TCP NetBIOS software limitations:

- PC/TCP does not support the NetBIOS UNLINK command.
- There can be no more than one NO WAIT instance of any other function pending at a time.
- There can be no more than 31 simultaneous sessions (established through CALL or LISTEN functions).
- Datagrams can contain no more than 512 bytes of user data.
- The ADAPTER\_STATUS function returns the first 335 bytes of adapter status information, which can contain no more than 16 names.

## 8.8 Troubleshooting NetBIOS

The following provides solutions to problems that you can have while using PC/TCP

NetBIOS:

NetBIOS does not load under the PC LAN Support program.

Remove the IBM NetBIOS device driver from the CONFIG.SYS file. See Getting Started for instructions.

TCP connection messages are displayed.

Increase the number of TCP connections. See section 8.6, Tuning PC/TCP for

NetBIOS.

You cannot access a mounted network drive.

Increase the number of TCP connections. See section 8.6, Tuning PC/TCP for

NetBIOS.

You see the message Conflicting drives.

Delete persisting connections in your LAN Manager LMUSER.INI file.

You see the message Network name not found.

Verify that the scope= parameter is set correctly in the [pctcp netbios] section of your

PCTCP.INI configuration file. See section 8.5.2, Partitioning Your Network with Scope.

You see the message Protocol not loaded.

Confirm that PC/TCP NetBIOS is installed/loaded.

Set ncbs=32 and sessions=32 in the [pctcp netbios] section of your PCTCP.INI

configuration file, and configure PC/TCP NetBIOS. See section 8.5, Setting PC/TCP

NetBIOS Configuration Options.

Increase the number of TCP connections. See section 8.6, Tuning PC/TCP for

NetBIOS.

You see the message Unable to unload NetBIOS.

Stop any active sessions.

You see the message Warning: The number of NetBIOS sessions was reduced to n.

Configure your PC/TCP kernel with additional TCP connections. See section 8.6,

[Tuning PC/TCP for NetBIOS.](#)

## 8.9 Related Information About Configuring NetBIOS

Refer to the following sources for more information about configuring NetBIOS:

Top So

ic urc

e

Tes Ch

ting apt

the er

ker 13,

nel Co

for nfig

the urin

optig

mal and

nu Tun

mb ing

er the

of Ker

TC nel

P

con

nec

tion

s

and

pac

ket

buff

ers.

Loa

din

g

the

PC/

TC

P

Net

BIO

S

Vx

D.

Usi Ap

ng pen

ker dix

nel A,

and PC/

Net TC

BIOP

S Co

con nfig

figu urat

rati ion

on Par

file am

entreter

ies. s

Ref

ere

nce

Usi Co

ng mm

net and

bio Ref

s ere

and nce

vxdi

nit

co

mm

and

opti

ons

.

Usi RF

ng C

the 100

Net 1

BIOand

S RF

sta C

nda 100

rd, 2

suc

h

as

defi

niti

ons

of

bro

adc

ast

pac

ket

s

and

SCO

pe.

Pro IB

gra M

mm Net

ing BIO

Net S

BIOAp

S plic

appatio

licatn

ion De

s. vel

op

me

nt

Gui

de

## Chapter 8 Configuring NetBIOS

### 8.1 Before You Start Using PC/TCP NetBIOS

### 8.2 Using NetBIOS in Windows

### 8.3 Configuring NetBIOS

### 8.4 Starting NetBIOS

#### 8.4.1 Starting the NetBIOS VxD

#### 8.4.2 Loading and Unloading the NetBIOS TSR

### 8.5 Setting PC/TCP NetBIOS Configuration Options

#### 8.5.1 Using Multiple NetBIOS Drivers

#### 8.5.2 Partitioning Your Network with Scope

#### 8.5.3 Communicating Across Routers

#### 8.5.4 Creating and Using a Broadcast File

8.5.5 Creating and Using a Name File

8.5.6 Using Domain Scope

8.6 Tuning PC/TCP for NetBIOS

8.7 Programming with PC/TCP NetBIOS

8.7.1 NetBIOS Software Features and Limitations

8.8 Troubleshooting NetBIOS

8.9 Related Information About Configuring NetBIOS

## Chapter 9

### Configuring PC/TCP Remotely Using DHCP or Bootp

PC/TCP allows you to keep your PC's network configuration on a server. By using one of the client configuration programs, DHCP (Dynamic Host Configuration Protocol) or Bootp (Bootstrap protocol), you can automatically get a PC's network configuration from a server each time that you start the PC.

With either of these programs, you can obtain PC network configuration, regardless of the PC's location. These programs also let you configure a PC that cannot maintain a local configuration either for security or hardware reasons. By centralizing administration for several PCs, this method of configuration makes information easier to update.

To get configuration information from a server, your network administrator must have set up a DHCP or Bootp server. This determines which protocol you use. DHCP is

usually preferred because it is more flexible.

The procedures in this chapter explain how to

- Obtain a permanent or temporary IP address from a server.
- Obtain network configuration information, such as server addresses, printer

information, default routers, Domain Name System (DNS) addresses, and a subnet mask.

With this chapter, you can learn

- How your system must be set up before you can use DHCP or Bootp.
- How DHCP and Bootp work.
- How to configure a DHCP client.
- How to start a DHCP client.
- How to configure a Bootp client.

- What to do when you encounter an unexpected situation.
- Where to find more information about DHCP and Bootp.

## 9.1 Before You Start Using DHCP and Bootp

Ensure that

- You have installed a network interface card in your PC, that it is correctly configured, and that it passes the diagnostic tests supplied by the card vendor.
- You have installed a correct network card driver.
- You or a network administrator have configured a Bootp or DHCP server to provide network information.
- You have installed PC/TCP and have a PCTCP.INI file for your system.

## 9.2 Understanding a Bootp and DHCP Client

When a DHCP or Bootp client starts on your PC, it sends a broadcast request for configuration information out to the network. If a DHCP or Bootp server is available, it responds to the client request. (A DHCP or Bootp client can also specify an address of a known server that it wants to use for configuration.) The client request contains several values from your system determined by the DHCP client software, including your PC's

- Media Access Control (MAC) address. This address specifies the physical address of the client's system.
- Subnet address.
- IP address field. If the kernel does not have an IP address configured for the PC, this field is 0.

After a server receives the configuration request, it searches its database to find the appropriate configuration for your PC. After the server determines the configuration values and IP address, it sends this information back to your PC. The information received updates the kernel and the PCTCP.INI file on your system. These values can change each time that you start your system and their accuracy is verified every time that you run DHCP or Bootp.

The IP address that you receive from a DHCP server can be a predetermined, permanent address or it can be dynamically allocated from a pool of available addresses. Bootp servers can only return predetermined, permanent addresses.

Dynamic allocation allows automatic reuse of an address that is no longer needed by the client to which it was assigned. Dynamic allocation is particularly useful for assigning an address to a client that connects to the network only temporarily.

Dynamically allocated addresses have a lease associated with them. A “lease” determines the length of time that you can keep the address. The DHCP client automatically tries to renew its lease before it expires. If the server does not let the client renew its lease, the server unloads the client’s PC/TCP kernel.

A DHCP client can get network information from either a Bootp server or a DHCP server. During installation, you can select the protocol to use.

DHCP supports clients for both Windows and DOS environments.

The DHCP client for Windows enables you to

- Configure your system.
- View your network configuration.
- Monitor your system status.
- Easily choose network options.

The DOS client uses the command line interface. Because of this, it is more difficult to request specific information, examine your configuration values, and monitor the process.


### 9.3 Configuring a DHCP Client in Windows

If you configured your PC as a DHCP client during installation of PC/TCP, the DHCP client application does not require any additional configuration.

If you did not configure your PC as a DHCP client during PC/TCP installation, or if you need to change configuration values or reconfigure your DHCP client, follow the steps in this section.

To configure your PC as a DHCP client in Windows

1. From the DHCP client's System menu, choose the Configuration command.



  
DHCP Client

The DHCP Client Configuration dialog box appears.

The screenshot shows a dialog box titled "DHCP Client Configuration". It features several input fields and control elements:

- Client ID:** A text box with the placeholder text "Enter client ID".
- Timeout (seconds):** A text box containing the value "60".
- Lease time (Hours):** A text box containing the value "1".
- Broadcast Retries:** A text box containing the value "5".
- Write to Configuration file:** A checked checkbox.
- Write to PC/TCP Kernel:** An unchecked checkbox.
- Protocol:** A group box containing two radio buttons: "Bootp" (unchecked) and "DHCP" (checked).
- Buttons:** Three buttons are located on the right side: "Ok", "Cancel", and "Help".

When you open the DHCP Client Configuration dialog box, the hardware address

(MAC address) of your system is automatically provided by DHCP.

2. If the DHCP server assigns profiles through client IDs, type your client ID.

Specifying a client ID is optional. Ask your network administrator for a valid client ID or the local policy for entering an ID.

The client ID helps the DHCP server determine your configuration and IP address if you have previously received configuration information from the server. The DHCP server also uses the MAC address or the subnet to determine configuration

information; however, if you specify a client ID, it overrides these values. This lets you change hardware addresses and still be able to get the same configuration.

You can request a previously assigned IP address in this box instead of a client ID. If available, you will receive the IP address and the same configuration.

3. Choose a Timeout interval.

The timeout interval specifies how long the DHCP client waits for a response. The default timeout interval is 60 seconds.

4. In the Lease Time box, specify the number of hours that you want to keep your IP address.

You need to specify a lease only for a dynamically assigned IP address.

A lease is the amount of time that you are allocated an IP address. If you request more time than the server's default lease time, you receive the server's default lease time

and a message of explanation. A lease usually ranges in time from 8 to 3600 hours.

Your system administrator sets the default lease time. Ask you administrator for your local lease policies.

5. Choose the number of broadcast retries.

This is the number of times that the client attempts to contact a server for a response.

The default is 5.

6. In you want to save configuration information in your PCTCP.INI file, select Write to Configuration File.

The only options that cannot be saved to the PCTCP.INI are the IP address, the Serial Number, and the Authentication Key. These values are never written to the configuration file and are always written directly to the kernel. This protects the system from starting with an incorrect configuration for the network.

7. If you want to save configuration information to the kernel, select Write to PC/TCP Kernel.

If you choose to save information to the kernel, DHCP only writes the most important options for configuration. The options kept by the kernel are domain name, DNS server address, router address, IP address, subnet mask, serial number, and authentication key.

Note: If you do not choose to save your information in the PCTCP.INI file or the kernel, your network information is not updated, but you can examine the configuration parameters returned by the server in the DHCP Client Status dialog box.

8. Select either DHCP or Bootp as your protocol.

Your selection depends on the server that provides network configuration information.

The default selection is DHCP. If you are unsure of which protocol to use, ask your

network administrator.

9. Choose OK.

You are prompted to save your configuration.

10. Choose OK.

This saves your PC's information to the server. You are now ready to start the DHCP client.


### 9.3.1 Starting the DHCP Client in Windows

After you have configured the DHCP client, you can use the DHCP Status windows to start the client and send for network configuration values. By default, the DHCP client is located in your Windows Startup directory, so it begins every time that you start Windows.

To start the DHCP client

1. From the DHCP client's System menu, choose the Status command.

The DHCP Client Status dialog box appears.



2. Choose Start.

The DHCP client sends your request with your configuration information to a server.

The Action Messages box shows the progress. The server returns the client's

configuration.

If you receive new configuration values, they overwrite older values. Values that were

present in past DHCP responses, but are not present in the current response, are

invalidated (set to zero or the line is removed). The only information that is not handled in this fashion is the IP address and the serial number and authentication key pair.

These values are never written to the configuration file if they are received from the server with configuration information and are always written directly to the kernel

(provided that you have chosen to have information written to the kernel). This protects the system from starting with an incorrect configuration for the network.

If you want to make any changes to your configuration after you have started DHCP, simply open the Client Configuration dialog box, make the changes, and choose the OK button again.

Once you have configured the DHCP client for Windows, it starts up with Windows. The application always runs minimized. You must keep DHCP running if you have a dynamically assigned (temporary) IP address so that the server can monitor your lease

time.

If you close the application, you will unload the PC/TCP software if you have a

dynamically assigned IP address. DHCP gives you a warning before this happens. If

you have a permanent IP address, you can quit the application after you have received

PC/TCP configuration information.


### 9.3.2 Monitoring DHCP Client Status in Windows

Once you have configured your PC for DHCP or Bootp and started the DHCP client application, you can view your network configuration information.

To view your network information

From the System menu of the DHCP Client icon, choose the Status command.

The DHCP Client Status dialog box appears.



This dialog box shows your PC's IP address, MAC address, lease time, and messages.

If you want to view your network configuration information, choose the Configuration

button.

## 9.4 Configuring a DHCP Client in DOS

You can obtain network configuration information in DOS with the `dhcp` command. You can type this command at the DOS prompt or you can put the command in your `AUTOEXEC.BAT` file so that it runs when you start your PC.

The command line interface for the `dhcp` command is very similar to that of the `bootp` command (discussed later in this chapter). The primary difference between the commands stems from the way that they handle address assignments. With `bootp`, each client is identified by a hardware address that is bound to an IP address so that an address for each client must already be assigned and entered with the server. With `dhcp` you can receive an IP address dynamically or you can retrieve a preassigned address. The `dhcp` command has several extra command line options to support this additional functionality. The additional options handle lease time, protocol selection,

and dynamic address assignment.

#### 9.4.1 DHCP Command Interface for DOS Clients

The dhcp command provides DHCP client capability for DOS clients. The dhcp command requires that your PC has a PCTCP.INI file so that the command can store the information it receives from a DHCP server.

The dhcp command has the format

```
dhcp[options] [config file]
```

With the dhcp command, you can select a communication protocol to use either DHCP or Bootp servers. For a complete listing of dhcp options, see the [Command Reference](#).

To select a protocol

Use the -p protocol option and specify either BOOTP or DHCP for the protocol. Enter the letter d for DHCP or the letter b for Bootp. The default protocol is DHCP.

DHCP also lets you request a lease time for an IP address. This is the amount of time

that the client can use the IP address.

To specify a lease time

Use the `-l` lease option specify the length of time you want to keep your IP address for

the lease. Specify the time in hours.

Usually, leases range in length from 8 hours to 3600 hours. Ask your network

administrator about your local lease policy. If you ask for too long of a lease, the server

assigns you the default length for a lease.

To prevent DHCP from entering configuration information in the `PCTCP.INI` file

Use the `dhcp` command with the `-nv` or the `-k` command options.

The `-nv` options let you view the information obtained from the server's configuration

file without writing the information to the `PCTCP.INI` file or the kernel. The `-k` option

updates only the resident kernel, not the `PCTCP.INI` file.

To specify the IP address of the DHCP server

Use the `dhcp` command with the `-d` address option.

The address specified with this option overrides the `server-address=` parameter's setting in the `[pctcp bootp]` section of the `PCTCP.INI` file. If the PC's address is not configured, the DHCP client broadcasts its request to the network and disregards this option.

You can also specify the complete path of a `PCTCP.INI` file, from which DHCP reads information and to which DHCP writes information by providing the `PCTCP.INI` file name on the command line. This optional setting overrides the `PC/TCP` environment variable's setting.

To see detailed information about the server's reply

Use the `dhcp` command with the `-v` option.

As an example of the dhcp command, you could use the following command line to get configuration information from a DHCP server at the IP address 128.127.50.55 for 40 hours:

```
dhcp -l 40 -d 128.127.50.55 -p DHCP
```

## 9.5 Configuring a Bootp Client

A Bootp client must be run on a DOS command line or placed in the AUTOEXEC.BAT file to be run when you start up your PC. You can use either the bootp command or the dhcp command with the -p option to get information from a Bootp server.

The bootp command has the format

```
bootp[options] [config file]
```

The bootp command requires that your PC has a PCTCP.INI file so that the command can store the information that it receives from a Bootp server.

To prevent the command from entering configuration information in the PCTCP.INI file

Use the bootp command with the -nv or the -k command options.

The -nv options let you view the information obtained from the server's configuration file (BOOTPTAB) without writing the information to the PCTCP.INI file or the kernel. The

-k option updates only the resident kernel, not the PCTCP.INI file.

The Bootp server can return the vendor network configuration information using

different formats, depending on what is specified as the value of the :vm tag in the

BOOTPTAB file. The formats control how the information is transported in the 64-byte

extension of the Bootp reply packet. Bootp supports replies in the format designed at

and named for Carnegie Mellon University (CMU), or in the format compliant with RFC

1533. (If :vm=auto is specified, the server's default format is used.)

A Bootp reply in the CMU format contains a subset of the information in a reply that

conforms to RFC 1048, and uses only predefined tags in the BOOTPTAB file. A Bootp

reply in the RFC 1048 format allows BOOTPTAB file tags that are defined by users.

However, both formats of the reply packet extension may use no more than 64 bytes to

transport the vendor information.

To get the information in the Bootp reply packet in the CMU format

Use the bootp command with the -c command option.

To specify the IP address of the Bootp server

Use the bootp command with the -d address option.

The address specified with this option overrides the server-address= parameter's setting in the [pctcp bootp] section of the PCTCP.INI file. If the PC's address is not configured, the Bootp client broadcasts its request to the network and disregards this option.

To replace your PC's current IP address with a new one from the Bootp server

Use the bootp command with the -f option.

Typically, a server does not give an IP address to a client that already has one. If the server does not reply with a new IP address, the old address stays in use. The bootp

command disregards this option if you also use the -n option.

Caution: Never use the -f option with the bootp command if you have network applications already running on your PC; your applications may lose their TCP connections.

You can also specify the complete path of a PCTCP.INI file by providing the PCTCP.INI file name on the command line. The DHCP client uses the file that you specify to store configuration information. This optional setting overrides the PC/TCP environment variable's setting.

To see detailed information about the server's reply

Use the bootp command with the -v option (for a verbose listing).

For a complete listing of bootp options, see the [Command Reference](#).

## 9.6 Troubleshooting DHCP Clients

This section provides possible solutions to situations that you may encounter when you use the DHCP client to get network configuration information. The situation is described first followed by the recommended course of action.

Could not locate server.

Verify that a DHCP or Bootp server is configured and running. If you know the server's address, try to send a request directly to that address.

Lease is expiring.

The DHCP client automatically tries to renew its lease for its IP address. If the DHCP server does not respond to the client's request to renew its lease, the client's PC/TCP kernel will be unloaded. If the DHCP does not renew your lease, check with your network administrator to ensure the server is active and to verify your network's lease

policies.

## 9.7 Related Information About the DHCP or Bootp Clients

Refer to the following sources for more information about DHCP and Bootp:

TopiSo

c urc

e

The Co

dhc m

p ma

and nd

bootRef

p ere

comnc

mane

ds

and

their

opti

ons

Boo RF

tp C

prot 95

ocol 1

defi

nitio

n

DH RF

CP C

defi 15

nitio41

n

Boo RF

tp Cs

exte15

nsio32,

ns 15

and 33,

inter15

ope 34

ratio

n

bet

wee

n

Boo

tp

and

DH

CP

## Chapter 9 Configuring PC/TCP Remotely Using DHCP or Bootp

### 9.1 Before You Start Using DHCP and Bootp

### 9.2 Understanding a Bootp and DHCP Client

### 9.3 Configuring a DHCP Client in Windows

#### 9.3.1 Starting the DHCP Client in Windows

#### 9.3.2 Monitoring DHCP Client Status in Windows

### 9.4 Configuring a DHCP Client in DOS

#### 9.4.1 DHCP Command Interface for DOS Clients

### 9.5 Configuring a Bootp Client

### 9.6 Troubleshooting DHCP Clients

### 9.7 Related Information About the DHCP or Bootp Clients

## Chapter 10

### Using PC/TCP with Memory Managers

PC/TCP provides several new features that increase your memory management options and let you optimize PC memory usage.

You can choose to load the kernel, InterDrive (network file system (NFS) client), and NetBIOS TSRs (terminate-and-stay-resident) into upper memory. You can also choose to load portions of the kernel and InterDrive TSRs into expanded memory (EMS).

You can use memory managers with PC/TCP if your PC has more than 1 MB of Random Access Memory (RAM).

PC/TCP complies with the LIM 3.2 Expanded Memory Specification (EMS). (LIM 4.0 applications are compatible with LIM 3.2 if there is a contiguous 64K page frame configured.)

PC/TCP has been tested with the following memory managers:

- Standard memory managers for DOS (EMM386.EXE and HIMEM.SYS)
- QEMM-386 (Quarterdeck Expanded Memory Manager 386)
- 386MAX
- NETROOM

This chapter shows how to

- Exclude your network interface card buffer space.
- Conserve conventional memory.
- Use memory managers with Microsoft Windows.
- Use the memory managers for DOS.
- Use QEMM-386.
- Use 386MAX.

## 10.1 Before You Use PC/TCP with a Memory Manager

Before you begin, you should

- Understand PC memory management terminology and concepts.
- Install PC/TCP and verify that you have network connectivity.
- Back up your PCTCP.INI, CONFIG.SYS, and AUTOEXEC.BAT files so that you

can easily restore your PC's current configuration (if necessary).

- Make sure that your memory manager is compatible with PC/TCP.
  - Verify that it is LIM 3.2-compliant.
  - If you load PC/TCP TSRs into upper memory, verify that your memory manager provides UMB (upper memory block) support.
  - Verify that your memory manager software interrupt (usually 0x67) does not conflict with the PC/TCP kernel or packet driver interrupt number.

- Review your PC's memory configuration and requirements.

You need to know what addresses are in use and what addresses are free so that you can load TSRs into memory more efficiently.

If your memory manager is already installed, you can use the report facility it provides to display your memory configuration. For MS-DOS versions 5.0 and later, you can display your PC's upper memory configuration using the mem command at the system prompt (after first exiting from Windows).

Note: Programs that display your RAM configuration do not generally report memory addresses that are configured for use by special-purpose hardware devices (such as your network interface card).

- Identify any RAM address space to exclude from memory management.

Some software products (such as Windows) and some hardware devices (such as

network interface cards) require buffer space in RAM. To run PC/TCP with memory managers you must configure the memory manager to exclude these addresses from management.

To identify RAM addresses to exclude for your network interface cards, see Getting Started.

To identify what areas to exclude if you are using Windows, see section 10.5, Using Memory Managers with Microsoft Windows.

## 10.2 Understanding Basic PC Memory Management Concepts

This section presents an introduction to basic memory management terms and concepts. Many memory managers use conflicting terminology. You should review these terms before you proceed.

The RAM address space on your DOS PC is partitioned into these regions:

**Conventional memory area**      The 640K memory area 00000h–9FFFFh. DOS typically loads your regular programs and TSR programs into this area.

**Upper memory block (UMB)**      The memory between the end of conventional memory (640K) and 1 MB. DOS typically uses this area for video or network drivers.

**Extended memory area**      RAM at 1024K (1 MB) and above.

**High Memory Area (HMA)** The first 64K of extended memory (addresses 1024K–1088K).

Note: UMB is also frequently referred to as “high memory,” “upper memory,” and “adapter segment memory.” In this document the term “high memory” refers exclusively to the HMA, the 64K extended memory region just above the UMB. The term “upper memory” refers exclusively to the UMB memory.

The extended memory area can be managed as extended (XMS) memory (using the Extended Memory Specification as defined by Lotus, Intel, and Microsoft), or as expanded (EMS) memory (using the LIM 3.2 Expanded Memory Specification).

- Extended memory managers (XMM) allocate extended memory to XMS-compliant programs and control access to the HMA, a 64K segment that begins at 10000h. You can use extended memory on 286 or higher PCs running in protected mode.
- Expanded memory managers (EMM) allocate memory in 16K pages to EMS-compliant programs. A program can reference up to 64K (four 16K pages). This is

known as an “EMS page frame.” The PC/TCP kernel and some PC/TCP applications run in expanded memory.

Most expanded memory managers can emulate expanded memory using extended memory. This lets an EMS-compliant program access the extended memory blocks through the EMS page frame as if they were expanded memory.

This lets you use extended memory area for


- Expanded memory pages.
- An extended memory RAM disk.
- Microsoft Windows disk cache, through the SMARTDRV program.
- Some program debuggers.

To emulate expanded memory, an expanded memory manager

- Creates the high memory area out of the first 64K of the extended memory area.

- Defines all or part of memory remaining in the extended memory area as extended memory blocks.
- Creates a 64K EMS page frame in the upper memory area. (This reduces the amount of available UMB.)
- Makes some or all of the extended memory blocks look like expanded memory pages.

This figure illustrates a RAM configuration using an extended memory manager to emulate expanded memory (EMS):



### 10.3 Excluding Your Network Interface Card Buffer Space

Some hardware devices (such as network interface cards) require buffer space in RAM. To avoid interrupt conflicts and to run PC/TCP with memory managers, you must configure the memory manager to exclude these addresses from management.

To configure your memory manager with a network interface card that uses RAM buffers

1. Identify the upper memory addresses configured for your network interface buffer.

The network interface buffer address may be configured with software or with jumper settings on your network interface card. For detailed information about the settings for your network interface card, see [Getting Started](#).

To maximize the amount of free upper memory space, FTP recommends that you

choose a network interface base address that is close to video RAM (A000h-C7FFh).

2. Use your memory manager's command syntax to make the network interface buffer addresses unavailable for use by other devices or TSRs.

For example, for QEMM-386, use the Exclude= parameter; for 386MAX, use the RAM= parameter.

3. If you are using PC/TCP in Windows, you should also instruct Windows to exclude the network interface buffer space by editing the EMMEExclude= entry in the [386Enh] section of your SYSTEM.INI file.

This SYSTEM.INI entry reserves the addresses C800h–CC00h:

```
[386Enh]
```

```
EMMEExclude=C800-CC00
```

## 10.4 Conserving Conventional Memory

The PC/TCP TSR kernels and other PC/TCP TSRs (such as the InterDrive NFS client)

support options that provide greater memory management flexibility and help to

conserve conventional memory.

PC/TCP kernel memory requirements differ depending on which kernel you are using

and on your configuration option settings. All PC/TCP TSRs report their memory usage

when you load them.

PC/TCP options let you

**Load into UMB** You can load the PC/TCP kernel, and the InterDrive and NetBIOS

TSRs into upper memory (UMB).

**Load into EMS** You can configure the PC/TCP kernel and InterDrive to use

expanded memory for some code or data segments.

Reduce kernel memory usage    You can affect the amount of memory that the kernel uses by setting kernel configuration options. For more information about reducing the size of the kernel, see section 13.4, Conserving Conventional Memory Usage.

Note: Loading PC/TCP TSRs into expanded memory, or using PC/TCP kernel options to reduce the amount of memory required, both generally result in reduced performance.

Memory managers attempt to arrange your TSRs to make the most efficient use of upper memory. In general, memory managers create an arrangement that is adequate for most machine configurations. After you configure your memory manager, you should review your upper memory configuration to assure that your upper memory usage is optimal.

The PC/TCP kernel and InterDrive TSRs are partitioned into code and data segments.

You can load the segments into upper or expanded memory independently. When you load the PC/TCP kernel TSR, it determines how best to use available upper and expanded memory. If you have enough combined available expanded and UMB memory, you can load the entire PC/TCP kernel above 640K (and not use any conventional memory).

#### 10.4.1 Loading PC/TCP Kernels and TSRs into Upper Memory (UMB)

You can conserve conventional memory by loading the PC/TCP kernel and other

PC/TCP TSRs into upper memory. Loading PC/TCP TSRs into UMB requires a

memory manager that provides access to upper memory (such as EMM386).

PC/TCP TSRs load into upper memory by default if there is enough upper memory

available.

FTP recommends that, in general, you use PC/TCP TSR commands and options to

load the PC/TCP TSRs into expanded memory (and not the load high command that

your memory manager provides).

Note: To load the PC/TCP TSR kernel into upper memory, you must use PC/TCP load

high options.

You can use the standard PC/TCP configuration utilities to specify memory loading

options.

This is a summary of the relevant PCTCP.INI file parameter settings:

F U Wit

ors h

th e this

is th con

T is figu

S c rati

R o on

m opti

mon

a sett

n ing

d

k k [pct

ere cp

n r ker

el n nel]

elloa

dhi

gh

=ye

s

In id[pct

te ri cp

r v idri

D e ve]

ri loa

v dhi

e gh

=ye

s

N n [pct

et etcp

Blbinet

O o bio

S s.s]

c loa

o dhi

mgh

=ye

s

You can use the loadhigh= parameter in the [pctcp vxdinit] section to load the PC/TCP

VxD loader into upper memory.

Depending on the configuration of available upper memory, the PC/TCP TSR kernel

can load into one or two upper memory blocks. The InterDrive and NetBIOS TSRs

each load into one upper memory block (UMB). You can reduce the size of the upper

memory block required by the PC/TCP kernel and InterDrive TSRs by also using

PC/TCP expanded memory options (use-emm=yes). PC/TCP TSRs use expanded memory primarily for data buffering. For more information about loading PC/TCP TSRs into expanded memory, see section 10.4.2, Loading PC/TCP Kernels and TSRs into

### Expanded Memory (EMS).

The following example shows how to load the PC/TCP generic token ring kernel into upper memory using the PC/TCP kernel command. The example assumes that loadhigh=yes in the [pctcp kernel] section of your PCTCP.INI configuration file. Note that PC/TCP TSRs report their memory usage when you load them.

```
C:\> tokdrv
```

```
Kernel interrupt vector is 0x61
```

```
Code Segment occupies 49.6K of high memory (UMB)
```

```
Data Segment occupies 22.8K of high memory (UMB)
```

Packet Driver found at vector 0x60

name:

version: 30, class: 17, type: 57, functionality: 6

ifcust (PC/TCP Generic Token Ring packet driver) initialized

5 free packets of length 2048, 5 free packets of length 160

The Resident Module occupies 0 bytes of conventional memory

## 10.4.2 Loading PC/TCP Kernels and TSRs into Expanded Memory (EMS)

If you have an expanded memory manager configured, you can load PC/TCP TSRs

into expanded memory. FTP recommends that, in general, you use PC/TCP TSR

commands and options to load the PC/TCP TSRs into expanded memory (and not the

load command that your memory manager provides).

This table summarizes the PC/TCP expanded memory loading options:

F U or

ors this

the con

is thfigu

T is rati

S c on

R o opti

mon

msett

a ing

n

d

k k [pct

ere cp

n r ker

el n nel]

eluse

- -

mem

m=

yes

In id[pct

te ri cp

r v idri

D e ve]

ri use

v -

e em

m=

yes

The PC/TCP kernel uses expanded memory for some code segments. Loading the PC/TCP kernel into expanded memory can significantly reduce the amount of conventional or upper memory that the kernel occupies. For example, you can reduce the upper memory required for the DIX Ethernet kernel by approximately 47K if you use the use-emm=yes and loadhigh=yes configuration options.

Note: The PC/TCP kernel can load itself into two non-contiguous upper memory blocks. When you use the expanded (use-emm=yes) and upper memory (loadhigh=yes) options, your kernel can use a smaller upper memory block.

This example shows how to load the PC/TCP DIX Ethernet kernel into expanded memory using PC/TCP command line options:

```
C:\> ethdrv -m
```

The PC/TCP InterDrive TSR uses expanded memory for data buffers by default. When

you do not use expanded memory (that is, if you set use-emm=no), the InterDrive TSR

uses an additional 7K of conventional memory.

## 10.5 Using Memory Managers with Microsoft Windows

If you are running Windows over DOS 5.0 (or greater), you must use the HIMEM.SYS

and EMM386.EXE drivers supplied with DOS rather than the HIMEM.SYS and

EMM386.EXE supplied with Windows.

These are some guidelines for using memory managers with Windows.

To use a third-party memory manager

Verify that your memory manager provides the same XMS capabilities as HIMEM.SYS

(the one supplied with Windows). QEMM-386 and 386MAX both provide these XMS

services.

To use programs that require expanded memory when Windows is not running

Use a memory manager that provides expanded memory services outside of Windows.

(The Windows expanded memory emulation capability is in effect only when Windows

is running.)

To use programs that require expanded memory in Windows

Use your memory manager command syntax to place the EMS page frame in the

address range supported by Windows (A000h–EFFFh).

## 10.6 Using the Memory Managers for DOS

You load the memory managers for DOS (HIMEM.SYS and EMM386.EXE ) using

device= statements in your CONFIG.SYS file.

This is a sample of the relevant entries in your CONFIG.SYS file:

```
DEVICE=C:\DOS\HIMEM.SYS
```

```
DEVICE=C:\DOS\EMM386.EXE 512 RAM FRAME=D000 X=C800-CC00
```

```
DOS=HIGH,UMB
```

T Does

hi this

s

p

ar

a

m

et

er

D Load

E s the

VIHIM

C EM.S

E YS

= exten

ded

mem

ory

driver

,

then

the

EMM

386.

EXE

expa

nded

mem

ory

emul

ation

progr

am.

5 Confi

1 gure

2 s

EMM

386.

EXE

to

use

512K

of

expa

nded

mem

ory.

In

gene

ral,

speci

fy

256K

more

than

your

TSR

s

requi

re.

This

value

is

adeq

uate

for

the

PC/T

CP

kern

el,

Inter

Drive

, and

NetB

IOS

TSR

s

(only

).

R Enab

A les

M EMS.

Use

the

NOE

MS

para

mete

r

inste

ad if

you

do

not

need

to

supp

ort

expa

nded

mem

ory.

F Start

R s the

A 64K

M EMS

E page

= fram

e at

the

speci

fied

addr

ess.

If you

are

using

Wind

ows,

this

must

be

withi

n the

supp

orted

addr

ess

rang

e

(A00

0h-

E000

h).

X Exclu

= des

the

speci

fied

addr

esse

s

from

mem

ory

man

age

ment

.

Use

this

para

mete

r to

exclu

de

any

netw

ork

interf

ace

bufe

r

spac

e.

For

the

speci

fic

addr

esse

s to

exclu

de

for

your

PC

confi

gurat

ion,

see

the

techn

ical

docu

ment

ation

for

your

netw

ork

card.

D Uses

O the

S HIG

= H

Hloptio

G n to

H,load

U most

M of

B DOS

into

the

high

mem

ory

area.

Uses

the

UMB

optio

n to

maint

ain a

link

betw

een

conv

entio

nal

mem

ory

and

the

uppe

r

mem

ory

area.

To load TSRs into upper memory

You can load TSRs into upper memory using the memory manager loadhigh command

or using PC/TCP command and configuration options.

Note: You must use only PC/TCP commands and options to load the PC/TCP kernel into upper memory. Do not use the loadhigh command to load the PC/TCP kernel into upper memory.

This example shows how to load PC/TCP SNMP using the DOS memory manager

loadhigh command:

```
C:\> loadhigh C:\PCTCP\snmpd.exe
```

For more detailed information on how to use the DOS memory manager commands and options, see the DOS Technical Reference.

This example shows how to load the PC/TCP DIX Ethernet TSR kernel into upper memory using the PC/TCP kernel command:

```
C:\> ethdrv
```

This assumes that loadhigh=yes in the [pctcp kernel] section of your PCTCP.INI configuration file.

## 10.7 Using QEMM-386

QEMM-386 is an EMS, XMS, and high memory manager. It automatically converts

XMS to EMS memory as needed.

Note: QEMM-386 Stealth mode was not reliable in QEMM-386 versions prior to 7.01.

You load QEMM-386 using device= statements in your CONFIG.SYS file. Here is a

sample of the relevant entries in your CONFIG.SYS file:

```
DEVICE=C:\QEMM\QEMM386.SYS EXCLUDE=C800-CC00 RAM
```

```
DOS=HIGH
```

T Does

hi this

s

p

ar

a

m

et

er

E Instr

X ucts

C QEM

L M-38

U 6 not

D to

E man

= age

addr

esse

s in

the

speci

fied

rang

e.

Use

this

para

mete

r to

exclu

de

any

netw

ork

interf

ace

bufe

r

spac

e.

For

the

speci

fic

addr

esse

s to

exclu

de

for

your

PC

confi

gurat

ion,

see

the

techn

ical

docu

ment

ation

for

your

netw

ork

card.

R Rese

A rves

M uppe

= r

mem

ory

for

loadi

ng

TSR

s and

drive

rs.

D Load

O s

S DOS

= into

HIthe

G high

H mem

ory

area.

To load TSRs into upper memory

You can load TSRs into upper memory using the memory manager loadhi command or using PC/TCP command and configuration options.

Note: Use only PC/TCP commands and options to load the PC/TCP kernel into upper memory. Do not use the loadhi command.

This example shows how to load PC/TCP SNMP into upper memory using the

QEMM-386 loadhi command:

```
C:\> loadhi C:\PCTCP\snmpd.exe
```

For more detailed information on how to use QEMM-386 commands and options, see the QEMM-386 User's Guide.

This example shows how to load the PC/TCP InterDrive TSR into upper memory using

the PC/TCP idrive command:

```
C:\> idrive
```

PC/TCP InterDrive loads into upper memory by default. To load it into conventional

memory, enter loadhigh=no in the [pctcp idrive] section of your PCTCP.INI configuration

file.

### 10.7.1 Using QEMM-386 with Windows

This section describes how to customize QEMM-386 memory management when you use Windows.

To use programs that require expanded memory in Windows

Edit the QEMM-386 Frame= parameter in your CONFIG.SYS file to have your memory manager place the EMS page frame in the address range supported by Windows

(A000h–E000h). For example,

```
DEVICE=C:\QEMM\QEMM386.SYS RAM R:3 X=A000-AFFF FRAME=E000
```

## 10.8 Using 386MAX

The 386MAX installation program places a device statement like this in your

CONFIG.SYS:

```
DEVICE=C:\386MAX\386MAX.SYS PRO=C:\386MAX\386MAX.PRO
```

Use the PRO= option to identify the pathname of the 386MAX.PRO file that contains 386MAX memory management configuration options.

By default, 386MAX places the EMS page frame at E000h.

A sample 386MAX.PRO file looks like this:

```
RAM=C800-CC00 ; Exclude the network interface card buffer area
```

```
FRAME=E000
```

T Does

hi this

s

p

ar

a

m

et

er

R Instr

A ucts

M 386

= MAX

not

to

man

age

addr

esse

s in

this

rang

e.

Use

this

para

mete

r to

exclu

de

any

netw

ork

interf

ace

bufe

r

spac

e.

For

the

speci

fic

addr

esse

s to

exclu

de

for

your

PC

confi

gurat

ion,

see

the

techn

ical

docu

ment

ation

for

your

netw

ork

card.

This

infor

matio

n is

also

listed

in the

“Net

work

Interf

ace

Card

Infor

matio

n

secti

on of

the

PC/T

CP

Confi

gurat

ion

Chec

klist

in

Getti

ng

Start

ed.

F If you

R are

A using

M Wind

E ows,

= instru

cts

your

mem

ory

man

ager

to

place

the

EMS

page

fram

e in

the

addr

ess

rang

e

supp

orted

by

Wind

ows

(A00

0h–

E000

h).

To load TSRs into upper memory

You can load TSRs into upper memory using the 386MAX 386load command or using

PC/TCP command and configuration options.

This example shows how to load PC/TCP SNMP into upper memory using the 386load

command:

```
C:\> 386load SIZE=86864 FLEXFRAME PROG=c:\pctcp\snmpd.exe
```

Specify the size of the TSR (including its initialization code) in decimal.

For more information about 386MAX command line options, see the 386MAX Technical Reference.

This example shows how to load the PC/TCP NetBIOS TSR into upper memory using the PC/TCP netbios command:

```
C:\> netbios.com
```

PC/TCP NetBIOS loads into upper memory by default. To load NetBIOS into conventional memory, enter loadhigh=no in the [pctcp netbios] section of your PCTCP.INI configuration file.

To determine how much upper memory a TSR requires using 386MAX

1. Run 386load with the GETSIZE= parameter (instead of SIZE= ):

```
C:\> 386load GETSIZE PROG=c:\pctcp\snmpd.exe
```

2. Run 386load with the /s option to display the Program Memory Summary:

```
C:\> 386load /s
```

Use the reported Initial Size as the value for the 386load SIZE= parameter.

## 10.8.1 Using 386MAX with Windows

This section describes how to customize 386MAX memory management when you use Windows.

To use programs that require expanded memory in Windows

Edit the 386MAX Frame= parameter in your CONFIG.SYS file to place the EMS page frame in the address range supported by Windows (A000h–EFFFh).

If the 386MAX maximize program places your EMS page frame in an area that is not supported by Windows, you must rearrange your upper memory configuration to create a 64K block available in the supported range.

To run Windows in standard or enhanced mode

Edit the 386MAX RAM= parameter in your CONFIG.SYS file to exclude the translation buffer areas from management.

## 10.9 Related Information About Using Memory Managers

For more information about managing memory, refer to the following sources:

TopiSo

c urc

e

ConCh

figu apt

ring er

Net 8,

BIO Co

S. nfig

uri

ng

Net

Bl

OS

ConCh

figu apt

ring er

Inte 11,

rDri Ma

ve. na

gin

g

the

Int

erD

rive

Cli

ent

Dia Ch

gno apt

singer

PC/ 22,

TC Tro

P ubl

pro esh

ble ooti

ms. ng

the

Ker

nel

an

d

Dri

ver

Co

nfig

ura

tion

ConAp

figu pe

ring ndi

PC/ x

TC A,

P PC

TS /TC

Rs P

to Co

use nfig

me ura

mor tion

y Par

opti am

ons. ete

rs

Ref

ere

nce

Co Co

mm m

and ma

line nd

opti Ref

ons ere

for nce

load

ing

PC/

TC

P

TS

Rs.

Ide Get

ntifying

ing Sta

net rte

wor d

k Ch

inte apt

rfac er

e 1,

RA Inst

M alli

buff ng

er PC

to /TC

exclP

ude Sof

fro twa

m re

me

mor

y

ma

nag

em

ent.

Inst Yo

allin ur

g me

and mo

trou ry

blesma

hoo na

ting ger

you 's

r tec

PC' hni

s cal

me doc

mor um

y ent

confatio

igur n

atio

n.

## Chapter 10 Using PC/TCP with Memory Managers

### 10.1 Before You Use PC/TCP with a Memory Manager

### 10.2 Understanding Basic PC Memory Management Concepts

### 10.3 Excluding Your Network Interface Card Buffer Space

### 10.4 Conserving Conventional Memory

#### 10.4.1 Loading PC/TCP Kernels and TSRs into Upper Memory (UMB)

#### 10.4.2 Loading PC/TCP Kernels and TSRs into Expanded Memory (EMS)

### 10.5 Using Memory Managers with Microsoft Windows

### 10.6 Using the Memory Managers for DOS

### 10.7 Using QEMM-386

#### 10.7.1 Using QEMM-386 with Windows

### 10.8 Using 386MAX

10.8.1 Using 386MAX with Windows

10.9 Related Information About Using Memory Managers

## Chapter 11

### Managing the InterDrive Client

InterDrive® software makes it possible for you to connect to a Network File System (NFS) server from your PC and use remote files and printers as if they were local.

InterDrive can run as either a terminate-and-stay resident (TSR) program or a virtual device driver (VxD). The TSR is necessary for DOS users. Windows users can choose between the TSR and the VxD; see section 11.2, Choosing the InterDrive TSR or VxD for details.

Figure 11-1 shows the relationship between applications, the InterDrive TSR, and the NFS server in a DOS environment. You can use InterDrive commands, such as `idnet`, `idmnt`, and `idutil`, to configure and manage InterDrive. Once you have established connections to file systems and printers, the client TSR manages the interaction between DOS user applications and the NFS server.




Figure 11-1 InterDrive in DOS

In Windows, an additional component, called the PC/TCP Network Driver, is necessary for access to network files and printers. Figure 11-2 shows the relationship between applications and PC/TCP file and print sharing components in a Windows environment.

To configure and manage file and print sharing services, you can use the standard Windows File Manager, Print Manager, and Control Panel interfaces, or alternately, the PC/TCP Network Control application. Once you have established connections to file systems and printers, the PC/TCP Network Driver and InterDrive manage the interaction between user applications and the NFS server.




Figure 11-2 InterDrive in Windows

This chapter is intended for people who need to have a deeper understanding of

interactions between InterDrive and the NFS server in order to manage InterDrive,

either individually or for a large network of end users. With this chapter, you can learn

- What you must do before you start managing InterDrive.
- How to choose between the TSR and VxD versions of InterDrive.
- How to start and stop InterDrive.
- How to create a configuration file that you can adapt for multiple users.
- How to use a centralized authentication server for multiple clients.

- Factors to consider in managing InterDrive's use of memory.
- Factors to consider in tuning InterDrive network performance.
- What to do when you encounter unexpected situations.
- Where you can find more information about using InterDrive.

## 11.1 Before You Start to Manage InterDrive

Make sure that

- You have read the related file and print sharing chapters in [Using PC/TCP in DOS](#).

See also [Using PC/TCP in Windows](#) for information about file and print sharing in

Windows. For a detailed list of related documentation, see section 11.9, [Related](#)

[Information About Managing InterDrive](#).

- You know and understand the environment on the server side, including the type of operating system, the type of NFS services available, and any resulting requirements or limitations.
- You know whether you are running the TSR or VxD version of the PC/TCP kernel, and why.

## 11.2 Choosing the InterDrive TSR or VxD

InterDrive can run as a terminate-and-stay-resident program (TSR) or as a virtual device driver (VxD). The version of InterDrive configured for your system depends on your choice of PC/TCP kernel. When you choose the VxD kernel at installation time, you get the VxD InterDrive. Likewise, when you install the TSR kernel, you get the TSR InterDrive.

If your working environment is mainly Windows, FTP recommends that you use the VxD kernel and InterDrive because of their memory advantage. In addition to the Windows interface for NFS printing and file sharing, the VxD supports the DOS InterDrive commands when you use them from a DOS session within Windows.

The InterDrive VxD loads when you start Windows. When you exit from Windows, the VxD versions of the kernel and InterDrive unload, and InterDrive closes any network

connections that you made while in Windows. If you need network connectivity before you start Windows, or if you need to preserve network connections when you exit from Windows, use the TSR kernel and InterDrive. With the TSR, you avoid having to reconfigure the network software and reconnect drives and printers every time you move between DOS and Windows. For additional considerations and information about choosing TSR or VxD solutions, see the [Getting Started](#) guide.

### 11.3 Starting and Stopping InterDrive

If you select the TSR kernel and InterDrive at installation time, the install program inserts the idrive command in your AUTOEXEC.BAT file and InterDrive should start automatically each time that your system starts.

If you select the VxD kernel and InterDrive, the install program adds the vxdinit command to your AUTOEXEC.BAT file and inserts the vidrive=yes parameter in the [pctcp vxdinit] section of your PCTCP.INI file. The vxdinit command prepares your system to load the VxD kernel and other VxD components when Windows starts. The vidrive=yes parameter indicates that you want to load the InterDrive VxD.

You can use these commands to start and stop InterDrive at times other than system startup or Windows startup. For example, after you change certain InterDrive parameters, you need to stop and restart InterDrive for the change to take effect.

To stop the InterDrive TSR

Enter idutil -u at the system prompt.

InterDrive disconnects all mounted file systems and printers and unloads from memory.

To start the InterDrive TSR

Enter idrive at the system prompt.

To stop the InterDrive VxD

1. Exit from Windows.

The kernel and all VxD components unload.

2. If you have changed parameters and you want the new parameters to take effect,

at the system prompt, enter vxdinit -u to unload the VxD loader.

To start the InterDrive VxD

1. At the system prompt, enter vxdinit to restart the VxD loader.

2. Start Windows. The VxD kernel and InterDrive load with new parameters.

## 11.4 Creating a Universal Configuration File

If you are a network administrator in charge of setting up NFS file and print sharing for a number of users, you can create default PCTCP.INI configuration file sections that each user can copy and modify as appropriate. Use the TEMPLATE.INI file in the directory containing your PC/TCP files to obtain a skeleton copy of the InterDrive configuration file sections.

If you want the PCTCP.INI file to be shared by more than one user, you can specify `user= ?` in each section defining a specific file system or print session. This causes InterDrive to prompt for a username during an attempt to mount the file system or printer.

Use the `[pctcp idrive]` section to specify parameters that apply globally for all InterDrive connections. Use the `[pctcp idrive filesystem]` and `[pctcp idprint print_session]` sections to

define specific file system and print connections. You can override some global parameters for specific file systems. For details, see Appendix A, PC/TCP

Configuration Parameters Reference.

## 11.5 Using a Centralized Authentication Server

The PCNFSD is the server that authenticates your username and password when you

try to mount a file system or printer. The PCNFSD also controls the mounting of

printers, so it must be running on any system whose printer you are trying to mount.

However, when you mount file systems, it is possible to use a different server for

authentication. For example, you might mount file systems on servers named Green,

Blue, and Red, with server Green authenticating mount requests for all systems. A

centralized authentication server is useful if

- You want to store and maintain password information in one secure, centralized

place.

- PCNFSD software is not available on all NFS servers in your network.

By default, InterDrive requests authentication from the same server whose files or

printers you are trying to mount. You can use the `pcnfsd=` parameter in the

`[pctcp idrive]` section of your `PCTCP.INI` file to specify the hostname or IP address of

another authentication server.

## 11.6 Managing InterDrive's Use of Memory

When it starts, InterDrive automatically tries to make the most efficient use of memory that it can. If you are using the InterDrive VxD, you do not need to worry about how it uses memory. If you are using the TSR, there are some things that you can do to improve its efficiency.

This section gives a brief overview of how InterDrive uses memory. It assumes that you have a basic understanding of memory management concepts. For introductory memory management concepts and additional guidelines, see Chapter 10, Using PC/TCP with Memory Managers.

### 11.6.1 Understanding How the VxD Uses Memory

A major advantage of the InterDrive VxD is that you do not have to understand much about how it uses memory. The VxD relies on Windows memory management, which does not conflict with the needs of other Windows applications. Therefore, the VxD can allocate as much space in memory as it needs.

For the most part, the VxD uses the same configuration parameters and defaults as the InterDrive TSR, reading them from the [pctcp idrive] section of your PCTCP.INI file.

Because of the increased memory capabilities of Windows, the VxD overrides some defaults in the [pctcp idrive] section in favor of larger values. For example, if you are using the VxD InterDrive, you can mount the maximum of 16 file systems and 7 printers by default.

The VxD stores values specific to its operation in the [pctcp idrive-vxd] section. For

more information, see Appendix A, [PC/TCP Configuration Parameters Reference](#).

## 11.6.2 Adjusting How the TSR Uses Memory

The amount of memory that the InterDrive TSR occupies varies depending on a number of factors, including

- Whether or not the program can load into upper memory.
- Whether or not an expanded memory manager (EMM) is running on your system.
- The number of default printers and file systems that you configure.
- The settings for FILES and FCBS in your CONFIG.SYS file.
- Whether and how you use caching.

By default, when you start the InterDrive TSR, it tries to load into an upper memory block if

- A memory manager that provides access to upper memory (such as

EMM386.EXE) is present, and

- There is enough room in upper memory on your system.

InterDrive also checks for the presence of an EMM when it loads. If an EMM is running,

InterDrive allocates space in expanded memory for the maximum number of print

entries, lookup cache buffers, name-mapping cache buffers, and read-write cache

buffers.

You can disable the use of upper memory and expanded memory by setting `loadhigh=`

`no` and `use-emm= no` in the `[pctcp idrive]` section of your PCTCP.INI file. However,

remember that the use of these features can save a great deal of conventional

memory.

You can do even more to reduce the TSR's use of memory by configuring the minimum

resources that you need for printing and file sharing. The `print-entries=` parameter in

the [pctcp idrive] section of your PCTCP.INI file specifies how many printers you want to be able to mount concurrently. The default number of print entries is 1 without an EMM and 7 with one. For every print entry that you configure, InterDrive allocates print buffer space in memory. Therefore, you can conserve memory by limiting the print-entries= value to the maximum number of printers that you need, or specifying print-entries= 0 if you do not use NFS printing.

InterDrive also allocates space based on the maximum number of files that can be open at one time on your system. This number is determined by the sum of the FILES= and FCBS= entries in your CONFIG.SYS file, or by a command issued to applications such as the Quarterdeck Office Systems FILES.COM or FCBS.COM programs. To conserve memory, ensure that the values that you have set for these entries are reasonable estimates representing the number of files that you plan to use

concurrently.

When the InterDrive TSR loads with an EMM running, it allocates four pages (a page frame) for each of the following:

- Lookup cache
- Name mapping cache
- Printing and read-write cache

Although memory usage is not as critical an issue with an EMM, you can reduce the amount of extended memory that InterDrive uses by disabling features that you do not need.

For example, if you do not need read-write caching, you can disable it by specifying `rw-cache-buffers= 0`. Disabling read-write caching and setting `print-entries= 0` reduces extended memory use by four pages.

## 11.7 Tuning InterDrive Network Performance

InterDrive automatically configures certain parameters with values that should work best for the environment in which it is running. However, if you experience slow response time when using network files or printing to an NFS printer, you may benefit by tuning some of these parameters. Remember that increasing the values for parameters only on the client side does not guarantee improved performance. Network performance is influenced by a number of factors, including

- The type of network connecting the client and server, and whether or not there are intervening gateways or routers.
- The server's ability to process requests and exchange data.
- The method that an application uses to read and write data.

This section describes how you can improve performance, with those considerations in

mind, by

- Changing the packet read and write size.
- Changing the streaming value.
- Using read-write caching.
- Using TCP connections.

### 11.7.1 Adjusting Packet Read and Write Size

“Read size” is the size of packets that InterDrive gets and processes from the NFS server. An example of a read is when you copy a file from the server to your local PC.

“Write size” is the size of packets that InterDrive formats and sends to the server. An example of a write is when you save a file to a network drive.

By default, InterDrive sets the write size to the transfer size requested by the server

(usually 8K) and selects the largest possible packet read-size based on these factors:

- The transfer size requested by the server.
- Whether or not the PC/TCP kernel has any huge packets allocated to it. The VxD

kernel allocates 25 huge packets by default; you can set the TSR kernel value with the

huge-packets= parameter in the [pctcp kernel] section of your PCTCP.INI file.

- Whether or not streaming is enabled for the mounted file system.

Because large packets carry more data per transaction, fewer packets need to be sent, which usually results in better network performance. However, sometimes large packets have an adverse effect on performance.

For example, if there is a router or gateway between the client and server, the router breaks down (fragments) packets into the largest size it can handle, adding time to network transactions. So, if a gateway fragments packets larger than 512 bytes, for instance, you should set the InterDrive read and write sizes to 512.

Another reason for poor performance could be that the NFS server does not process large packets well. Many older NFS servers take longer processing read sizes that are not 1024 bytes or multiples of 1024.

To verify the current read and write size

Use the `idutil -f` command.

The output displays current settings for each mounted file system, including the current read and write sizes. It also shows statistics for “current round trip time” and “base round trip time” so that you can analyze whether network transactions are taking longer than they should be.

To change the read size

1. Set the read-size= parameter in your PCTPC.INI file. Specify a global value in the

[pctcp idrive] section or a value for a specific file system in a [pctcp idrive filesys]

section. The minimum value is 512 bytes; the maximum is 8192. The new value takes

effect when you restart InterDrive or remount the specified file system.

–or–

Use the idconfig -r drive: command to set the read size for a specified file system for

the current InterDrive session only.

2. If you increase the read size to its maximum (8K), verify that at least one huge packet buffer is allocated for the PC/TCP kernel to process large packets.

You set this with the huge-packets= parameter in the [pctcp kernel] section of your PCTCP.INI file. The default value is 25 buffers for the VxD kernel and 0 for the TSR kernel.

3. Unload and restart the kernel for a new huge-packets= value to take effect.

To change the write size

Set the write-size= parameter in the [pctcp idrive] section of your PCTCP.INI file.

Specify a global value in the [pctcp idrive] section or a value for a specific file system in a [pctcp idrive filesys] section. The minimum value is 512 bytes; the maximum is 8192.

The new value takes effect when you restart InterDrive or remount the specified file system.

–or–

Use the `idconfig -w drive:` command to set the write size for a specified file system for

the current InterDrive session only.

## 11.7.2 Tuning Stream Values

In a typical network exchange, one system sends a packet, then waits for a response from the remote host before sending the next packet. InterDrive can do what is known as “streaming”; that is, it sends several packets at a time without waiting for a response for each one sequentially. Because several packets are being processed concurrently, writes and reads can take much less time than waiting for each packet to travel through the network and be acknowledged by the remote host. InterDrive does require an eventual response for each packet that it sends. Consequently, streaming can improve performance without affecting reliability.

Streaming can improve performance

- In networks with long transmission delays, where sequential processing of each packet takes a long time.

- When the server has high processing capacity and can handle streaming well.

Sometimes streaming can actually degrade performance. Decreasing streaming, or

disabling it altogether, can improve performance in the following situations:

- When the InterDrive read size is larger than the maximum transmit unit (MTU) for the network.
- When the server is not able to process streamed packets well.
- If there is a router in the network path between client and server.
- If you are using a serial line connection to the remote host.

One indicator that streaming is not working well is a high number of retransmitted

packets.

To see current statistics on retries sent

Use the `idutil -s` command.

The command produces output similar to the following:

-----InterDrive Statistics-----

9696 RPC requests sent

9650 RPC replies received

119 retries sent

73 bad XIDs received

174 NFS errors (these can be ignored)

0 stale filehandle errors

0 send errors

0 receive errors

Last net I/O error = 0 (No error)

Last NFS error = 248 (Unexpected end of file or directory)

Last DOS error = 18 (No more files)

A high value for retries sent can indicate a performance problem due to streaming. If

InterDrive is busy retransmitting unacknowledged packets, and the server is

overloaded trying to process all of the retransmitted data, the result is degraded

performance.

A high number of retries can also indicate other network problems. For example, the

bad XID count indicates the number of duplicate replies that the server sent in

response to retransmitted requests. A very low bad XID value in comparison to the

retries value could indicate that packets are being dropped; the client keeps resending

packets, but the server does not receive them or respond. A high retry count also can

indicate an uneven round trip time between the client and server due to network

congestion or router problems. These factors require adjustment to your network

configuration that is outside of the scope of InterDrive tuning.

To change the stream value

Edit the stream= parameter in the [pctcp idrive] section of your PCTPC.INI file. The new

value takes effect when you restart InterDrive. Change the value by increments of 1

until you reach a setting that provides adequate performance. You can also set this

value for a specific file system in a [pctcp idrive filesystem] section.

–or–

Use the idconfig -q command to change the stream value for the current InterDrive

session only. The command can change the setting either globally or for a specified file

system.

Note: InterDrive automatically sets the upper limit for streaming to one less than the

number of `streaming` can actually degrade performance. Decreasing streaming, or

disabling it altogether, can improve performance in the following situations:□

c