

LAN Server Configuration Help

Please select the following: [Configuring the LAN Server.](#)

Configuring the LAN Server

NOTE

LAN is only supported with 32-bit SICL and VISA on Windows 95 and Windows NT.

To configure the LAN server for the I/O Libraries, you need to provide the following information.

- **Server Timeout** is the timeout value, in seconds, used by the LAN server when SICL applications either use the default timeout value, or set the timeout to 0 (infinity). The default is 120 seconds.
- **Log Errors** specifies whether you want to log LAN server errors, or not.
- **Log Locks and Connections** specifies whether you want to log locks and connections over the LAN, or not.
- **Use Keepalive Client Probes** specifies whether you want keepalive client probes done, or not.

If the configuration values that are displayed for Server Timeout, Log Errors, Log Locks and Connections, and Use Keepalive Client Probes are acceptable to you, click on the **OK** button.

Otherwise, you can change the configuration values either by clicking on the arrows next to the values, or, if there are no arrows, by typing in the values you want. At any time, you can press the **Defaults** button to return the configuration dialog box to its default configuration values for the LAN server.

When you are done changing the values, either press the **OK** button if you want I/O Config to accept the changes, or press the **Cancel** button to cancel the changes and return to the previous configuration values for the LAN server.

