

## Sheet1

### MIDI Channel Messages

Note Off	8n kk vv	kk = key number (0-127) vv = velocity (0-127)
Note On	9n kk vv	kk = key number (0-127) vv = velocity (1-127, 0 = note off)
Polyphonic After Touch	An kk tt	kk = key number (0-127) tt = after touch (0-127)
Control Change	Bn cc xx	cc = controller (0-121) xx = value (0-127)
Channel Mode:		
Local Control	Bn 7A xx	xx = 0 (off), 127 (on)
All Notes Off	Bn 7B 00	
Omni Mode Off	Bn 7C 00	
Omni Mode On	Bn 7D 00	
Mono Mode On	Bn 7E cc	cc = number of channels
Poly Mode On	Bn 7F 00	
Program Change	Cn pp	pp = program (0-127)
Channel After Touch	Dn tt	tt = after touch (0-127)
Pitch Wheel Change	En 11 hh	ll = low byte (0-127) hh = high byte (0-127)

NOTE: n = channel number, 0-15