Installation Procedure of
DESKO ChipCardReader Interface

A. Connecting the Device

Please only connect the Smart Card Terminal when the PC is switched-off !! Then the device will be connected as follows:

1. DESKO CLE 3433 (integrated Chipcard- Terminal)
Plug the keyboard cable into the keyboard port of the PC instead.
Switch-on the PC. Now the Smart Card Terminal is working.

2. DESKO CL 4000 (Stand Alone Reader)
Unplug the keyboard cable from the PC and plug the Y-cable of the Smart Card Terminal into the keyboard connector instead. Now, plug the keyboard cable into the female connector of the Y-cable.
Switch-on the PC. If the green LED is on, the Smart Card Terminal is now working.

B. Software Installation

1. PC/SC Windows NT

    a) Install the Microsoft SmartCard Base Components (Execute: A:\SCBASE.EXE)

    b) Execute the supplied setup.cmd and restart the PC.

2. PC/SC Windows ´98

Select „Hardware" in the System control panel and follow the instructions.
Select „No the hardware component is not on the list"
Click the button „Disk" and select the file *Ps2card.inf* from the supplied disk.
Confirm your Selection.
After installation reboot your PC.

    a) Install the Microsoft SmartCard Base Components (Execute: A:\SCBASE.EXE)

    b) Click „Start" and select „Control Panel" from the „Settings" menu

    c) Option "Hardware"

    d) Install the DESKO CL 4000 PS/2 Smart Card Reader using the Hardware Assistant.

        Select Type of hardware as „Other components"

        Open the file *Ps2card.inf* from directory A:\WIN98 .

        Press "OK" to install the "DESKO CL4000 PS/2 Smart Card Reader" .

    e) Restart your PC.

3. CT-API Windows ´95/ ´98, Windows NT

Start the Setup Program on the Diskette supplied (setup.exe).

Please note: All other programs are closed and you probably have administration rights on the PC.

Follow the instructions of the installation program.

After having ended the installation procedure, re-start the PC so that all drivers can be loaded.