You can raise or lower the VOLUME by moving the GREEN knob to the LEFT or RIGHT. Move the knob to

the LEFT to LOWER the sound volume - moving it to the far left turns OFF the sound. Move the knob to the

RIGHT to RAISE the volume - moving it to the far right turns the sound level to HIGH.