



In some houses the black and yellow are already wired in others you will have to go out to your box and rewire it. A good way to figure out which line is which is to take the phone you are looking for off the hook. Then you only need to take the red and green wires entering your phone and hook them to the different pairs of red and green going into the house. You can't hurt anything in the phone or telephone by probing. When you find the pair that you want take the black from your line and attach it to the red of the other line then take the yellow and attach it to the green line. Now you are all set to go. For people with rotary phones you can have one person call you then place the second call out to the other person. Though not a phreakers tool, the brown box can be phun.

Written by The Doc & Edited by 13th Floor Enterprises