

GOLD BOX PLANS: COURTESY OF SIR WILLIAM

HOW TO BUILD IT

YOU WILL NEED THE FOLLOWING:

TWO 10K OHM AND THREE 1.4K OHM RESISTORS, TWO 2N3904 TRANSISTORS,
TWO PHOTOCELLS, TWO RED LED'S (THE MORE LIGHT PRODUCED THE BETTER), A BOX THAT WILL NOT LET LIGHT IN, AND RED AND GREEN WIRE.

LIGHT FROM THE #1 LED MUST SHINE DIRECTLY ON THE PHOTOCELL #1. THE GOLD BOX I MADE NEEDED THE TOP OF THE LED'S TO TOUCH THE PHOTOCELL FOR IT TO WORK. THE SAME APPLIES TO THE #2 PHOTOCELL AND LED

```
1
  :-PHOTOCELL--:
  :
:
  :
:BASE
  :
1   TTTTT
  : +LED-  TRANSISTOR
  :
  :   TTTTT
  :
::
  : -I(--
: :COLLECTOR
RED1--<      >:--: :-----:-----GREEN2
  -I(-- :
-----:
```

```

:
:
2  :-/+/+/-+/+/-+/+/-+/+/
    LED    10K    10K    1.4K 1.4K

```

RESISTORES

```

2
- PHOTOCELL-----
:
:
: BASE
:
: TTTT
:
: TRANSISTOR
:
: TTTT
:
: :EMITTER
:
GREEN1- -----RED2
:
:
: /+/+
: 1.4K

```

THE 1.4K RESISTOR IS VARIABLE AND IF THE SECCOND PART OF THE GOLD BOX IS SKIPPED IT WILL STILL WORK BUT WHEN SOMEONE PICKS THE PHONE UP THEY

WILL HEAR A
FAINT DIAL TONE IN THE BACKGROUND AND MIGHT REPORT IT TO THE GESTOPO
ER...(AT&T). 1.4K WILL GIVE YOU GOOD RECEPTION WITH LITTLE RISK OF A
GESTOPO
AGENT AT YOUR DOOR.

NOW THAT YOU HAVE BUILT IT TAKE TWO GREEN WIRES OF THE SAME LENGTH
STRIP THE
ENDS, TWIST TWO ENDS TOGETHER AND CONNECT THEM TO GREEN1 AND PLACE
A PEICE OF
TAPE ON IT WITH LINE #1 WRITING ON IT.
CONTINUE THE PROCESS WITH RED1 ONLY USE
RED WIRE. REPEAT WITH RED2 AND GREEN2 BUT CHANGE TO LINE #2.

HOW TO INSTALL

YOU WILL NEED TO FIND TWO PHONE LINES THAT ARE CLOSE TOGETHER.
LABEL ONE OF
THE PHONES LINES LINE #1.CUT THE PHONE LINES AND TAKE THE OUTER
COUTING OFF IT.
THERE SHOULD BE 4 WIRES CUT THE YELL OW AND BLACK WIRES OFF AND STRIP
THE RED
AND GREEN WIRES FOR BOTH LINES.

LINE #1 SHOULD BE IN TWO PEICES TAKE THE GREEN WIRE OF ONE END AND
CONNECT IT
TO THE ONE OF THE GREEN WIRES ON THE GOLD BOX.
TAKE THE OTHER HALF OF LINE # 1
AND HOOK THE FREE GREEN WIRE TO THE GREEN WIRE ON THE PHONE LINE.
REPEAT THE
PROCESS WITH RED1 AND THE OTHER LINE.

ALL YOU NEED TO DO NOW IS TO RIGHT DOWN THE PHONE NUMBERS OF THE
PLACE YOU
HOOKED IT UP AT AND GO HOME AND CALL IT . YOU SHOULD GET A DIAL
TONE!!! IF NOT
LEAVE ME A MESSAGE ON THE MODEM MADNESS BBS 516-569-0589 OR TRY
CHANGING THE
EMITTER WITH COLLECTOR. OH AND HOOKING IT UP TO A PAYPHONE IS A
FEDERAL OFFENCE
AND IS ILLEAGAL TO PUT ON ANY PHONE. I RECOMMEND YOU SEE YOUR LOCAL
POLICE
DEPARTMENT BEFORE DOING ANYTHING SAID IN THIS ARTICLE.
(HAHAHAH A!!!!!!)

