

INSTRUCTIONS FOR CONSTRUCTION AND USE OF COMPUTER/FAX INTERFACE CABLE

Construction:

(See fig. below)

1. Cutting red* lead, connect one side to resistor.
2. Connect other end of resistor to black lead of 9V battery connector.
3. Connect red lead of battery connector to other red phone cable lead.

Operation:

1. Connect cable between phone line jack of fax machine and phone line jack of computer fax/modem.
2. Insert document to be scanned into fax machine.
3. Initiate manual fax receive on computer (refer to fax software documentation).
4. Pick up fax machine handset and listen for high pitch tone from computer.
5. When heard, initiate fax transmission from machine (usually by pressing "Start" or "Send").

* In the event that the modular phone cable does not use colored leads use middle two conductors.

NOTE: Either end of cable may be connected to either device. Also, polarity of battery leads is irrelevant but, to clarify the diagram, a given polarity was arbitrarily selected.

