

Sheet1

Loudspeaker Enclosure Designer... data file template, v1.0A

Driver: BTW-1048

Brand: MTX

Fs:	24.0000
Vas:	6.0000
Qts:	0.3800
Qms:	1.7000
Qes:	0.4900
Sd:	0.0324
Xmax:	9.1440
Revc:	7.3000
Znom:	8.0000
Pmax:	100.0000

Comments:

Blue Thunder 10" 8ohm

Sheet1

Driver's model #.
Driver's brand name.
Hz (Free air resonance)
ft³ (Compliance volume)
Total Q
Mechanical Q
Electrical Q
M² (Piston area)
mm (Cone excursion)
ohms (DC resistance)
ohms (Nominal impedance)
watts maximum rated power

Press <ALT-S> to save this file.

Sheet1

{HOME}{GOTO B3}/fs{up}\aseasy\led\drivers\~{dn}{BEEP}{?}~{BEEP}

	#NAME?
Convert for Vas:	0.0000
	0.0000
Derive Qes from Qts/Qms:	
derived Qes:	
Convert for Sd:	8.0000
Convert for Xmax:	0.3600
	◆◆◆◆◆◆◆◆

