FT-2400H Frequency Mod

- -Remove front panel (2 allen screws)
- -Locate and unsolder jumper pad 2
- -Locate and solder jumper pads 1 & 3
- -Install front panel

Result 118-174 Rx 140-174 TX

Cpu w/

Battery 1 2 3 4 5 6 <-jumpers CHIP w/ On top Yaesu on it.

Notes,

Jumper 2 has a BLOB of solder on it. It is the only one that is soldered. The jumpers are in the center of the control board. JP6 is for the 1750hz European tone burst. JP4 makes it a UHF radio??