



SANDWASH

Bring the rugged outdoors inside with sand and color.

Tools and Materials

3" or 4" Nylon/Polyester Paintbrush, 3/4" Nap Roller, Gloves, Drop Cloth, Paint Tray, BEHR SandWash

Application Tip: For best results, apply a tinted primer to your wall in a color that is close to your selected SandWash color.

Apply two coats of SandWash to achieve an even finish.

First Coat:

- Begin at the top corner and use a paintbrush to cut in a 2 ft. strip across the ceiling edge and down the corner of the wall.
- Generously load a 3/4" nap roller with SandWash, filling in the 2 ft. x 2 ft. area. Continue to cut in and roll out 2 ft. x 2 ft. sections, creating a column down the wall. Overlap sections slightly to maintain a wet edge.
- As each column is complete, reload the roller and apply a thin coat of SandWash, covering the entire column area. Repeat this process as you complete each column across the entire wall.
- The first coat will appear uneven. Allow four hours to dry completely before applying the second coat.

Second Coat:

- Apply your second coat of SandWash using the same process as the First Coat. Allow the finish to dry 24 hours.

For added Durability and Protection:

Use BEHR Crystal Clear Water Based Polyurethane for high traffic or high moisture areas. Topcoating will enhance or darken the color of the SandWash finish.