

*User Mode* *Program with Control*  
*Internal CD*     ◦ *Full Playthrough*     ◦ *44.100 kHz*

*System Mode (660AV & 840AV)* *Command*  
*Microphone*     ◦ *No Playthrough*     ◦ *24.000 kHz*

*System Mode (Power Macintosh)* *Command*  
*Microphone*     ◦ *No Playthrough*     ◦ *22.050 kHz*