Mt. verything will throw away the disk's driver after successfully unmounting the volumes on the disk and stopping it. Thus on next "Mount" the driver will be reinstalled.