

## MEMORY MENU,

This menu is used to control the transceiver's internal memories. It will allow you to save the current memory contents to a text file which uses the same format as the database file or load a new set of internal memories from a saved file.

Use of Internal Memories.

## RECALL INTERNAL MEMORIES,

If you click on the "SHOW," button you will be given a list of the internal memories contained in the transceiver itself. Clicking one of these will then recall that memory in the transceiver.