

Eject Button

Use the Eject button to eject all floppy disks. This is useful if you want to examine a different floppy disk.