
IO-PS110

*PCI 32 bit P&P
1Port (16c550 16FIFOs)*

CE

USER MANUAL

DESCRIPTION:

The IO-PS110 32Bit PCI bus Plug & Play 1S I/O card is equipped with one High-Speed RS-232 Standard Serial-Interface, The serial port include 16 Byte FIFO, The IO-PS110 include one 9 pin male connector for attaching peripheral's unit with Serial RS-232 Standard Interface.

HARDWARE SPECIFICATION

Serial Port:

UART Chipset: NM9820CV, Hardware FIFO is 16Byte FIFO,

Compatible chips: with 16C550

IEEE standard: RS-232 Interface

HARDWARE INSTALLATION GUIDE:

- Turn off the power of your computer
- Plug-in the IO-PS110 MIO Series Adapter to PCI bus of your computer
- Add-on the peripheral (Printer, Modem, Scanner... etc.) that you need to this Adapter
- Turn on the power of your computer
- After The Screen, your Card install correct, you can install WINDOWS 95,98,NT, 2000 or LINUX, Please see INSTALL GUIDE

TECHNICAL SPECIFICATION:

| | |
|--|---|
| Operating system: | -DOS, WIN 95, 98, ME, 2000, XP, NT, LINUX |
| Chips: | -1 x NM9820CV |
| Connections: connector serial | -1 x 9 Pin D-SUB male |