HP DeskJet 500C Application Note for Harvard(tm) Graphics Ver. 3.0

Use the installation utility contained on the "HP DeskJet 500C Color Driver Disk for DOS", to copy the DESKJETC.PN3 file to the ...\HG3\DRIVER directory on your hard disk.

<u>Setting Up Harvard(tm) Graphics</u>

- 1. Start the Harvard(tm) Graphics program.
- 2. From the F6-Main Menu, press 8 (Setup).

3. Press 5 (Printer 1).

4. From the Printer 1 Setup Menu press F3 (Choices).

- 5. Use the down arrow key to highlight one of the following, then press <Enter>.
 - HP DeskJet 500C Choose this for color output on paper. HP DeskJet 500C Mono Choose this for black & white output.
 - HP DeskJet 500C Transparency Choose this for transparency output.
- 6. Press the down arrow key to position the cursor across from "Output' Port".

7. Press F3 (Choices).

- 8. Use the arrow keys to select the port where your printer is connected, then press <Enter>.
- 9. Press the down arrow key to position the cursor across from "Default paper size", then press F3 (Choices).
- 10. Use the arrow keys to select the correct paper size, then press <Enter>.
- 11. Use the arrow keys to position the cursor across from "Use spooler".
- 12. Press F3 (Choices), and select "Yes".

 NOTE: Setting "Use spooler" to "Yes" activates the integral spooler and allows you to get back to Harvard Graphics sooner when printing. With it set to "No", you'll have to wait until the print job is nearly finished in order to continue working. If you do not wish to use the integral spooler, (for example, when using an external hardware or software spooler) set "Use spooler" to "No".
- 13. Use the arrow keys to position the cursor across from "Quality".

14. Press F3 (Choices).

15. Select one of the following "Quality" options, then press <Enter>.
 High: Presentation/best quality.
 Medium: Normal/medium quality (faster printing than "High").

Medium: Normal/medium quality (faster printing than "High"). Draft: Use to "proof" your work before printing a final copy.

16. Press <Enter>.

17. Press 1 (Program Defaults).

- 18. Using the arrow keys, move the cursor down to the bottom of the screen across from "Max. spooler size (K):".
- 19. Type 3072 as the spooler size, then press <Enter>. NOTE: This sets the spooler size to approximately 3Mb. Since Harvard Graphics creates this 3Mb file on your hard disk, make sure that you have enough disk space to accommodate it. Lowering the spooler size will increase the time it will take to free up your PC while printing. If you are using an external spooler (hardware or software solution), set the "Use spooler" option to "No" in the Printer Setup Menus.
- 20. Press the Esc key.

Printing from Harvard(tm) Graphics 3.0

- 1. From the F6-Main Menu press 5 (Output).
- 2. Press 1 (Printer 1).
- 3. Check to see if all of the printing information is correct, then press F10-Continue to print.