


AUTOBOOT COMMANDER™



- Supports all 100% IBM compatible PCs
- Works with both PS/2 and serial mice
- Optional Macintosh and Sun support

**Monitor and operate multiple PCs
or file servers with just one
keyboard, monitor and mouse!**

AutoBoot Commander is the simple, efficient and cost effective way to monitor and control multiple PCs or file servers from a single location.

AutoBoot Technology

Commander's built-in AutoBoot feature intelligently manages the boot process for all attached computers. Commander will boot all computers simultaneously without operator intervention. By fully emulating a keyboard and mouse at every computer, AutoBoot technology assures error-free booting every time.

Scanning and Broadcast Capability!

Commander's built-in scanning feature lets you scan through the PCs in your system sequentially without user intervention! Your keyboard remains operational during the scan process; scanning will pause while you work, then resume with the next channel in sequence. With Commander's Broadcast Mode, you can enter data into multiple PCs at the same time. You choose which computers to broadcast to. Once in Broadcast Mode, whatever you type will be sent to all of the computers you have designated.

Add-on Expandability

AutoBoot Commander keeps pace with

your growing system. A base unit supports from two to eight computers. Expansion units can be added, supporting up to eight additional computers each. Up to 12 units can be linked together for a total of 96 computers controlled by one keyboard, monitor and mouse!


Add a Second Control Center

Add more control to your system with the Dual Access option. A second keyboard, monitor and mouse can control all attached PCs up to 150 feet away from the Commander.



AUTOBOOT COMMANDER™

Functional Diagram



Base Unit	Expansion Unit††
AR-n Replace 'n' with the number of computers to be attached - from 1 to 4	AE-n Replace 'n' with the number of computers to be attached to the expansion unit - from 2 to 8

Cable Assemblies

Video	Keyboard	Cable Type	Mouse	8 ft.†	25ft.	50 ft.	100 ft.	150 ft.
MDA CGA EGA	5-pin	Rack Mount	None Serial PS/2	CCR-8 CER-8 CDR-8				
	●	Single Sender Dual Sender			CCS-25 CCD-25	CCS-50 CCD-50	CCS-100 CCD-100	CCS-150 CCD-150
	6-pin	Rack Mount	None Serial PS/2	** ** **				
	●	Single Sender Dual Sender			CCS-25* CCD-25*	CCS-50* CCD-50*	CCS-100* CCD-100*	CCS-150* CCD-150*
VGA	5-pin	Rack Mount	None Serial PS/2	CVR-8 CMR-8 CPR-8				
	●	Single Sender Dual Sender			CVS-25 CVD-25	CVS-50 CVD-50	CVS-100 CVD-100	CVS-150 CVD-150
	6-pin	Rack Mount	None Serial PS/2	C2R-8 CSR-8 CIR-8				
	●	Single Sender Dual Sender			C2S-25 C2D-25	C2S-50 C2D-50	C2S-100 C2D-100	C2S-150 C2D-150
Sun		Rack Mount	Sun	CWSC-8				

Distributed By

IBM, PC, and PS/2 are registered trademarks of International Business Machines Corporation. Macintosh is a registered trademark of Apple Computer, Inc. Sun is a trademark of Sun Microsystems. Cybex, AutoBoot, Commander and all part numbers are trademarks of Cybex Corporation.

© Copyright 1995 Cybex Corporation



4912 Research Drive
Huntsville, Alabama 35805 USA

205/430-4000 Fax 205/430-4030

* With KAD-1 adaptor. Contact the Cybex Sales Department.

** Special order. Contact the Cybex Sales Department.

† Distance can be extended in 5 ft. increments up to an additional 20 ft. Order CXT-5, CXT-10, CXT-15, or CXT-20.

†† Includes 18 in. expansion cable. Distance can be extended in 5 ft. increments up to an additional 20 ft. Order CXP-5, CXP-10, CXP-15, or CXP-20. Maximum total distance between all units is 50 ft.