

## SYMBOL TABLE ENTRY BITS IN USE FOR THE ARMADILLO

```

BIT POSITIONS  |
                | MEANING WHEN SET
0|1|2|3|4|5|6|7|
-----
| | | |*|*|*|*| ARRAY BIT
-----
| | |*| | | | | UDF BIT
-----
| |*| | | | | | SHARED BIT
-----
|*| | | | | | | STRING BIT
-----
*| | | | | | | | INTEGER BIT
-----
*|*| | | | | | | SUBROUTINE BIT

```

```

BIT POSITIONS  |
                | MEANING WHEN SET
0|1|2|3|4|5|6|7|
-----
| | | | | | |*| PASSED BY REFERENCE
-----
| | | | | |*| | ARRAY
-----
| | | | |*| | | STRING
-----
| | | |*| | | | INTEGER

```

```

BIT POSITIONS  |
                | MEANING WHEN SET
HEX  0|1|2|3|4|5|6|7|
-----
0    | | | | | | | | NUMERIC REAL SCALER PASSED BY VALUE
-----
1    | | | | | | |*| NUMERIC REAL SCALER PASSED BY REFERENCE
-----
3    | | | | | |*|*| NUMERIC REAL ARRAY PASSED BY REFERENCE
-----
4    | | | | |*| | | STRING SCALER PASSED BY VALUE
-----
5    | | | | |*| |*| STRING SCALER PASSED BY REFERENCE
-----
7    | | | | |*|*|*| STRING ARRAY PASSED BY REFERENCE
-----
8    | | | |*| | | | INTEGER SCALER PASSED BY VALUE
-----
9    | | | |*| | |*| INTEGER SCALER PASSED BY REFERENCE

```

-----+-----  
B        I I I I\* I I\*I\*I INTEGER ARRAY PASSED BY REFERENCE