

NE2000 Compatible ISA Adapters Setup

Use this dialog box to configure settings for the
IBM ISA Ethernet Adapter
D-Link DE-220 Ethernet Adapter
LinkSys Ether16 Ethernet Adapter

IRQ Level

Select an interrupt level for his adapter. Do not set this to IRQ3 if you have two COM ports (COM1=IRQ4 and COM2=IRQ3).

I/O Port Address

Select a number (expressed as a hexadecimal string) to specify the I/O port base address.

