## **Topic for ANSI IBM Terminal:**

Operating Mode

## **Help for Operating Mode**

The Operating Mode determines whether the emulation can display only the standard 128 ASCII character codes or the entire 256-character set.

**Note:** The Communications Parameters must be set for 8 data bits and no parity for 8-bit mode to be fully operational.

For additional information, select:

**Operating Mode** 

## **Operating Mode**

Select either 7-Bit or 8-Bit operating mode for the emulation.

If 7-Bit is selected, the characters displayed are limited to the standard 128 ASCII character codes.

If 8-Bit is selected, the characters displayed can include the entire 256-character set of the personal computer including graphics characters.

**Note:** The Communications Parameters must be set for 8 data bits and no parity for 8-bit mode to be fully operational.