

Sheet1

PRN_DESC,C,35	PITCH10,C,25	COMPRESSED,RESET,C,25	LINES6,C,25
Anadex DP-6500	\027Q	\027R	\027H
Anadex DP-9000	\018		\027H
Anadex DP-9001	\018	\026	\027H
Blaser	\018	\015	\027(
Brother HR1	\027P	\027M	\017
Brother HR15/25		\027M	\017
C. Itoh 8510A	\027N	\027Q	\017
C. Itoh F10	\027E12	\027E08	
Canon LBP-8 A1/A2	\027\031\013	\027\031\009	\027\058\027\013P
Canon LBP-8 A1/A2 (ISO)	\155\048\032K	\155\049\032K	\027c
Centronics 351/352/353	\027[1w	\027[4w	
Centronics H80-1/H80-2	\018	\015	\027@
Citizen MSP-10/MSP-15	\027P	\015	\027@
Comrex CR-I	\027P	\027M	\017
Comrex CR-II	\027\031\013	\027\031\009	\017\027\013P
DaisyWriter 1500/2000	\027P	\027M	\017\027\026S
Diablo 620 & 630	\027\031\013	\027\031\009	\017\027\013P
Epson E/F/J/L/RX/LQ	\027P\018	\015	\027@
Epson MX	\018	\015	\027@
Epson LX-90	\018	\015	
Generic Printer			\027@
HP LaserJet (+/II/IIP/III)	\027&k0S\027(s0T	\027&k2S	\027E
IBM Graphics Printer	\018	\015	
IBM Color Printer	\018	\015	\027?
IBM Proprinter	\018	\015	
IBM Quietwriter 5201	\015\027X\001\132	\027X\001\198	
IBM Wheelprinter 5216	\018	\015	\017
Juki 6100	\027\031\013	\027\031\009	\027\026\027Q
Mannesmann MT160/180	\027[4w	\027[6w	\027[6~
Mannesmann Spirit-80	\018	\015	\027@
NEC Pinwriter P2/P3	\027?1	\027?7	
NEC Pinwriter P5/P6/P7	\027P	\027g	\027@
NEC Spinwriter 3550	\027S	\027\015	\027=
NEC Spinwriter 7710/20	\027]L	\027]H	\027#B
NEC Spinwriter 7715/25	\027]L	\027]H	\027\026R
NEC Spinwriter 7730	\027]L	\027]H	
Oki Microline 182/183	\018	\015	
Oki Microline 192/193	\018	\015	
Oki Microline 292/3/4	\018	\015	
Oki Microline 82A/83A	\030	\029	
Oki Microline 84/92/93	\030	\029	\024
Oki Okimate 20	\018	\015	
Oki Pacemark 2350	\0276	\027B	
Oki Pacemark 2410	\0276	\027B	\024
Oki Pacemark 2410-IBM	\018	\015	
Panasonic KX-P1090	\027P\001	\027P\015	\017\027@
Panasonic KX-P1091	\027P	\015	\017\027@
Panasonic KX-P3151	\027\031\013	\027\031\009	\027\026I
Quadram QuadJet	\027N		\017
Qume Sprint 5		\027[\027\026I
Silver Reed 550	\027\031\012	\027\031\008	\027\013P
Silver Reed 770	\027\031\013	\027\031\009	\027\013P

Sheet1

Star Gemini 10-X/15-X	\027B\001	\027B\003	\027@	\0272
Star Radix 10/15	\027B\001	\027B\003	\027@	\0272
Toshiba P 341/351		\027[\027\026I	\027\030\009
Toshiba P1340		\027[\027\026I	\027\030\009
Toshiba P1350/1351		\027\031\009	\027\026I	\027\030\009

LINES8,C,25 PORTRAIT,C,2LANDSCAPE,C,25

\027I
\027I
\027I
\0270

\027\030\007
\027B
\027L06
\027\030\007 \000 \000
\155\052\032B \155\048\037r \155\049\037r
\027[2z
\0270
\0270

\027\030\007
\027806
\027\030\007
\0270
\0270
\0270

\027&I8D \027&I00 \027&I10
\0270
\0270
\0270
\0270
\0270
\027\030\007
\027[4z
\0270
\0270
\0270
\0270
\027]U
\027]U
\027]U
\0270
\0270
\0270
\0278
\0278
\027A\012
\0275

\0270
\0270
\0270
\027\030\007
\027F\008
\027\030\006
\027\030\007
\027\030\007

\0270

\0270

\027\030\007

\027\030\007

\027\030\007