

AOpen BIOS Afbfvff [fg

homepage: <http://www.aopen.com.tw/>

'1 FŠeff [f^, i'~ iCE, í A "Á•Ê, ì'f, è, ð, È, ç, ©, ¬, èŠJ"-
f [fj] [É<A'® ,µ,Ü,·B

'2 FŽû~ ^ ŠeŽĐ, ", æ, ÑDOS/V POWER
REPORT•ÒW•", Á, í AfAfbfvff [fg, É, æ, é
, ç, ©, È, é "ŠQ, ÉŠÖ, µ, Ä, à^ê ØÓ" C, ð•%o, ç, Ü, ¹, ñ, ì, Á, , ç, ©, ¶, ß, ²—¹³, -
, ³/₄, ³, ç B



à-¾, ð•Ž!, µ, Ü, ·B

UP! X V, ³, è, ½ftf@fCf<

ft [fefBšfefB

Award Flash ROM Utility R1.40 1998/1/23 UP!

DISC2:\BIOS\AOPEN\AOFLASH

Checksum Utility 1995/7/3

DISC2:\BIOS\AOPEN\CHECKSUM

AMI Flash ROM Utility V5.24 1997/4/9

DISC2:\BIOS\AOPEN\AMIFLASH

• **PentiumII f}fU [f{ [fh**

• **AX6L**

AX6L BIOS R1.30 1997/11/26

DISC2:\BIOS\AOPEN\AX6L130

• **AX6F**

AX6F BIOS R2.10 1997/10/7

DISC2:\BIOS\AOPEN\AX6F210

• **PentiumPro f}fU [f{ [fh**

• **AX65**

AX65 BIOS R1.20 1997/12/4

DISC2:\BIOS\AOPEN\AX65120

• **AP65**

AP65 BIOS R1.40 1997/12/4

DISC2:\BIOS\AOPEN\AP65140

 **AP61**

AP61 BIOS R1.20 1996/5/12

 [DISC2:\BIOS\AOPEN\AP61R120](#)

 **Pentium f}fU[f{[fh**

 **AP5T**

AP5T BIOS R1.70I 1998/1/21 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AP5T17I](#)

 **Bus Master IDE Driver**

BMIDE Bus Master Driver V3.01 for Win95 1997/6/21

 [DISC2:\BIOS\AOPEN\BMIDE_95](#)

BMIDE Bus Master Driver V2.01.3 for NT 1997/7/3

 [DISC2:\BIOS\AOPEN\BMIDE_NT](#)

AP5T BIOS R1.60 1997/11/4

 [DISC2:\BIOS\AOPEN\AP5S160](#)

 **AX5T**

AX5T BIOS R1.70CI 1998/1/21 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AX5T17CI](#)

AX5T BIOS R1.60 1997/11/4

 [DISC2:\BIOS\AOPEN\AX5T160](#)

 **AX65**

AX65 BIOS R1.30A 1998/1/6 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AX65130A](#)

 **AX6L**

AX6L BIOS R1.40CD 1998/1/21 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AX6L14CD](#)

 **AP58**

AP58 BIOS R1.40L 1998/1/20 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AP58140L](#)

AP58 BIOS R1.30 1997/12/31 

 [DISC2:\BIOS\AOPEN\AP58130](#)

 **AP5C**

AP5C BIOS R2.20CS 1998/1/20 Beta BIOS (Evaluation Version) 

 [DISC2:\BIOS\AOPEN\AP5C22CS](#)

 **AP5C • AP5C/P**

AP5C & AP5C/P BIOS R2.01A 1996/9/6 (for SMC1665IR Super I/O Only)

 [DISC2:\BIOS\AOPEN\AP5C201A](#)

AP5C & AP5C/P BIOS R2.10S 1996/11/10 (For SMC665GT only)

 [DISC2:\BIOS\AOPEN\AP5C210S](#)

 **AP5CS**

AP5CS BIOS R1.50 1996/10/18

 [DISC2:\BIOS\AOPEN\AP5CS15](#)

 **E-IDE Driver**

AP5CS EIDE R1.1 Driver

 [DISC2:\BIOS\AOPEN\AP5CSR11](#)

 **NSIDE Driver**

NSIDE Driver for Win95

 [DISC2:\BIOS\AOPEN\NSIDE95](#)

 **DP5**

 **NSIDE Driver**

NSIDE Driver for Win95

 [DISC2:\BIOS\AOPEN\NSIDE95](#)

DP5 BIOS R1.10A 1995/1/17

 [DISC2:\BIOS\AOPEN\DP511A](#)

 **AP5V□•AP5VM-1**

AP5V & AP5VM-1 BIOS R1.70 1997/11/18

 [DISC2:\BIOS\AOPEN\AP5V170](#)

 **AP55CS**

 **VGA Driver**

VGA Driver for Windows 95 (Evaluation only) R1.15 1996/11/18

 [DISC2:\BIOS\AOPEN\205115-2](#)

VGA Driver for Windows NT 5.0 (Evaluation only) R1.15 1996/11/18

 [DISC2:\BIOS\AOPEN\205115-3](#)

VGA Driver for Windows 3.1 (Evaluation only) R1.10 1996/5/25

 [DISC2:\BIOS\AOPEN\205110-3](#)

AP55CS BIOS R1.15 1996/11/18

 [DISC2:\BIOS\AOPEN\55CS110](#)

 **AP5S**

AP5S BIOS R.1.60 1997/9/19

 [DISC2:\BIOS\AOPEN\AP5S160](#)

 **AP53□•AX53**

AP53 & AX53 BIOS R3.C0 1997/11/3

 [DISC2:\BIOS\AOPEN\AP53R3C0](#)

 **AP5VM-2/-3**

AP5VM-2/-3 BIOS R2.70 1997/11/3

 [DISC2:\BIOS\AOPEN\AP5VM270](#)

 **LP5**

LP5 BIOS R2.00 1996/8/26

 [DISC2:\BIOS\AOPEN\LP5R200](#)

 **AP5K**

AP5K BIOS R1.40 1997/5/27

 [DISC2:\BIOS\AOPEN\AP5K140](#)

 **AP57**

AP57 BIOS R1.40 1997/11/20

 [DISC2:\BIOS\AOPEN\AP57140](#)

 **486 f}fU□[f{□[fh**

 **VI15G**

VI15G BIOS R2.3 1995/6/28

 [DISC2:\BIOS\AOPEN\VI15GR23](#)

 **AP4X**

AP4X BIOS R1.61S 1996/3/12 (Super IO SMC665GT only)

 [DISC2:\BIOS\AOPEN\AP4161SS](#)

 **E-IDE Driver**

SiS596/597 E-IDE Driver R3.7 1995/6/28

 [DISC2:\BIOS\AOPEN\AP4EIDE](#)

AP4X BIOS R1.61 1996/3/12 (Super IO SMC2065IR only)

 [DISC2:\BIOS\AOPEN\AP4161SA](#)
