


# Elitegroup ComputerSystems BIOS

homepage: <http://www.ecs.com.tw/>

'1 FŠeff [f^, i'~ iCE, í A "Á•Ê, i'f, è, a, È, ç, ©, -, èŠJ"-  
f [fj] [L, É<A'®, µ, Ü, · B

'2 FŽû~ ^ ŠeŽĐ, ", æ, ÑDOS/V POWER  
REPORT • Ö W • ", Á, í AfAfbfvff [fg, É, æ, é  
, ç, ©, È, é "ŠQ, ÉŠÖ, µ, Ä, à ^ ê Ø Ó "C, ð • %oo, ç, Ü, <sup>1</sup>, ñ, Ì, Å, , ç, ©, ¶, ß, <sup>2</sup>—<sup>1</sup>³, -  
, <sup>3</sup>/<sub>4</sub>, <sup>3</sup>, ç B

 目次へ戻る

 BROWSE à-¾, ð • Ž!, µ, Ü, · B

**NEW!** V<K, ÉŽû~ ^, <sup>3</sup>, è, ½ftf@fCf<  
**UP!** X V, <sup>3</sup>, è, ½ftf@fCf<

- PentiumII f}fU [f{ [fh
- P6KFX-A

P6KFX-A PCB1.1,1.2 BIOS Ver1.5

 [DISC2:\BIOS\ELITE\P6KFXA15](#)

P6KFX-A PCB2.0 BIOS Ver2.2

 [DISC2:\BIOS\ELITE\P6KFXA22](#)

- P6LX2-A

P6LX2-A PCB1.0(W/Z SCSI, 2Mb) BIOS Ver1.3 **UP!**

 [DISC2:\BIOS\ELITE\LX2A13](#)

- P6LX-A

P6LX-A PCB1.1a(W/O SCSI, W/Z LM78, 1Mb) BIOS Ver2.3 **UP!**

 [DISC2:\BIOS\ELITE\LXA23](#)

P6LX-A PCB1.1a(W/O SCSI, W/O LM78, 1Mb) BIOS Ver3.0

 [DISC2:\BIOS\ELITE\P6LXA30](#)

P6LX-A PCB1.1a(W/Z SCSI, W/Z LM78 2Mb) BIOS Ver1.2

 [DISC2:\BIOS\ELITE\P6LXA12](#)


- P6LX-A+

P6LX-A+ PCB1.1 BIOS Ver1.0 **NEW!**

 [DISC2:\BIOS\ELITE\P6LXAP10](#)

- PentiumPro f}fU [f{ [fh
- P6FX1-A

**P6FX1-A PCB1.0,1.1,1.2 BIOS Ver1.5**

 DISC2:\BIOS\ELITE\FX1A15

- **P6FX1-B**

**P6FX1-B PCB1.0,1.0A BIOS Ver1.1**

 DISC2:\BIOS\ELITE\FX1B11

- **P6FX2-A**

**P6FX2-A PCB1.0,1.1 BIOS Ver1.2**

 DISC2:\BIOS\ELITE\FX2A12

- **Pentium f}fU[f{[fh**
- **P5HX-A**

**P5HX-A PCB1.0A BIOS Ver1.0**

 DISC2:\BIOS\ELITE\HXA10

**P5HX-A PCB2.1,2.3 BIOS Ver1.2**

 DISC2:\BIOS\ELITE\HXA12

- **P5HX-B**

**P5HX-B PCB1.0,1.1 BIOS Ver1.6**

 DISC2:\BIOS\ELITE\HXB16

- **P5HX-LA**

**P5HX-LA PCB VT/1.0A BIOS Ver1.0D**

 DISC2:\BIOS\ELITE\HXLA10D

- **P5SJ-AU**

**P5SJ-AU PCB1.0 BIOS Ver1.1**

 DISC2:\BIOS\ELITE\P5SJA11

- **P5SV-B**

**P5SV-B PCB1.0 BIOS Ver1.2**


 DISC2:\BIOS\ELITE\P5SVB10

- **P5TX-A**

**P5TX-A PCB1.0,1.2,2.0,2.1,2.2 BIOS Ver1.3**

 DISC2:\BIOS\ELITE\TXA13

**P5TX-A PCB3.0,3.1 BIOS Ver2.2**

 DISC2:\BIOS\ELITE\P5TXA22

- **P5TX-Apro**

**P5TX-Apro PCB2.X BIOS Ver1.0**

- DISC2:\BIOS\ELITE\P5TXAP10

- **P5TX-AR**

**P5TX-AR PCB1.X BIOS Ver1.1**

- DISC2:\BIOS\ELITE\P5TXAR11

- **P5TX-B**

**P5TX-B PCB1.0 BIOS Ver1.1**

- DISC2:\BIOS\ELITE\TXB11

**P5TX-B PCB2.0 BIOS Ver2.1**

- DISC2:\BIOS\ELITE\TXB21

- **P5TX-Bpro**

**P5TX-Bpro PCB2.X(W/O LM78/75) BIOS Ver2.0**

● DISC2:\BIOS\ELITE\P5TXBP20

**P5TX-Bpro PCB2.X(W/Z LM78/75) BIOS Ver1.0**

● DISC2:\BIOS\ELITE\P5TXBP10

● **P5TX-LA**

**P5TX-LA PCB1.X BIOS Ver1.0**

● DISC2:\BIOS\ELITE\P5TXLA10

● **P5VX-B**

**P5VX-B PCB1.0,1.2 BIOS Ver1.5**

● DISC2:\BIOS\ELITE\VXB15

● **P5VX-Be**

**P5VX-Be BIOS** ●

● DISC2:\BIOS\ELITE\VXBE14