


# SOYO Computer BIOS

homepage: <http://www.soyo.com.tw/>

1 FŠeff [f^, i' ~ i CE, í A "Á • Ê, ì' f, è, ð, È, ç, ©, ¬, è Š J" -  
f [fj] [É < A' ®, µ, Ü, · B

2 FŽû ~ ^ Še ŽĐ, ", æ, Ñ DOS/V POWER  
REPORT • Ö W • ", Á, í AfAfbfvff [fg, É, æ, é  
, ç, ©, È, é "Š Q, É Š Ö, µ, Ä, à ^ ê Ø " C, ð • % o, ç, Ü, <sup>1</sup>, ñ, Ì, Å, , ç, ©, ¶, ß, <sup>2</sup> - <sup>1</sup> <sup>3</sup>, -  
, <sup>3</sup>/<sub>4</sub>, <sup>3</sup>, ç B



**NEW!** V < K, É Ž û ~ ^, <sup>3</sup>, è, ½ ftf @ fCf <  
**UP!** X V, <sup>3</sup>, è, ½ ftf @ fCf <

## • ft [fefBfŠfefB

**Award Flash Utility AWDFLASH ver5.5** **UP!**

DISC2:\BIOS\SOYO\AWDFLASH

**DMI Configuration Utility for Award Flash BIOS (DOS version)**

DISC2:\BIOS\SOYO\DMICFG

## • PentiumII f}fU [f{ [fh

### • 6KB

**2b2 fo SOYO 6KB Mainboard (2Mbit BIOS) 1997/12/18** **UP!**

DISC2:\BIOS\SOYO\6KB-2B2

### • 6KA

**2a2 for SOYO 6KA Mainboard (2Mbit BIOS)**

DISC2:\BIOS\SOYO\6KA-2A2

## • PentiumPro f}fU [f{ [fh

### • 6FB

**0507b for SOYO 6FB Mainboards (1Mbit BIOS) 1997/5/7**

DISC2:\BIOS\SOYO\6FB0507B

### • 6FA

**C for SOYO 6FA Mainboards (2Mbit BIOS) 1997/3/25**

DISC2:\BIOS\SOYO\6FA-C

**1C for SOYO 6FA Mainboards (1Mbit BIOS) 1997/4/21**

DISC2:\BIOS\SOYO\6FA-1C

- Pentium f}fU[f{[fh
- 5XAE

2a1 for SOYO 5XAE Mainboard (2Mbit BIOS) **NEW!**

DISC2:\BIOS\SOYO\5XAE-2A1

1a2 fo SOYO 5XAE Mainboard (1Mbit BIOS) 1997/11/18

DISC2:\BIOS\SOYO\5XAE-1A2

- 5BT

1120J for SOYO 5BT Mainboard (2Mbit BIOS) 1998/1/23 **UP!**

DISC2:\BIOS\SOYO\5BT1120J

1b2 for the SOYO 5BT Mainboard (1Mbit BIOS) 1997/11/18

DISC2:\BIOS\SOYO\5BT-1B2

- 5TT

1120J for SOYO 5TT Mainboard (2Mbit BIOS) 1997/12/17 **UP!**

DISC2:\BIOS\SOYO\5TT1120J

- 5VX

0814J for SOYO 5VX Mainboard (2Mbit BIOS) 1997/11/18 ●

- DISC2:\BIOS\SOYO\5VX0814J

1C for SOYO 5VX Mainboard (1Mbit BIOS) 1997/10/04

- DISC2:\BIOS\SOYO\5VX-1C

- 5XA

2a5 for SOYO 5XA Mainboard (2Mbit BIOS) 1997/11/18 ●

- DISC2:\BIOS\SOYO\5XA-2A5

- 5TF

1114 for SOYO 5TF Mainboard (1Mbit BIOS) 1997/11/26 ●

- DISC2:\BIOS\SOYO\5TF1114

- 5TC(S)

1014 for SOYO 5TC(S) Mainboard (1Mbit BIOS) 1997/11/18 ●

- DISC2:\BIOS\SOYO\5TCS1015

- 5ED

1A1 for SOYO 5ED Mainboard (1Mbit BIOS)

- DISC2:\BIOS\SOYO\5ED-1A1

- 5EAS

1A3 for SOYO 5EAS Mainboard (1Mbit BIOS)

- DISC2:\BIOS\SOYO\5EAS-1A3

- 5EA

D5 for SOYO 5EA Mainboard (1Mbit BIOS)

- DISC2:\BIOS\SOYO\5EA-D5

- 31A

A4 for SOYO 31A2 Mainboard (1Mbit BIOS)

- DISC2:\BIOS\SOYO\31A-A4

- 5SA

0704B for SOYO 5SAx Mainboards (1Mbit BIOS) 1997/7/4

- DISC2:\BIOS\SOYO\5SA0704B

● **33A**

**D1 for SOYO 33A2 Mainboard (1Mbit BIOS) 1997/6/6**

● DISC2:\BIOS\SOYO\33A-D1

● **5XB**

**1a5 for SOYO 5XB Mainboard (1Mbit BIOS)**

● DISC2:\BIOS\SOYO\5XB-1A5

● **5VM**

**1001 for SOYO 5VM Mainboard (2Mbit BIOS) 1997/10/16**

● DISC2:\BIOS\SOYO\5VM1001

● **5VC**

**0721 for SOYO 5VC Mainboard (1Mbit BIOS) 1997/7/21**

● DISC2:\BIOS\SOYO\5VC-0721

● **5TX**

**B for SOYO 5TX Mainboard (2Mbit BIOS) 1997/04/29**

● DISC2:\BIOS\SOYO\5TX-B

● **5SM**

**V31 for SOYO 5SM Mainboards (1Mbit BIOS)**

● DISC2:\BIOS\SOYO\5SM-V31

● **5VD**

**B6 for SOYO 5VD Mainboard (1Mbit BIOS) 1997/10/13**

● DISC2:\BIOS\SOYO\5VD-B6

● **5VA**

**0911H for SOYO 5VA Mainboard (1Mbit BIOS) 1997/11/18**

● DISC2:\BIOS\SOYO\5VA0911H

● **5TH**

**0827 for SOYO 5TH Mainboard (1Mbit BIOS) 1997/8/27**

● DISC2:\BIOS\SOYO\5TH0827

● **5TE**

**0821A for SOYO 5TE and 5TCU Mainboard (1Mbit BIOS) 1997/10/15**

● DISC2:\BIOS\SOYO\5TE0821A

● **5TCU**

**A23 for SOYO 5TCU Mainboard (1Mbit BIOS)**

● DISC2:\BIOS\SOYO\5TCU-A23

● **5TB**

**A for SOYO 5TB Mainboard (1Mbit BIOS)**

● DISC2:\BIOS\SOYO\5TBA

● **5TA/TD**

**0823 for SOYO 5TA/5TD Mainboard with NS I/O chip (1Mbit BIOS) 1997/11/18**

● DISC2:\BIOS\SOYO\5TAN0823

● **5SW**

**A2 for SOYO 5SWx Mainboards (1Mbit BIOS)**

● DISC2:\BIOS\SOYO\5SW-A2

● **5SV**

**A2 for SOYO 5SVx Mainboards (1Mbit BIOS)**

• DISC2:\BIOS\SOYO\5SV-A2

• **5TS**

**C-4 for SOYO 5TS Mainboard (1Mbit BIOS) 1997/4/10**

• DISC2:\BIOS\SOYO\5TS-C-4

• **486 f}fU[]f{[]fh**

• **25R2**

**B2 for SOYO 25R2 Mainboards**

• DISC2:\BIOS\SOYO\25R2-B2

• **4SAW2**

**0911 for SOYO 4SAW2 Mainboards 1997/9/11**

• DISC2:\BIOS\SOYO\4SAW0911

• **4SA2**

**0730 for SOYO 4SA2 Mainboards 1997/7/30**

• DISC2:\BIOS\SOYO\4SA0730

• **30H**

**B2 for SOYO 30H Mainboards**

• DISC2:\BIOS\SOYO\30H-B2