

The monitor type affects the number of resolutions and refresh rates displayed. If the monitor type is not set correctly, use the Display Properties Settings tab to set the correct monitor type.

Monitor type.

Current resolution.

Current bit depth.

Current refresh rate.

Resolution.

Bit depth.

Refresh rate.



This resolution has been used by the system or an application but not set. Please set to a more adequate resolution.



