

QuickTime Sound Problem  
David R. Weaver, Naperville, IL, USA

I experienced the same symptoms as John F. Smith (Letters, Vol. 3-7) in that playing QuickTime results in "Wave" audio being left at the maximum setting. Here is a kluge which uses the "Pro Mixer" to get around this Problem: 1) Set the "Wave" slider to maximum. 2) Set the "WAVE" "Rec/Play" button to "Rec." 3) Set the "Rec" slider to the desired sound level for "Wave."

Note that the "Rec" slider is not the "Record" Master slider. Also, note that all buttons except "Wave" and "Rec", which can't be changed, should be set to "Play."

**From the Tech Desk:**

**Sounds like you have a work-around; that's great. Of course, we are still working with Apple to completely resolve this issue. We have a work-around of our own: Set the "Wave" control and others to the maximum setting. Then, adjust the "Master" control to the desired sound level. We will keep you posted of our findings from Apple.**