

Simulation

The checkboxes in this view control the default settings of the “Sim.”, “Crit.” and “Sens.” attributes. Similarly, the “Sensitivity factor” contains the default value of the “S.fact.” attribute.