

Sheet1

PR_NAME,C,25	PR_SETUP,C,60	PR_RESET,C
Alphacom 8125		
Anadex 9620A		
Anadex DP-6500		
Anadex DP-9000/DP-9500		
Anadex DP-9001/DP-9501		
	LGP	
	LANGUAGE=X630	
	X630.RESET	
	X630.SPACING=STANDARD	
AST TurboLaser	END!	
Blaser	(
Brother HR1		
Brother HR15/25		
C. Itoh 8510A		
C. Itoh F10		
C. Itoh LIPS 10+	(O) SEM 6; EXIT;E	
	:	
Canon LBP-8 A1/A2	P	
Canon LBP-8 A1/A2(ISO)c		
Centronics 351/352/353		
Centronics H80-1/H80-2	@	
Citizen MSP-10/MSP-15	@	
Comrex CR-I		
Comrex CR-II	P	
Cordata LP300	@RESET;@FONT MX9M;	
DaisyWriter 1500/2000	S	
Data Products SPG-8010		
Datasouth DS 180		
Diablo 620 & 630	P	
Dynax DX-15	P	
Epson E/F/J/RX/LQ	@	
Epson EX-800/1000	@	
Epson LX	@	
Epson LX-90		
Epson MX	@	
Generic printer		
HP 2225C+ (Epson Mode@		
HP 2225C+ (HP Mode)	E	
HP LaserJet	E	
HP LaserJet 500+/II/III	E	
HP PaintJet (HP3630)	E	
IBM 80 CPS Graphics	6	
IBM 80 CPS Matrix		
IBM Color Printer	?	
IBM LetterQuality 5218	p5	

Sheet1

IBM Pageprinter 3812
IBM Proprinter
IBM Quietwriter 5201
IBM Quietwriter III
IBM Wheelprinter 5216
IDS 460
IDS Prism 80/132

Juki 6100 IQ
Kyocera F-1010 (Land) !R! RES; UNIT D; SPO L; EXIT;
Kyocera F-1010 (Port) !R! RES; UNIT D; SPO P; EXIT;
Mannesmann MT160/180[6~
Mannesmann Spirit-80 @
NEC Pinwriter P2/P3
NEC Pinwriter P2200 @
NEC Pinwriter P5/P6/P7 @
NEC Silentwriter LC850 #A
NEC Silentwriter LC860 E
NEC Spinwriter 3550 =
NEC Spinwriter 5515/25
NEC Spinwriter 7710/20 #B
NEC Spinwriter 7715/25 R
NEC Spinwriter 7730
Oki Laserline 6 E
Oki Microline 182/183
Oki Microline 192/193
Oki Microline 292/3/4
Oki Microline 82A/83A
Oki Microline 84/92/93
Oki Okimate 20
Oki Pacemark 2350
Oki Pacemark 2410
Oki Pacemark 2410-IBM
Oki Plug&Play 192/193
Oki Plug&Play 82A/83A
Oki Plug&Play 84/92/93
Panasonic KX-P1090 @
Panasonic KX-P1091 @

Panasonic KX-P3151 I
Quadram QuadJet

QuadLaser |1e|1s|2i
Qume Sprint 5 I

Qume Sprint 9/45, 9/55 I

Sanyo PR-5500 P
Silver Reed 550 (Line)

Sheet1

Silver Reed 550 (Ser)	P
Silver Reed 770	P
Star Gemini 10-X/15-X	@
Star Radix 10/15	@
Texas Inst 850/855	
Texas Inst 860/865	@
Toshiba P 341/351	I
Toshiba P1340	I
Toshiba P1350	I
Toshiba P1351	I
	+X
Xerox 2700 II	
Xerox 4045 - 630 Mode	P+1Titan10iso-P+2XCP14iso-L
None	

Sheet1

PR_6LPI,C,40

PR_8LPI,C,40

H
H
H
H

I
I
I
I

LGP
X630.VERTICAL=51
END!

LGP
X630.VERTICAL=68
END!

2
6

0

A
L08
&I7.27C

B
L06
&I5.45C

ø0 B
[1z
2
2
6

ø4 B
[2z
0
0

@LH 48;@TBORDER 66;@PHEIGHT 3168; 808
B,8,\$ [1z

@LH 36;@TBORDER 66;@PHEIGHT 3168; 806
B,6,\$ [2z

2
2
2
2
2

0
0
0
0
0

2
&I6D
&I7.27C
&I7.27C
&I6D
2
2
2

0
&I8D
&I5.45C
&I5.45C
&I8D
0
0
0
0

Sheet1

2
2
2
2
2
2
B,8,\$
B,8,\$

0
0
0
0
0
0
B,6,\$
B,6,\$

!R! STM 102; SLPP 51; SLS 46; EXIT;
!R! STM 132; SLPP 66; SLS 46; EXIT;

!R! STM 85; SLPP 68; SLS 35; EXIT;
!R! STM 110; SLPP 88; SLS 35; EXIT;

[3z
2
2
2
2
2
2
&!7.27C

[4z
0
0
0
0
0
0
&!5.45C

2
]W
]W
]W
]W
&!6D

0
]U
]U
]U
]U
&!8D

3\$
6
6
6
6
2
4

0
8
8
8
8
A
5

2
2
2
2
2
2
2

0
0
0
0
0
0
0

F

F

8

6

Sheet1

2	0
2	0
2	0

Sheet1

PR_10CPI,C,40

PR_12CPI,C,40

PR_COMPR,C,40

U
Q
H
H

T
T

R
R

LGP
X630.FONT[1]=PCOURIER12
END!F

LGP
X630.FONT[2]=PCOURIER9
END!F
%

LGP
X630.FONT[3]=PCOURIER7
END!F

H
P

E

H
M
M

N
E12
(s10H

E
E10
(s12H

Q
E08
(s16.6H

ø0 K
[1w
H
P
P

ø1 K
[2w
M
M
E

ø2 K
[4w
H
H
M

P

E

M

[1w

[2w

[4w

PH
PH
PH
H
H

MH
MH
MH

H
H
H
H
H

PH
&k0S
&k12H
(s10H
&k0S
H
H
H
H

MH
&k10H
(s12H
&k4S
:
:

H
&k2S
&k8H
(s16.6H
&k2S
H
H
H
H

Sheet1

H	:	H
H	:	H
Xä	Xx	Xã
H	:	H
H	:	H

(s10H	(s12H	(s16.6H
(s10H	(s12H	(s16.6H
[4w	[5w	[6w
H	H	H
?1	?3	?7
P	M	H
P	M	gH
S	I	H
(s10H	(s12H	(s16.6H
S	I	H
]L]J]H
]L]J]H
]L]J]H
]L]J]H
&l0O(0U(s1p10v0s0b1T	(s12H&l0O(0U(s1p10v0s0b2T	&l0O(0U(s-1p10v0s0b5T
H	:	H

H	:	H
6	A	B
6	A	B
H	:	H
H	:	H
H		H
H		H
P	P ^{MUL}	P ^{MUL} H
P	M	H

N

[












Sheet1

B
B
y
y

B
B
z
z

B
B
H
H
[
[
[

Sheet1

PR_BDON,C,12	PR_BDOFF,C,12	PR_ULON E	PR_ULOFF. R	PR_ITON,C,12	PR_ITOFF,C,12
p	q	8	9	t	u
O	&	E	R		
G	H	-			
!	"	E	R		
O	&	X	Y		
(s3B	(s0B	-	R	(s1S	(s0S
		&dD	&d@		
O	&	E	R		
ø1m	ø22m	ø4m	ø24m	ø3m	ø22m
		[4m	[0m		
G	H	-		4	5
G	H	-		4	5
F	&	E	R		
@FONT MX9B;	@FONT MX9M;	@ULON;	@ULOFF;	@FONT MX9MI;	@FONT MX9M;
O	&	I	J		
d	e	f,1,\$	f,0,\$		
		\$1	\$2		
W	&	E	R		
F	&	E	R		
G	H	-		4	5
G	H	-		4	5
G	H	-		4	5
G	H	-		4	5
G	H	-		4	5
E	F	-1	-0		
(s1B	(s0B	&dD	&d@		
(s3B	(s0B	&dD	&d@	(s1S	(s0S
(s3B	(s0B	&dD	&d@	(s1S	(s0S
(s1B	(s0B	&dD	&d@		
G	H	-			
G	H	-			
G	H	-			

Sheet1

E	F	-	-		
G	H	-	-		
E	F	-	-		
O	&	E	R		
(s3B	(s0B	&dD	&d@	(s1S	(s0S
(s3B	(s0B	&dD	&d@	(s1S	(s0S
[=Z	[>z	[4m	[0m		
G	H	-	-	4	5
G	H	-1	-0		
E	F	-	-	4	5
G	H	-1	-0	4	5
E	F	-	'		
(s3B	(s0B	&dD	&d@	(s1S	(s0S
E	F	-	'		
*	,	-	'		
O	&	E	R		
(s1B	(s0B	&dD	&d@	(s1S	(s0S
G	H	-1	-0		
T	I	C	D	!/*	!*
T	I	C	D	!/*	!/*
H	I	C	D		
		-	-	%G	%H
		U	V		
G	H	-	-		
G	H	-	-	%G	%H
G	H	-	-		
G	H	-	-	4	5
G	H	-	-	4	5
O	&	E	R		
O	&	I	J	W	&
		I	J		
K	M	I	J		
O	&	E	R		

Sheet1

O	&	E	R		
G	H	-	-	4	5
G	H	-	-	4	5
K	M	I	J		
G	H	I	J		
Q	R	I	J	H	
		I	J		
		I	J		
		I	J		
b	p	U	W		
W	&	E	R		