

Sheet1

PR_NAME,C,40	PR_SETUP,C,80
Anadex 9620A	
Anadex DP-6500	
	LGP
	LANGUAGE=X630
	X630.RESET
	X630.SPACING=STANDARD
AST TurboLaser	END!
Blaser	(
Brother DM-40	@
Brother HR-1	
Brother HR-20	P
Brother HR-40	P
C. Itoh 8510A	
C. Itoh CI-400/CI-800	>
C. Itoh F10	
C. Itoh LIPS 10+	(O) SEM 6; EXIT;E
Canon BJ-300/BJ-330 (IBM mode)	[K
Canon Bubble Jet BJ-130e	[K
Canon Control Capsule 48/XL	
Canon LBP-4	; <[0q[?1;5;6;7;32h[?2;4;331[0,4,10,0,0,0%u
	:
Canon LBP-8 A1/A2	P
Canon LBP-8 A1/A2(ISO)	c
Canon LBP-8 II (IBML Graphic Set)	; <('\$2[?1;5;6h[?2;4l
Canon LBP-8 IIR/IIT (ISO_UK Graphic Set)	; <[0q(A[?1;5;6h[?2;4l
Canon LBP-8 Mark III	; <[0q[?1;5;6;7;32h[?2;4;331[0;4;10;0;0;0%u
Centronics 351/352/353	
Centronics H80-1/H80-2	@
Citizen MSP-10/MSP-15	@
Comrex CR-I	
Comrex CR-II	P
DaisyWriter 1500/2000	S
Data Products LZR 2655	E
Datasouth DS 180	
Diablo 620 & 630	P
Dynax DX-15	P
Epson EX,FX,JX,LX,RX High-Speed Draft	@
Epson EX,FX,JX,LX,RX Microspace Draft	@
Epson EX,FX,JX,LX,RX Microspace NLQ	@x1
Epson LQ Series Draft Mode	@x0
Epson LQ Series Letter Quality Mode	@x1
Epson MX	@
Fujitsu DL 1200	@
Fujitsu DL 3300/3400	I
Genicom 4410	c[;13m
HP DeskJet	E(10U&kG
HP DeskJet Plus/DeskJet 500	E(10U&kG
HP LaserJet (Original)	&l1H(10U

Sheet1

HP LaserJet +	&l1H(10U
HP LaserJet 2000	&l1H(10U
HP LaserJet 500+	&l1H(10U
HP LaserJet III	&l1H(10U
HP LaserJet III D Duplex	&l1H(10U
HP LaserJet III D Simplex	&l0S&l1H(10U
	%-12345X@PJL ENTER LANGUAGE = PCL
HP LaserJet III Si Simplex	&l0S&l1H(10U
	%-12345X@PJL ENTER LANGUAGE = PCL
HP LaserJet III Si Standard	&l1H(10U
HP PaintJet	E(10U&v0S
HP ThinkJet	E

IBM 5218	[K
IBM Color Printer	?
IBM LaserPrinter 4019	[K 1öí[H [I] ÉÁ
HP LaserJet II = all with 12 CPI font	&l1H(10U
IBM LaserPrinter 4029 Series	[K 1öí[H [I] ÉÁ
IBM LetterQuality 5218	p5
IBM PPSII 2380/2381 Draft Mode	[K [d @

IBM PPSII 2380/2381 Letter Quality mode	[K [d Ç
IBM PPSII 2390/2391 Draft Mode	[K [d @

IBM PPSII 2390/2391 Letter Quality Mode	[K [d Ç
IBM Proprinter II, XL, IIXL, X24, XL24	
IBM Quietwriter 5201	
IBM Quietwriter III	
IBM Wheelprinter 5216	
IDS 460	
IDS Prism 80/132	

Kyocera F-1000A	!R! RES; UNIT D; EXIT;(10U
Kyocera F-1010 (Landscape)	!R! RES; UNIT D; SPO L; EXIT;
Kyocera F-1010 (Portrait)	!R! RES; UNIT D; SPO P; EXIT;
Mannesmann MT160/180	[6~

NEC Pinwriter P2/P3	
NEC Pinwriter P2200	@
NEC Pinwriter P5/P6/P7	@
NEC Pinwriter P5200/P5300	@
NEC Pinwriter P9XL	(
NEC Silentwriter LC 850	#A
NEC Silentwriter LC 860	E
NEC Spinwriter 2000	#A
NEC Spinwriter 3550	=
NEC Spinwriter 5515/25	
NEC Spinwriter 7710/20	#B
NEC Spinwriter 7715/25	R
NEC Spinwriter 7730	

Okí 320/321	@
Okí Laser 400	E
Okí Microlíne 182/183/192/193	
Okí Microlíne 292/3/4	
Okí Microlíne 390/391	@t1
Okí Microlíne 393/393C	@6

Sheet1

Oki Microline 84/92/93	
Oki Okimate 20	
Oki Pacemark 2350	
Oki Pacemark 2410	
Oki Pacemerk 2410-IBM	
Oki Plug&Play 192/193	
Olympia NP-80/NP-136	@6
Panasonic KX-P1090	@
Panasonic KX-P1124	@t
Panasonic KX-P1091	@
Panasonic KX-P1180	@t
Panasonic KX-P1624	@
Panasonic KX-P3151	I
Panasonic KX-P4450/4450i Epson Mode	E;@t
Panasonic KX-P4450/4450i Panasonic Mode	H,P,X0,Y0;1E(10U
Primage I	P
Quadram QuadLaser	1e 1s 2i
Qume LetterPro 20	P
Qume Sprint 9/45, 9/55	I
Sanyo PR-5500	P
Silver Reed 770	P
Star Gemini 10-X/15-X	@
Star Radix 10/15	@
Tandy DMP 2100P	!:
Tandy DMP 2110	7!
Toshiba P 351 SX	I
Toshiba PageLaser 12	I
Texas Instruments 810 LQ	
Xerox 4045 - 630 Mode ASCII	P+1Titan10iso-P+2XCP14iso-L
HP LaserJet IV	&l1H(10U
HP LaserJet II - all without 12 CPI font	&l1H(10U
HP LaserJet V	&l1H(10U

Sheet1

PR_RESET,C,80PR_6LPI,C,80

H
H

LGP
X630.VERTICAL=51
END!

2
2
6

@

RS
A
?!
L08
&!7.27C
2
2
2
< [0 L

ø0 B
< [0 L
< [0 L
< [0 L
[1z
2
2
6

808
&!6D
[1z

2
2
2
2
2
2
2
2
@
I
0
[120; G
E &!6D
E &!6D
E &!6D

PR_8LPI,C,80

I
I

LGP
X630.VERTICAL=68
END!

0
0

RS
B
?!#
L06
&!5.45C
0
0
0
< [4 L

ø4 B
< [4 L
< [4 L
< [4 L
[2z
0
0

806
&!8D
[2z

0
0
0
0
0
0
0
0
2
[90; G
&!8D
&!8D
&!8D

Sheet1

E	&I6D	&I8D
E	&I6D	&I8D
E	&I6D	&I8D
E	&I6D	&I8D
E	&I6D	&I8D
E	&I6D	&I8D
%-12345X		
	&I6D	&I8D
%-12345X		
	&I6D	&I8D
(10U&v0S	&I6D	&I8D
	&I6D	&I8D
[K	2	0
		0
[K	3\$	0
E	&I6D	&I8D
[K	3\$	0
	2	0
[K	2	0
[K	2	0
[K	2	0
[K	2	0
	2	0
	2	0
	2	0
	2	0
	2	0
	B,8,\$	B,6,\$
	B,8,\$	B,6,\$
!R! RES; EXIT;	!R! SLPI 6; EXIT, E;	!R! SLPI 8; EXIT, E;
	!R! STM 102; SLPP 51; SLS 46; EXIT;	!R! STM 85; SLPP 68; SLS 35; EXIT;
	!R! STM 132; SLPP 66; SLS 46; EXIT;	!R! STM 110; SLPP 88; SLS 35; EXIT;
	[3z	[4z
	2	0
	2	0
	2	0
	2	0
	2	0
(2	0
	2	0
	&I7.27C	&I5.45C
#A]W]U
	2	0
]W]U
]W]U
]W]U
]W]U
@]W]U
	2	0
	&I6D	&I8D
	6	8
	6	8
	2	0
	2	0

Sheet1

	6	8
	2	A
	4	5
	A12	0
	2	0
	2	0
@	2	0
	2	0
@	2	0
	2	0
	2	0
	2	0
	2	0
@	2	0
E	&l6D	&l8D
P		
P		
	8	6
	2	0
	2	0
		0
	2	0
	L8	L6
	%	
	4	5
E	&l6D	&l8D
E	&l6D	&l8D
E	&l6D	&l8D

Sheet1

PR_10CPI,C,80
U
Q

PR_12CPI,C,80
T
T

PR_COMPR,C,80
R
R

LGP
X630.FONT[1]=PCOURIER12
END!F

LGP
X630.FONT[2]=PCOURIER9
END!F
%

LGP
X630.FONT[3]=PCOURIER7
END!F

P
P

M
E

M

US
N
?
E12
(s10H

US
E
?!
E10
(s12H
:
:
:

Q
?#
E08
(s16.6H

[0 K

[1 K

(' \$2[?1666 K

ø0 K
[0 K
[0 K
[0 K
[1w

ø1 K
[1 K
[1 K
[1 K
[2w

ø2 K
[2 K
[2 K
[?1700 K
[4w

P
P

M
E

M

P
(s10H
[1w

E
(s12H
[2w

M
(s16.6H
[4w

P
P
P
P

M
M
M
M
M
M
M

P
P
[;72 G
(s10H
(s10H
(s10H

[;60 G
(s12H
(s12H
(s12H

[;43 G
(s16.67H
(s16.67H
(s16.66H

Sheet1

(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
&k0S	&k4S	&k2S
&k3S	&k0S	&k2S
>	>	>
	:	
	:	
(s10H	(s12H	(s16.66H
	:	
	:	
	:	
Xä	Xx	Xã
	:	
	:	
!R! SCPI 10; EXIT, E;	!R! SCPI 12; EXIT, E;	(s16.66H
(s10H	(s12H	(s16.6H
(s10H	(s12H	(s16.6H
[4w	[5w	[6w
?1	?3	?7
P	M	
P	M	g
P	M	g
P	M	P
S	I	
(s10H	(s12H	(s16.6H
]L]J]H
S	I	
]L]J]H
]L]J]H
]L]J]H
]L]J]H
P	M	P
(s10H	(s12H	(s16.6H
P	M	
P	M	g

Sheet1

6	:	
6	A	B
	A	B
	:	
	:	
	:	
P	P	P
P	M	P
P	M	
	M	
P	M	g
P	M	
(s10H	(s12H	(s16.66H

B	B	B
B	B	B
	:	
	:	
E12	E10	[
E12	E10	[
6	V	2

(s10H	(s12H	(s16.66H
(s10H	(s0t&k10H	(s16.66H
(s10H	(s12H	(s16.66H

Sheet1

PR_PORT,C,80	PR_LAND,C,80	PR_B	PR_B	PR_UL	PR_UL	PR_IT	PR_ITO
		p	q	8	9	t	u
LGP X630.FORMAT=PORTRAIT END!	LGP X630.FORMAT=LANDSCAPE END!	O	&	E	R		
@	?	G E	H F	- -			
		F	O	E	R		
		F ! 3!	& 3	E X 2!	R Y		
&l0O	&l1O&l14c1E	O (s3B G G E	& H H F	- - -	R 	(s1S	(s0S
[0p	[1p	[1m	[22m	[4m	[24m	[3m	[23m
ø0%r	ø1%r	O ø1m	& ø22m	E ø4m	R ø24m	ø3m	ø22m
[0p	[1p	[1m	[22m	[4m	[24m	[3m	[23m
[0p	[1p	[1m	[22m	[4m	[24m	[3m	[23m
[0p	[1p	[1m	[22m	[4m	[24m	[3m	[23m
				[4m	[0m		
		G G	H H	- -	 	4 4	5 5
		F O	& &	E I	R J		
&l0O	&l1O	(s3B	(s0B	&d0D \$1	&d@ \$2	(s1S	(s0S
		W	&	E	R		
		F G G E E E G G G	& H H F F F H H	E -1 -1 -1 -1 -1 - -1 -1	R -0 -0 -0 -0 -0 -0 -0	4 4 4 4 4 4 4	5 5 5 5 5 5 5
		[1m	[0m	[4m	[0m		
		(s3B	(s0B	&dD	&d@	(s1S	(s0S
&l0O	&l1O&k1W	(s3B	(s0B	&dD	&d@	(s1S	(s0S
&l0O	&l1O	(s3B	(s0B	&dD	&d@	(s1S	(s0S

Sheet1

&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
&l00&l1S	&l10&l1S	(s3B (s0B &dD &d@ (s1S (s0S
&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S

&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
------	------	-----------------------------

&l00	&l10	(s3B (s0B &dD &d@ (s1S (s0S
		(s1B (s0B &dD &d@
		(s1B (s1B &dD &d@

k		E F -	[NUL]		
&l00	&l10	G H -	[NUL]		
k		G H -	[NUL]		
		(s3B (s0B &dD &d@ (s1S (s0S			
		G H -	[NUL]	[Z]	[Z]
		-	[NUL]		
		G H -	[NUL]	[@]	[@]
		G H -	[NUL]	[@]	[@]
		G H -	[NUL]	[@]	[@]
		G H -	[NUL]	[@]	[@]
		-	[NUL]		
		-	[NUL]		
		G H -	[NUL]		

!R! SPO P; EXIT;	!R! SPO L; EXIT;	(s3B (s0B &dD &d@ (s1S (s0S			
		(s3B (s0B &dD &d@ (s1S (s0S			
		(s3B (s0B &dD &d@ (s1S (s0S			
		[=z [>z [4m [0m			
		G H -1 -0			
		E F -	[NUL]	4	5
		G H -1 -0		4	5
		E F !128 !0		4	5
		E F -	[NUL]	4	5
		E F -	'		

&l00	&l10&l14c1E	(s3B (s0B &dD &d@ (s1S (s0S
		* , - '
		E F - '
		* , - '
		O & E R

&l00	&l10	E F -	[NUL]	4	5
		(s3B (s0B &d0D &d@ (s1S (s0S			
		T I C D !/ !*			
		T I C D !* !/			
		E F -1 -0		4	5
		G H -	[NUL]	4	5

Sheet1

		H	I	C	D		
				-	U	%G	%H
		G	H	-	V		
		G	H	-			
		G	H	-		%G	%H
		G	H	-1	-0	4	5
		G	H	-		4	5
		G	H	-		4	5
		G	H	-		4	5
		G	H	-1	-0	4	5
		E	F	-		4	5
E,P,X50,Y0; &l00	E,L,X100,Y0; &l10	O	&	E	R		
		E	F	-1	-0	4	5
		(s3B	(s0B	&dD	&d@	(s1S	(s0S
		O	&	E	R		
0m	1m	O	&	I	J	W	&
		Q	R	I	J		
		K	M	I	J		
		O	&	E	R		
		G	H	-		4	5
		G	H	-		4	5
		E	F	-			
		K3	M	I	J		
		K	M	I	J		
		N	O	-	^		
F1	F2	W	&	E	R		
&l00	&l10	(s3B	(s0B	&d0D	&d@	(s1S	(s0S
&l00&l1S	&l10&l1S	(s3B	(s0B	&dD	&d@	(s1S	(s0S
&l00	&l10	(s3B	(s0B	&d0D	&d@	(s1S	(s0S

FF,C,80

ULSUL

ULSUL
ULSUL

ULSUL