

Sheet1

PRINTER,C,20	BOLD_UNDLINTALIC SUPSCR SUBSCR_COMP_ONWIDE_ON,C,SEBOLD_UNDLI										
ASCII (Plain Text)										###	
Canon BJ-10e	E	-1								###  F	-0
Canon LBP Plus	[[1m	[[4m	[[3m			[[0y	[[200;200 B	###	[[22m	[[24m	
Epson FX	G	-1		S0	S1		W1	###	H	-0	
Epson LQ 2500	G	-1	4	S0	S1		W1	###	H	-0	
Epson LQ 800/1000	E	-1	4	S0	S1		W1	###	F	-0	
Epson LX 800/810	E	-1	4	S0	S1		W1	###	F	-0	
HP Deskjet 500	(s3B	&d0D	(s1S	(s1u6V	(s-1u6V	(s16.67H	(s5H	###	(s0B	&d@	
HP Laserjet I	(s7B	&dD	(s1S			&k2S		###	(s0B	&d@	
HP Laserjet II	(s3B	&dD	(s1S			&k2S		###	(s0B	&d@	
HP Laserjet III	(s3B	&dD	(s1S			&k2S		###	(s0B	&d@	
HP Laserjet IV	(s3B	&dD	(s1S			&k2S		###	(s0B	&d@	
IBM Proprinter	E	-1		S0	S1		W1	###	F	-0	
Panasonic KX-P1091i	G	-1	4	S0	S1		W1	###	H	-0	
Panasonic KX-P1624	E	-1	4	S0	S1		W1	###	F	-0	

Sheet1

ITALIC SUPSCR\_SUBSCR\_COMP\_WIDE\_OFF,(PORTFLANDSLEGALLETTE ENV\_MARGIILABELS

											00L00
											00L00
[[23m			[[3y	[[100;100 B	[[0p	[[1p				[[11h][2160d	00L00
	T	T		W0							00L00
5	T	T	M	W0							00L00
5	T	T	P	W0							00L00
5	T	T	M	W0							00L00
(s0S	(s0u10V	(s0u10V	(s10H	(s10H	&l0O	&l1O	&l3A	&l2A	&a1650H		00L11
(s0S			&k0S		&l0O	&l1O	&l3A	&l2A	*p1650X		03L11
(s0S			&k0S		&l0O	&l1O	&l3A	&l2A	*p1650X		03C11
(s0S			&k0S		&l0O	&l1O	&l3A	&l2A	*p1650X		03C11
(s0S			&k0S		&l0O	&l1O	&l3A	&l2A	*p1650X		03C11
	T	T		W0							00L00
5	T	T		W0							00L00
5	T	T		W0							00L00

Sheet1

FONT\_1,C,40

FONT\_2,C,40

FONT\_3,C,40

|:|[3y  
|x0

|:  
|[4y  
|x1

||[5y  
|x1|k0

|x0  
|x0  
|(s1Q

|x1  
|x1  
|(s2Q

|x1|k0

|(8U|(s0p10.00v0s0b3T|&l6D  
|(8U|(s0p10.00v0s0b3T|&l6D

|(8U|(s0p10.00v0s3b4101T|&l6D  
|(8U|(s0p10.00v0s3b4101T|&l6D

|(8U|(s1p12.00v0s3b4101T|&l6D  
|(8U|(s1p12.00v0s3b4101T|&l6D

|x1  
|k0

|x2  
|k1

|x3  
|k2

FONT\_4,C,40

FONT\_5,C,40

[[16y  
|x1|k1

[[23y

|x1|k1

|(8U|(s1p12.00v0s3b4148T|&l6D |(8U|(s1p36.00v0s3b4101T|&l2D  
|(8U|(s1p12.00v0s3b4148T|&l6D |(8U|(s1p36.00v0s3b4101T|&l2D

|x4  
|k3

|x5  
|k6