

Settings of SCSI Scanner Interface Card

1. The scanner interface card needs an I/O port address selection which is set to either 0280, 0290, 0300, 0310, 0330, 0340, 0348 or 0350.
(default is 0280)



280 ~ 28F .

330 ~ 33F



290 ~ 29F .

340 ~ 34F



300 ~ 30F .

348 ~ 357



310 ~ 31F .

350 ~ 35F

2. If you have any other device(s) in your computer which is using an I/O port, please check the used I/O port address(es) and set the scanner interface card to a free I/O port.

