

## Contents for Panasonic KX-P6500/P6300/P6100 GDI Overlay Help

The **Overlay** screen is one of the most powerful features of the KX-P6500/P6300/P6100 software. The feature lets you overlay an image on top of any document printed in GDI print mode.

You can use this feature to:

- \* Incorporate your letterhead on the first page of a business letter.
- \* Print your logo at the bottom of each page of a set of presentation slides.
- \* Overlay the word "Confidential" on every page of an important document.
- \* Print a special cover page or trailer page for each print job.

### **Print Cover Page:**

Select this feature to print a cover page on a separate page before the remainder of your document.

### **Print Trailer Page:**

Select this feature to print a trailer page on a separate page after the document has been printed.

### **Print Overlay:**

This feature will overlay your image on the pages of your document. The effect is similar to printing your image on a transparency, then putting the transparency over your document.

Select 1st to overlay the image only on the first page of the document.

Select All to overlay the image on each page in the document.

Select From to overlay the image on a range of pages within the document.

### **Buttons**

[OK](#)

[Cancel](#)

[Browse](#)

[Help](#)

**OK**

Click on **OK** to make your changes take effect and return to the previous screen.

## **Cancel**

Click on ***Cancel*** to ignore any changes you have made and return to the previous screen.

## **Browse**

After selecting *Print Cover Page*, *Print Trailer Page*, or *Print Overlay*, clicking **Browse** will let you search for your GDI file in the file system.

## **Help**

*Help* provides detailed help on the Overlay features screen.

