

Reinstalling the Right End-Cover.

1- Before replacing the end-cover, make sure that

- a) The black plastic piece at the front end of the pinch arm linkage is correctly attached to the side-plate.
- b) The lever nut is positioned inside the slot on the black plastic piece.



